User Manual

PC Cards cifX PC/104 (CIFX 104)

Installation, Operation and Hardware Description





Hilscher Gesellschaft für Systemautomation mbH

www.hilscher.com

DOC120206UM42EN | Revision 42 | English | 2014-12 | Released | Public

Table of Contents

1 INTRODUCTION 7
1.1 About the User Manual 7
1.1.1 List of Revisions 8
1.1.2 Notes on Hardware, Firmware, Software and Driver Versions 9
1.1.3 Conventions in this Manual 11
1.1.4 Used Terminology 11
1.2 Contents of the Product DVD 12
1.2.1 Installation Guide, Documentation Overview 12
1.2.2 What's New 12
1.2.3 Important Changes 12
1.2.4 Device Description Files cifX 15
1.3 Legal Notes 16
1.3.1 Copyright 16
1.3.2 Important Notes 16
1.3.3 Exclusion of Liability 17
1.3.4 Warranty 17
1.3.5 Export Regulations 18
1.3.6 Registered Trademarks 18
1.3.7 EtherCAT Disclaimer 19
1.3.8 Obligation to read and understand the Manual 19
1.4 Licenses 19
1.4.1 License Note about VARAN Client 19

2 SAFETY 20
2.1 General Note 20
2.2 Intended Use 20
2.3 Personnel Qualification 21
2.4 Safety Instructions to avoid Personal Injury 21
2.4.1 Electrical Shock Hazard 21
2.5 Safety Instructions to avoid Property Damage 22
2.5.1 Device Destruction by exceeding allowed Supply Voltage 22
2.5.2 Device Destruction by exceeding allowed Signaling Voltage 22
2.5.3 Electrostatically sensitive Devices 23
2.6 Labeling of Safety Messages 24
2.6.1 References Safety 24

3 DESCRIPTIONS AND REQUIREMENTS 25
3.1 Description 25
3.2 PC Cards cifX with integrated Interfaces 26
3.2.1 PC Cards PC/104: CIFX 104-XX, CIFX 104-XX-R 26
3.3 PC Cards cifX with AIFX Assembly Interfaces 26
3.3.1 The Label „\F“ in the Device Name 26

© Hilscher, 2008-2014

3.3.2 PC Cards PC/104: CIFX 104-XX\F, CIFX 104-XX-R\F 27
3.3.3 AIFX Assembly Interfaces 27
3.4 System Requirements 28
3.4.1 Slot for the PC Cards cifX PC/104 28
3.4.2 Power Supply and Host Interface 28
3.4.3 Panel Cutout for Installing AIFX 28
3.4.4 System Requirements cifX PC/104 (ISA) 29
3.5 Requirements for Operation of the PC Cards cifX 30

4 GETTING STARTED 31
4.1 Installation and Configuration PC Card cifX PC/104 31
4.2 Note on Exchange Service (Replacement Case) 35
4.3 Notes for the Configuration of the Master Device 35
4.4 Device Names in SYCON.net 36
4.5 Update for Firmware, Driver and Software 37

5 DEVICE DRAWINGS 38
5.1 PC-Karten cifX PC/104 38
5.1.1 CIFX 104-RE 38
5.1.2 CIFX 104-RE-R 39
5.1.3 CIFX 104-RE\F 40
5.1.4 CIFX 104-RE-R\F 41
5.1.5 CIFX 104-DP 42
5.1.6 CIFX 104-DP-R 43
5.1.7 CIFX 104-CO 44
5.1.8 CIFX 104-CO-R 45
5.1.9 CIFX 104-DN 46
5.1.10 CIFX 104-DN-R 47
5.1.11 CIFX 104-DP\F, CIFX 104-CO\F, CIFX 104-DN\F, CIFX 104-CC\F 48
5.1.12 CIFX 104-DP-R\F, CIFX 104-CO-R\F, CIFX 104-DN-R\F 48
5.2 AIFX Assembly Interfaces 49
5.2.1 Ethernet - AIFX-RE 49
5.2.2 PROFIBUS - AIFX-DP 50
5.2.3 CANopen - AIFX-CO 51
5.2.4 DeviceNet - AIFX-DN 52
5.2.5 CC-Link - AIFX-CC 53
5.2.6 Diagnostic - AIFX-DIAG 54

6 HARDWARE INSTALLATION AND UNINSTALLING 55
6.1 Safety Messages on Personal Injury 55
6.1.1 Electrical Shock Hazard 55
6.2 Property Damage Messages 56
6.2.1 Device Destruction by exceeding allowed Supply Voltage 56
6.2.2 Device Destruction by exceeding allowed Signaling Voltage 56
6.2.3 Electrostatically sensitive Devices 56
6.3 cifX PC/104: Set Starting Address and Interrupt 57

© Hilscher, 2008-2014

6.4 Installing PC Cards cifX PC/104 (PC/104 Modules) 59
6.5 Uninstalling PC Cards cifX PC/104 62

7 TROUBLESHOOTING 63
7.1 Instructions for Problem Solving 63

8 LED DESCRIPTIONS 64
8.1 Overview LEDs Real-Time Ethernet Systems 64
8.2 Overview LEDs Fieldbus Systems 65
8.3 System LED 65
8.4 Power On LED 65
8.5 EtherCAT Master 66
8.6 EtherCAT Slave 67
8.7 EtherNet/IP Scanner (Master) 68
8.8 EtherNet/IP Adapter (Slave) 69
8.9 Open Modbus/TCP 70
8.10 POWERLINK Controlled Node/Slave 71
8.11 PROFINET IO-Controller 72
8.12 PROFINET IO-Device 73
8.13 sercos Master 74
8.14 sercos Slave 75
8.15 VARAN Client (Slave) 76
8.16 PROFIBUS DP Master 77
8.16.1 1 Communication Status LED 77
8.16.2 2 Communication Status LEDs 77
8.17 PROFIBUS DP Slave 78
8.17.1 1 Communication Status LED 78
8.17.2 2 Communication Status LEDs 78
8.18 PROFIBUS MPI Device 79
8.18.1 1 Communication Status LED 79
8.18.2 2 Communication Status LEDs 79
8.19 CANopen Master 80
8.19.1 1 Communication Status LED 80
8.19.2 2 Communication Status LEDs 81
8.20 CANopen Slave 82
8.20.1 1 Communication Status LED 82
8.20.2 2 Communication Status LEDs 83
8.21 DeviceNet Master 84
8.22 DeviceNet Slave 85
8.23 CC-Link Slave 86

9 DEVICE CONNECTIONS AND SWITCHES 87

© Hilscher, 2008-2014

9.1 Ethernet Interface 87
9.1.1 Ethernet Pin Assignment at the RJ45 Socket 87
9.1.2 Ethernet Connection Data 88
9.1.3 Use of Hubs and Switches 88
9.2 PROFIBUS Interface 89
9.3 CANopen Interface 89
9.4 DeviceNet Interface 90
9.5 CC-Link Interface 90
9.6 Mini-B USB Connector (5 Pin) 91
9.7 Rotary Switch Device Address 91
9.8 Cable Connector 92
9.8.1 Pin Assignment for Cable Connector Ethernet 92
9.8.2 Pin Assignment for Cable Connector Fieldbus X3, X304, X4 93
9.8.3 Pin Assignment for Cable Connector DIAG 93
9.9 SYNC Connector (Pin-Assignment, Hardware/Firmware) 94
9.9.1 Pin Assignment SYNC Connector, X51 (CIFX 80 90 104C) 94
9.9.2 Items on Hardware 94
9.9.3 Items on Firmware 94
9.10 Pin Assignment at the PC/104 Bus 95
9.10.1 Overview 95
9.10.2 Reference PC/104 Specification 95
9.10.3 Pin Assignment for PC/104 Bus 96

10 TECHNICAL DATA 98
10.1 Technical Data PC Cards cifX 98
10.1.1 CIFX 104-RE, CIFX 104-RE-R 98
10.1.2 CIFX 104-RE\F, CIFX 104-RE-R\F 100
10.1.3 CIFX 104-DP, CIFX 104-DP-R 102
10.1.4 CIFX 104-DP\F, CIFX 104-DP-R\F 103
10.1.5 CIFX 104-CO, CIFX 104-CO-R 105
10.1.6 CIFX 104-CO\F, CIFX 104-CO-R\F 106
10.1.7 CIFX 104-DN, CIFX 104-DN-R 108
10.1.8 CIFX 104-DN\F, CIFX 104-DN-R\F 109
10.1.9 CIFX 104-CC\F 110
10.1.10 AIFX-RE 112
10.1.11 AIFX-DP 113
10.1.12 AIFX-CO 114
10.1.13 AIFX-DN 115
10.1.14 AIFX-CC 116
10.1.15 AIFX-DIAG 117
10.2 Technical Data of the Communication Protocols 118
10.2.1 EtherCAT Master 118
10.2.2 EtherCAT Slave 119
10.2.3 EtherNet/IP Scanner (Master) 120
10.2.4 EtherNet/IP Adapter (Slave) 121
10.2.5 Open Modbus/TCP 122

© Hilscher, 2008-2014

10.2.6 POWERLINK Controlled Node/Slave 122
10.2.7 PROFINET IO-Controller 123
10.2.8 PROFINET IO-Device (V3.4) 124
10.2.9 PROFINET IO-Device (V3.5) 125
10.2.10 sercos Master 126
10.2.11 sercos Slave 127
10.2.12 VARAN Client (Slave) 128
10.2.13 PROFIBUS DP Master 129
10.2.14 PROFIBUS DP Slave 130
10.2.15 PROFIBUS MPI 131
10.2.16 CANopen Master 132
10.2.17 CANopen Slave 133
10.2.18 DeviceNet Master 134
10.2.19 DeviceNet Slave 135
10.2.20 CC Link Slave 136

11 ANNEX 137
11.1 Matrix Label 137
11.2 EtherCAT Summary over Vendor ID, Conformance test, Membership and Network Logo 137
11.2.1 Vendor ID 137
11.2.2 Conformance 138
11.2.3 Certified Product vs. Certified Network Interface 138
11.2.4 Membership and Network Logo 138
11.3 Notes on earlier Hardeware Revisions 139
11.3.1 Failure in 10 MBit/s Half Duplex Mode and Workaround 139
11.4 Disposal of Waste Electronic Equipment 140
11.5 References 140
11.6 List of Figures 141
11.7 List of Tables 141
11.8 Glossary 145
11.9 Contacts 154

© Hilscher, 2008-2014

1 Introduction

1.1 About the User Manual

This user manual provides descriptions of the **installation**, **operation** and **hardware** of the PC cards cifX *PC/104* under Windows® XP, Windows® Vista, Windows® 7 and Windows® 8, as listed subsequently.

PC Cards cifX PC/104 (CIFX 104) inclusively the AIFX Assembly Interfaces[1]:

- Ethernet (AIFX-RE)
- PROFIBUS (AIFX-DP)
- CANopen (AIFX-CO)
- DeviceNet (AIFX-DN)
- CC-Link (AIFX-CC)
- Diagnose (AIFX-DIAG)

for the Real-Time Ethernet systems:

- EtherCAT
- EtherNet/IP
- Open-Modbus/TCP
- POWERLINK
- PROFINET IO
- sercos
- VARAN

for the fieldbus systems:

- PROFIBUS DP
- PROFIBUS MPI
- CANopen
- DeviceNet
- CC-Link

For information about the **Installation of the Software** refer to the User Manual „Software Installation for PC cards cifX“ [DOC120207UMXXEN]. For information about the **Wiring of the Protocol Interface** refer to the „Wiring Instructions“ [DOC120208UMXXEN].
The **devices described in this manual** are listed in the sections *PC Cards cifX with integrated Interfaces* (page 26) and *PC Cards cifX with AIFX Assembly Interfaces* (page 26).
The devices are described in detail in the chapters *Hardware Installation and Uninstalling* (page 55), *LED Descriptions* (page 64), *Device Connections and Switches* (page 87) and *Technical Data* (page 98).

You can download the latest edition of a manual from the website www.hilscher.com under **Support** > **Downloads** > **Manuals** or under **Products** directly with the information about your product.

[1] The AIFX Assembly Interface is also named as „Detached Network Interface“.

© Hilscher, 2008-2014

1.1.1 List of Revisions

Index	Date	Chapter	Revisions
40	13-12-18	10.2.2 10.2.3 10.2.4 10.2.9 10.2.10 10.2.11 10.2.17 11.5	Section Technical Data *EtherCAT Slave* updated. Section Technical Data *EtherNet/IP Scanner (Master)* updated. Section Technical Data *EtherNet/IP Adapter (Slave)* updated. Section Technical Data *PROFINET IO-Device (V3.5)* added. Section Technical Data *sercos Master* updated. Section Technical Data *sercos Slave* updated. Section Technical Data *CANopen Slave* updated. Section *References* updated.
41	14-06-18	All 8.14	Items on Safety Messages updated. Sections *sercos Slave* (LEDs) flashing frequency for Identification, MST losses, Application error and Watchdog error corrected from 4 Hz to 2 Hz.
42	14-12-01	All 7.1, 8.1, 8.2, 8.14, 10.1, 11.8	Details about the PC card CIFX 104-CC\F as well as for the assembly interface AIFX-CC added. Sections *Instructions for Problem Solving, Overview LEDs Real-Time Ethernet Systems*, *Overview LEDs Fieldbus Systems*, *sercos Slave*, *Technical Data PC Cards cifX*, *Glossary* updated and completed.

Table 1: List of Revisions

© Hilscher, 2008-2014

1.1.2 Notes on Hardware, Firmware, Software and Driver Versions

Note on Software Update: The hardware revisions and the versions for the firmware, the driver or the configuration software listed in this section functionally belong together. For existing hardware installation the firmware, the driver and the configuration software must be updated according to the details listed in this section.
For the software upgrade system overview refer to section *Update for Firmware, Driver and Software* on page 37.

1.1.2.1 Hardware: PC Cards cifX, AIFX Assembly Interfaces

PC Card cifX, AIFX	Part No.	Hardware Revision	USB from HW Rev.
CIFX 104-RE	1278.100	2	1
CIFX 104-RE-R	1279.100	2	1
CIFX 104-RE\F[1]	1278.101	2	1[6]
CIFX 104-RE-R\F[1]	1279.101	2	1[6]
CIFX 104-DP	1278.410	2	1
CIFX 104-DP-R	1279.410	2	1
CIFX 104-DP\F[2]	1278.411	2	1[6]
CIFX 104-DP-R\F[2]	1279.411	2	1[6]
CIFX 104-CO	1278.500	2	1
CIFX 104-CO-R	1279.500	2	1
CIFX 104-CO\F[3]	1278.501	2	1[6]
CIFX 104-CO-R\F[3]	1279.501	2	1[6]
CIFX 104-DN	1278.510	2	1
CIFX 104-DN-R	1279.510	2	1
CIFX 104-DN\F[4]	1278.511	2	1[6]
CIFX 104-DN-R\F[4]	1279.511	2	1[6]
CIFX 104-CC\F[5]	1278.741	2	1[6]
AIFX-RE	2800.100	2	-
AIFX-DP	2800.400	2	-
AIFX-CO	2800.500	2	-
AIFX-DN	2800.510	3	-
AIFX-CC	2800.730	1	-
AIFX-DIAG	2800.000	2	-

[1] inclusively Ethernet Assembly Interface (AIFX-RE)
[2] inclusively PROFIBUS Assembly Interface (AIFX-DP)
[3] inclusively CANopen Assembly Interface (AIFX-CO)
[4] inclusively DeviceNet Assembly Interface (AIFX-DN)
[5] inclusively CC-Link Assembly Interface (AIFX-CC)
[6] only when using the Diagnostic Assembly Interface (AIFX-DIAG)

Table 2: Reference on Hardware PC Cards cifX, AIFX Assembly Interfaces

1.1.2.2 Driver and Software

Driver and Software		Version
SYCON.net	`SYCONnet netX setup.exe`	1.360.x.x
netX Configuration Tool-Setup	`netXConfigurationUtility_Setup.exe`	1.0510.x.x
cifX Device Driver	`cifX Device Driver Setup.exe`	1.2.x.x
Toolkit		1.1.x.x
cifX TCP/IP Server for SYCON.net	`cifX TCP Server.exe`	V2.1.0.0
US Driver	USB Driver of Windows®	5.1.2600.x

Table 3: Reference on Driver and Software

© Hilscher, 2008-2014

1.1.2.3 Firmware

Fieldbus System	Firmware File	Firmware Version	Minimum Version of the Firmware for USB Support	Minimum Version of the Firmware for PC Cards cifX PC/104
CANopen Master	CIFXCOM.NXF	2.11.x.x	from 2.5.2.0	from 2.4.5.0
CANopen Slave	CIFXCOS.NXF	3.6.x.x	from 2.4.4.0	from 2.4.2.0
CC-Link Slave	CIFXCCS.NXF	2.9.x.x	-	-
DeviceNet Master	CIFXDNM.NXF	2.3.x.x	from 2.2.7.0	from 2.2.4.0
DeviceNet Slave	CIFXDNS.NXF	2.3.x.x	from 2.2.7.0	from 2.2.5.0
EtherCAT Master	cifxecm.NXF	3.0.x.x	from 2.4.4.0	from 2.4.3.0
EtherCAT Slave	cifxECS.NXF	2.5. x.x (V2)	from 2.5.13.0	from 2.5.10.0
EtherCAT Slave	cifxECS.NXF	4.2.x.x (V4)	from 2.5.13.0	from 2.5.10.0
EtherNet/IP Adapter	cifxEIS.NXF	2.7. x.x	from 2.3.4.1	from 2.2.3.0
EtherNet/IP Scanner	cifxEIM.NXF	2.6. x.x	from 2.2.4.1	from 2.2.2.0
Open-Modbus/TCP	cifxOMB.NXF	2.5. x.x	from 2.3.2.1	from 2.3.1.0
POWERLINK Controlled Node	cifxPLS.NXF	2.1. x.x	from 2.1.22.0	from 2.1.19.0
PROFIBUS DP Master	CIFXDPM.NXF	2.6.x.x	from 2.3.22.0	from 2.3.21.0
PROFIBUS DP Slave	CIFXDPS.NXF	2.7.x.x	from 2.3.30.0	from 2.3.30.0
PROFIBUS MPI Device	CIFXMPI.NXF	2.4.x.x	from 2.4.1.2	from 2.4.4.1
PROFINET IO Controller	cifxPNM.NXF	2.6. x.x	from 2.4.10.0	from 2.4.10.0
PROFINET IO Device	cifxPNS.NXF	3.4.x.x (V3)	from 3.4.9.0	from 3.4.7.0
PROFINET IO Device	cifxPNS.NXF	3.5.x.x (V3)	from 3.4.9.0	from 3.4.7.0
sercos Master	cifxS3M.NXF	2.1.x.x	from 2.0.14.0	from 2.0.12.0
sercos Slave	cifxS3S.NXF	3.1.x.x	from 3.0.13.0	from 3.0.10.0
VARAN Client	cifxvrs.nxf	1.0.x.x	from 1.0.3.0	from 1.0.3.0

Table 4: Reference on Firmware

The downloadable cifX firmware runs on PC cards cifX *PC/104*. The firmware automatically detects whether it is running on a PC cards cifX *PC-104*. Precedent cifX firmware is only applicable to PC cards cifX *PC/104*.

If a precedent cifX firmware (without PC/104 recognition) is loaded in a PC Card cifX PC/104, the cifX will get defective and must be sent to the service! For the PC cards cifX *PC/104* only cifX firmware from the minimum versions may be used as listed in section *Hardware: PC Cards cifX, AIFX Assembly Interfaces* on page 9.

© Hilscher, 2008-2014

1.1.3 Conventions in this Manual

Notes, operation instructions and results of operation steps are marked as follows:

Notes

Important: <important note you must follow to avoid malfunction>

Note: <general note>

<note, where to find further information>

Operation Instructions

1. <instruction>
2. <instruction>

or

➢ <instruction>

Results

<result>

Safety Messages

The labeling of safety messages is explained in the chapter *Safety*.

1.1.4 Used Terminology

PC Card cifX	Communication Interfaces of the cifX family of Hilscher based on the netX technology.
CIFX 104-RE	Example for the product name for a PC card cifX Real-Time Ethernet.
CIFX 104-XX	Example (‘XX’ replaces ‘RE’, ‘DP’, ‘CO’, ‘DN’ or ‘CC’)
CIFX 104-FB\F	Example (‘FB’ replaces ‘DP’, ‘CO’, ‘DN’ or ‘CC’)

For further terminology to the PC cards cifX, its installation, configuration and operation refer to section *Glossary* on page 145.

© Hilscher, 2008-2014

1.2 Contents of the Product DVD

On the **Communication Solutions DVD** you will find these installation instructions about the software installation and the necessary configuration software, the documentation, the drivers and software for your PC card cifX, and additional auxiliary tools.

1.2.1 Installation Guide, Documentation Overview

The installation guide **Software Installation and Documentation Overview** on the Communication Solutions DVD are in the directory *Documentation\0. Installation and Overview*. The installation guide includes:

- An overview on the **Content of the Communication Solutions DVD** (in the section *What is on the Communication Solutions DVD?*)
- Overviews listing the available **Documentations** for PC cards cifX (in chapter *PC Cards cifX, Software and Documentation*).

1.2.2 What's New

All current version information for hardware and software described in this manual are provided in the folder *\Documentation\What's New - Communication Solutions DVD RL XX EN.pdf* on the Communication Solutions DVD.

1.2.3 Important Changes

1.2.3.1 DeviceNet Master - SYCON.net and Firmware

The DeviceNet Master firmware from V2.3.11.0 and the DeviceNet Master DTM from V1.360.x.x support the network scan function. If in the device a firmware version V2.3.10.0 or earlier is used then a firmware update to V2.3.11.0 or higher must be done, in order to use the **network scan** function.

© Hilscher, 2008-2014

1.2.3.2 PROFINET IO-Device Firmware Versions 3.4 and 3.5

The PROFINET IO Device firmware was revised and completed and is available in version 3.5 since the third quarter 2013.

Use the PROFINET IO Device firmware in version 3.5 for a new installation, when you create or develop your application program for the first time.

If you want to change in an existing system from the PROFINET IO Device firmware version 3.4 to the version 3.5, note the following guidelines:

1. Customize your application program according to the Migration Guide **PROFINET IO Device, Migration from V3.4 to V3.5**.

If you want to change to V3.5, please check in the Migration Guide **PROFINET IO Device, Migration from V3.4 to V3.5** which changes are necessary in the application program in order to use version 3.5.

2. Adjust the configuration of your PROFINET IO Controller device. Use the new GSDML file in the configuration software of the PROFINET IO Controller for this:
   GSDML-V2.3-HILSCHER-CIFX RE PNS-20130301.xml.
3. Update the PROFINET IO Device firmware in your device to version 3.5.

Note also:

- SYCON.net V1.360.x.x can configure the PROFINET IO Device firmware V3.4 as well as V3.5
- netX Configuration Tool V1.0510.x.x can configure the PROFINET IO Device firmware V3.4 as well as V3.5.
- The development of the PROFINET IO Device firmware V3.4 will not be continued, but this firmware version will be delivered furthermore.

On the Communication Solutions DVD, software and manuals relating to both firmware versions V3.4 and V3.5 are available:

	PROFINET IO-Device V3.4 Directory on the DVD \ File:	**PROFINET IO-Device V3.5** Directory on the DVD \ File:
Firmware	*Firmware\CIFX\cifxpns.nxf*	*Firmware\CIFX\PNS V3.5.X\cifxpns.nxf*
Header	*Examples and API\0. Header\Firmware\PROFINET IO Device V3.4.X*	*Examples and API\0. Header\Firmware\PROFINET IO Device V3.5.X*
GSDML	*EDS\PROFINET\V3.4.X\GSDML-V2.3-HILSCHER-CIFX RE PNS-20130225.xml*	*EDS\PROFINET\V3.5.X\GSDML-V2.3-HILSCHER-CIFX RE PNS-20130301.xml*
Protocol API	*Documentation\7. Programming Manuals\EN\3. Protocol API\PROFINET IO Device V3.4\PROFINET IO Device Protocol API 13 EN.pdf* *TCP IP - Packet Interface API 13 EN.pdf*	*Documentation\7. Programming Manuals\EN\3. Protocol API\PROFINET IO Device V3.5\PROFINET IO Device V3.5 Protocol API 06 EN.pdf* *PROFINET IO Device - Migration from Version 3.4 to 3.5 MG 03 EN.pdf*

Table 5: PROFINET IO-Device Firmware Version 3.4 and 3.5, Header, GSDML and Protocol API Manual

© Hilscher, 2008-2014

1.2.3.3 EtherCAT Slave Firmware Versions 2.5 and 4.2

The EtherCAT Slave firmware was revised and completed and is available in version 4.2 since the third quarter 2013.

Use the EtherCAT Slave firmware in version 4.2 for a new installation, when you create or develop your application program for the first time.

If you want to change in an existing system from the EtherCAT Slave firmware version 2.5 to the version 4.2, note the following guidelines:

1. Customize your application program according to the Migration Guide **EtherCAT Slave, Migration from V2.5 to V4.2**.

If you want to change to V4.2, please check in the Migration Guide **EtherCAT Slave, Migration from V2.5 to V4.2** which changes are necessary in the application program in order to use version 4.2.

2. Adjust the configuration of your EtherCAT Master device. Use the new XML file in the configuration software of the EtherCAT Master for this: *Hilscher CIFX RE ECS V4.2.X.xml.*
3. Update the EtherCAT Slave firmware in your device to version 4.2.

Note also:

- SYCON.net V1.360.x.x can configure the EtherCAT Slave firmware V2.5 as well as V4.2.10.0 and higher.
- netX Configuration Tool V1.0510.x.x can configure the EtherCAT Slave firmware V2.5 as well as V4.2.
- The development of the EtherCAT Slave firmware V2.5 will not be continued, but this firmware version will be delivered furthermore.

On the Communication Solutions DVD, software and manuals relating to both firmware versions V2.5 and V4.2 are available:

	EtherCAT-Slave V2.5 Directory on the DVD \ File:	**EtherCAT-Slave V4.2** Directory on the DVD \ File:
Firmware	*Firmware\CIFX\cifxecs.nxf*	*Firmware\CIFX\ECS V4.X\cifxecs.nxf*
Header	*Examples and API\0. Header\Firmware\EtherCAT Slave V2.5.X*	*Examples and API\0. Header\Firmware\EtherCAT Slave V4.2.X*
XML	*EDS\EtherCAT\Slave\V2.X\Hilscher CIFX RE ECS V2.2.X.xml*	*EDS\EtherCAT\Slave\V4.X\Hilscher CIFX RE ECS V4.2.X.xml*
Protocol API	*Documentation\7. Programming Manuals\EN\3. Protocol API\EtherCAT Slave V2\EtherCAT Slave Protocol API 21 EN.pdf*	*Documentation\7. Programming Manuals\EN\3. Protocol API\EtherCAT Slave V4\EtherCAT Slave V4 Protocol API 03 EN.pdf* *EtherCAT Slave - Migration from Version 2.5 to 4.2 MG 02 EN.pdf* *Object Dictionary V3 03 API EN.pdf*

Table 6: EtherCAT-Slave Firmware Version 2.5 and 4.2, Header, XML and Protocol API Manual

© Hilscher, 2008-2014

1.2.4 Device Description Files cifX

The Communication Solutions DVD **EDS** directory includes the device description files for the PC cards cifX. The device description file is required to configure the used Master device. The systems Open Modbus/TCP, PROFIBUS MPI and VARAN do not use device description files.

PC Cards cifX	System	File Name of the Device Description File
CIFX 104-RE CIFX 104-RE-R CIFX 104-RE\F CIFX 104-RE-R\F	EtherCAT Slave	For the EtherCAT Slave Firmware V2.5: *Hilscher cifX RE ECS V2.2.x.xml* (or with extension DDF)
		For the EtherCAT Slave Firmware with V4.2.1.0 the *Hilscher CIFX RE ECS V4.2.X.xml* is provided.
	Note! If the XML file *Hilscher cifX RE ECS V2.**2**.x.xml* is used/re-installed, the firmware must be used/re-installed at the Version *2.**5**.x*.	
	EtherNet/IP Adapter (Slave)	*HILSCHER CIFX-RE EIS V1.1.EDS*
	EtherNet/IP Scanner (Master)	*HILSCHER CIFX-RE EIM V1.0.eds*
	Note! The description files for the EtherNet/IP Master device is needed, when an additional EtherNet/IP Master device shall communicate to a Hilscher EtherNet/IP Master device via EtherNet/IP.	
	POWERLINK-Controlled-Node/Slave	*00000044_CIFX RE PLS.xdd*
	PROFINET IO-Device	For the PROFINET IO Device Firmware V3.4: *GSDML-V2.3-HILSCHER-CIFX RE PNS-20130225.xml*
		For the PROFINET IO Device Firmware with V3.5.13.1 the *GSDML-V2.3-HILSCHER-CIFX RE PNS-20130301.xml* is provided.
	sercos Slave	*Hilscher CIFX RE S3S FixCFG FSPIO Default.xml,* *Hilscher CIFX RE S3S VarCFG FSPDrive.xml*
	Note! If you use a sercos Master which is using SDDML files for configuration, and one of the defaults for vendor code, device ID, input data size or output data size was changed, then you have to export a new updated SDDML file from SYCON.net and import this SDDML file into the configuration software for the sercos Master.	

PC Cards cifX	System	File Name of the Device Description File
CIFX 104-DP CIFX 104-DP-R CIFX 104-DP\F CIFX 104-DP-R\F	PROFIBUS DP Slave	*HIL_0B69.GSD*
CIFX 104-CO CIFX 104-CO-R CIFX 104-CO\F CIFX 104-CO-R\F	CANopen-Slave	*CIFX CO COS.eds*
CIFX 104-DN CIFX 104-DN-R CIFX 104-DN\F CIFX 104-DN-R\F	DeviceNet Slave	*CIFX_DN_DNS.EDS*
CIFX 104-CC\F	CC-Link Slave	*cifx-ccs_1.csp, cifx-ccs_2.csp, cifx-ccs_3.csp, cifx-ccs_4.csp,* (for one, two, three or four Remote Device Station), cifx-ccs_io.csp (for one Remote IO Device Station)

Table 7: Device Description Files for PC Cards cifX

© Hilscher, 2008-2014

1.3 Legal Notes

1.3.1 Copyright

© Hilscher, 2008-2014, Hilscher Gesellschaft für Systemautomation mbH

All rights reserved.

The images, photographs and texts in the accompanying material (user manual, accompanying texts, documentation, etc.) are protected by German and international copyright law as well as international trade and protection provisions. You are not authorized to duplicate these in whole or in part using technical or mechanical methods (printing, photocopying or other methods), to manipulate or transfer using electronic systems without prior written consent. You are not permitted to make changes to copyright notices, markings, trademarks or ownership declarations. The included diagrams do not take the patent situation into account. The company names and product descriptions included in this document may be trademarks or brands of the respective owners and may be trademarked or patented. Any form of further use requires the explicit consent of the respective rights owner.

1.3.2 Important Notes

The user manual, accompanying texts and the documentation were created for the use of the products by qualified experts, however, errors cannot be ruled out. For this reason, no guarantee can be made and neither juristic responsibility for erroneous information nor any liability can be assumed. Descriptions, accompanying texts and documentation included in the user manual do not present a guarantee nor any information about proper use as stipulated in the contract or a warranted feature. It cannot be ruled out that the user manual, the accompanying texts and the documentation do not correspond exactly to the described features, standards or other data of the delivered product. No warranty or guarantee regarding the correctness or accuracy of the information is assumed.

We reserve the right to change our products and their specification as well as related user manuals, accompanying texts and documentation at all times and without advance notice, without obligation to report the change. Changes will be included in future manuals and do not constitute any obligations. There is no entitlement to revisions of delivered documents. The manual delivered with the product applies.

Hilscher Gesellschaft für Systemautomation mbH is not liable under any circumstances for direct, indirect, incidental or follow-on damage or loss of earnings resulting from the use of the information contained in this publication.

1.3.3 Exclusion of Liability

The software was produced and tested with utmost care by Hilscher Gesellschaft für Systemautomation mbH and is made available as is. No warranty can be assumed for the performance and flawlessness of the software for all usage conditions and cases and for the results produced when utilized by the user. Liability for any damages that may result from the use of the hardware or software or related documents, is limited to cases of intent or grossly negligent violation of significant contractual obligations. Indemnity claims for the violation of significant contractual obligations are limited to damages that are foreseeable and typical for this type of contract.

It is strictly prohibited to use the software in the following areas:

- for military purposes or in weapon systems;
- for the design, construction, maintenance or operation of nuclear facilities;
- in air traffic control systems, air traffic or air traffic communication systems;
- in life support systems;
- in systems in which failures in the software could lead to personal injury or injuries leading to death.

We inform you that the software was not developed for use in dangerous environments requiring fail-proof control mechanisms. Use of the software in such an environment occurs at your own risk. No liability is assumed for damages or losses due to unauthorized use.

1.3.4 Warranty

Although the hardware and software was developed with utmost care and tested intensively, Hilscher Gesellschaft für Systemautomation mbH does not guarantee its suitability for any purpose not confirmed in writing. It cannot be guaranteed that the hardware and software will meet your requirements, that the use of the software operates without interruption and that the software is free of errors. No guarantee is made regarding infringements, violations of patents, rights of ownership or the freedom from interference by third parties. No additional guarantees or assurances are made regarding marketability, freedom of defect of title, integration or usability for certain purposes unless they are required in accordance with the law and cannot be limited. Warranty claims are limited to the right to claim rectification.

© Hilscher, 2008-2014

1.3.5 Export Regulations

The delivered product (including the technical data) is subject to export or import laws as well as the associated regulations of different counters, in particular those of Germany and the USA. The software may not be exported to countries where this is prohibited by the United States Export Administration Act and its additional provisions. You are obligated to comply with the regulations at your personal responsibility. We wish to inform you that you may require permission from state authorities to export, re-export or import the product.

1.3.6 Registered Trademarks

Windows® XP, Windows® Vista, Windows® 7 and Windows® 8 are registered trademarks of Microsoft Corporation.

Linux is a registered trademark of Linus Torvalds.

QNX is a registered trademark of QNX Software Systems, Ltd.

VxWorks is a registered trademark of Wind River Systems, Inc.

IntervalZero RTX ™ is a trademark of IntervalZero.

Adobe-Acrobat® is a registered trademark of the Adobe Systems Incorporated.

CANopen® is a registered trademark of CAN in AUTOMATION - International Users and Manufacturers Group e.V (CiA), Nürnberg.

CC-Link is a registered trademark of Mitsubishi Electric Corporation, Tokyo, Japan.

DeviceNet™ and EtherNet/IP™ are trademarks of ODVA (Open DeviceNet Vendor Association, Inc).

EtherCAT® is a registered trademark and a patented technology of Beckhoff Automation GmbH, Verl, Germany, formerly Elektro Beckhoff GmbH.

Modbus is a registered trademark of Schneider Electric.

POWERLINK is a registered trademark of B&R, Bernecker + Rainer Industrie-Elektronik Ges.m.b.H, Eggelsberg, Austria

PROFIBUS® and PROFINET® are registered trademarks of PROFIBUS & PROFINET International (PI), Karlsruhe.

sercos and sercos interface are registered trademarks of sercos international e. V., Suessen, Germany.

PC/104™ is a trademark of the PC/104 Consortium (pc104.org).

All other mentioned trademarks are property of their respective legal owners.

© Hilscher, 2008-2014

1.3.7 EtherCAT Disclaimer

EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

To get details and restrictions regarding using the EtherCAT technology refer to the following documents:

- “EtherCAT Marking rules”
- “EtherCAT Conformance Test Policy”
- “EtherCAT Vendor ID Policy”

These documents are available at the ETG homepage www.ethercat.org or directly over info@ethercat.org.

A summary over Vendor ID, Conformance test, Membership and Network Logo can be found within the appendix section of this document under section *EtherCAT Summary over Vendor ID, Conformance test, Membership and Network Logo* on page 137.

1.3.8 Obligation to read and understand the Manual

Important!

- To avoid personal injury and to avoid property damage to your system or to your PC card, you must read and understand all instructions in the manual and all accompanying texts to your PC card, before installing and operating your PC card.
- First read the **Safety Instructions** in the safety chapter.
- Obey to all **Safety Messages** in the manual.
- Keep the product DVD providing the product manuals.

1.4 Licenses

If a PC card cifX is used as a Slave, neither for the firmware nor for the configuration software SYCON.net a license is required.

Licenses will be required if the PC card cifX is used with

- a firmware with master functionality*.

* The master license includes the PC card cifX operating as master and the license for the configuration software SYCON.net for the respective cifX.

1.4.1 License Note about VARAN Client

In order to use the PC card cifX with VARAN, you need a licence which you can acquire at the VNO (VARAN Bus-Nutzerorganisation, Bürmooser Straße 10, A-5112 Lamprechtshausen, info@varan-bus.net) after getting a member of VON.

The licence as well as the Vendor ID and the Device ID can be adjusted with the SYCON.net configuration software or with the netX Configuration Tool.

© Hilscher, 2008-2014

2 Safety

2.1 General Note

The documentation in the form of a user manual, an operating instruction manual or other manual types, as well as the accompanying texts have been created for the use of the products by educated personnel. When using the products, all Safety Messages, Safety Messages, Property Damage Messages and all valid legal regulations have to be obeyed. Technical knowledge is presumed. The user has to assure that all legal regulations are obeyed.

2.2 Intended Use

The **PC Cards cifX** described in this user manual are PC cards for the Real-Time Ethernet or fieldbus communication. Depending from the loaded firmware, the Real-Time Ethernet or fieldbus systems listed in the following table can be realized using the respective PC card cifX.

PC Cards cifX	Real-Time Ethernet System
CIFX 104-RE CIFX 104-RE-R CIFX 104-RE\F CIFX 104-RE-R\F	EtherCAT Master, EtherCAT Slave
	EtherNet/IP Scanner (Master), EtherNet/IP Scanner (Slave)
	Open-Modbus/TCP
	POWERLINK Controlled Node/Slave
	PROFINET IO-Controller (Master), PROFINET IO-Device (Slave)
	sercos Master, sercos Slave
	VARAN Client (Slave)

PC Cards cifX	Fieldbus System
CIFX 104-DP CIFX 104-DP-R CIFX 104-DP\F CIFX 104-DP-R\F	PROFIBUS DP Master, PROFIBUS DP Slave, PROFIBUS MPI Device
CIFX 104-CO CIFX 104-CO-R CIFX 104-CO\F CIFX 104-CO-R\F	CANopen Master, CANopen Slave
CIFX 104-DN CIFX 104-DN-R CIFX 104-DN\F CIFX 104-DN-R\F	DeviceNet Master, DeviceNet Slave
CIFX 104-CC\F	CC-Link slave

Table 8: PC Cards cifX and the Real-Time Ethernet or Fieldbus Systems realized thereby

The **AIFX Assembly Interfaces** are each attached to the respective basic card for the PC card cifX via a cable connector (label „\F“). Thereby the PC card cifX is equipped with a Real-Time Ethernet or fieldbus interface and in addition with a diagnostic interface.

AIFX	PC Cards cifX with AIFX Assembly Interface
AIFX-RE, AIFX-DIAG	CIFX 104-RE\F, CIFX 104-RE-R\F
AIFX-DP, AIFX-DIAG	CIFX 104-DP\F, CIFX 104-DP-R\F
AIFX-CO, AIFX-DIAG	CIFX 104-CO\F, CIFX 104-CO-R\F
AIFX-DN, AIFX-DIAG	CIFX 104-DN\F, CIFX 104-DN-R\F
AIFX-CC, AIFX-DIAG	CIFX 104-CC\F

Table 9: PC Cards cifX with AIFX Assembly Interface

© Hilscher, 2008-2014

2.3 Personnel Qualification

The PC card cifX must only be installed, configured and removed by qualified personnel. Job-specific technical skills for people professionally working with electricity must be present concerning the following topics:

- Safety and health at work
- Mounting and connecting of electrical equipment
- Measurement and Analysis of electrical functions and systems
- Evaluation of the safety of electrical systems and equipment
- Installing and Configuring IT systems

2.4 Safety Instructions to avoid Personal Injury

To ensure your own personal safety and to avoid personal injury, you necessarily must read, understand and follow the following safety instructions and safety messages in this manual about danger causing personal injury, before you install and operate your PC card cifX.

2.4.1 Electrical Shock Hazard

The danger of a lethal electrical shock caused by parts with more than 50V may occur if you open the PC cabinet to install the PC card cifX.

- HAZARDOUS VOLTAGE is present inside of the PC or of the connecting device, into which the PC card cifX is integrated. Strictly obey to all safety rules provided by the device's manufacturer in the documentation!
- First disconnect the power plug of the PC or of the connecting device, before you open the cabinet.
- Make sure, that the power supply is off at the PC or at the connecting device.
- Open the PC cabinet and install or remove the PC card cifX only after disconnecting power.

An electrical shock is the result of a current flowing through the human body. The resulting effect depends on the intensity and duration of the current and on its path through the body. Currents in the range of approximately ½ mA can cause effects in persons with good health, and indirectly cause injuries resulting from startle responses. Higher currents can cause more direct effects, such as burns, muscle spasms, or ventricular fibrillation.

In dry conditions permanent voltages up to approximately 42.4 V peak or 60 V DC are not considered as dangerous if the contact area is equivalent to the size of a human hand.

Reference Safety [S2]

© Hilscher, 2008-2014

2.5 Safety Instructions to avoid Property Damage

To avoid property damage respectively device destruction to the PC card cifX and to your system, you necessarily must read, understand and follow the following safety instructions and safety messages in this manual about danger causing property damage, before you install and operate your PC card.

2.5.1 Device Destruction by exceeding allowed Supply Voltage

To avoid device destruction due to high supply voltage to your PC card cifX, you must observe the following instructions. These instructions apply to all PC cards cifX described in this manual.

The PC card cifX may only be operated with the specified supply voltage. Make sure that the limits of the allowed range for the supply voltage are not exceeded. A supply voltage above the upper limit can cause severe damage to the PC card cifX! A supply voltage below the lower limit can cause malfunction in the PC card cifX. The allowed range for the supply voltage is defined by the tolerances specified in this manual.

The data on the mandatory supply voltage for the PC cards cifX described in this manual you find in the *Power Supply and Host* Interface on page 28. There the required and permitted supply voltage is provided by device type inclusively the permitted tolerance range.

2.5.2 Device Destruction by exceeding allowed Signaling Voltage

To avoid device destruction due to high signal voltage to your PC card cifX, you must observe the following instructions. These instructions apply to all PC cards cifX described in this manual.

- All I/O signal pins at the PC card cifX tolerate only the specified signaling voltage!
- Operation with a signaling voltage other than the specified signaling voltage may lead to severe damage to the PC card cifX!

The data on the mandatory signaling voltage for the PC cards cifX described in this manual you find in the section *Power Supply and Host Interface* on page 28. There the required and permitted signaling voltage is provided by device type.

© Hilscher, 2008-2014

2.5.3 Electrostatically sensitive Devices

This equipment is sensitive to electrostatic discharge, which cause internal damage and affect normal operation. Therefore adhere to the necessary safety precautions for components that are vulnerable with electrostatic discharge if you install or replace your device. Follow the guidelines listed hereafter when you handle this equipment:

- Touch a grounded object to discharge potential static.
- Wear an approved grounding wriststrap.
- Do not touch connectors or pins on the PC card cifX.
- Do not touch circuit components inside the equipment.
- If available, use a static-safe workstation.
- When not in use, store the equipment in appropriate static-safe packaging.

Reference Safety [S3]

© Hilscher, 2008-2014

2.6 Labeling of Safety Messages

- The **Section Safety Messages** at the beginning of a chapter are pinpointed particularly and highlighted by a signal word according to the degree of endangerment. The kind of danger is specified exactly by the safety message text and *optionally* by a specific safety sign.
- The **Integrated Safety Messages** within an instruction description are highlighted with a signal word according to the degree of endangerment. The kind of danger is specified exactly by the safety message text.

Signal Word	Meaning (international)	Meaning (USA)
DANGER	Indicates a direct hazard with high risk, which will have as consequence death or grievous bodily harm if it isn't avoided.	Indicates a Hazardous Situation Which if not Avoided, will Result in Death or Serious Injury.
WARNING	Indicates a possible hazard with medium risk, which will have as consequence death or (grievous) bodily harm if it isn't avoided.	Indicates a Hazardous Situation Which if not Avoided, could Result in Death or Serious Injury.
CAUTION	Indicates a minor hazard with medium risk, which could have as consequence simple battery if it isn't avoided.	Indicates a Hazardous Situation Which if not Avoided, may Result in Minor or Moderate Injury.

Safety Sign	USA	Sort of Warning or Principle
		Warning of Lethal Electrical Shock
		Principle: Disconnect the Power Plug

Table 10: Signal Words and Safety Signal in Safety Messages on Personal Injury

Signal Word	Meaning (international and USA)
NOTICE	Indicates a Property Damage Message.
Safety Sign	**Sort of Warning or Principle**
	Warning on Damages by Electrostatic Discharge
-	Example: Warning on Device Destruction due by too high supply voltage

Table 11: Signal Words and Safety Signal in Safety Messages on Property Damage

In this document all Safety Instructions and Safety Messages are designed according both to the international used safety conventions as well as to the ANSI Z535.6 standard, refer to reference safety [S1].

2.6.1 References Safety

[S1] ANSI Z535.6-2006 American National Standard for Product Safety Information in Product Manuals, Instructions, and Other Collateral Materials

[S2] IEC 60950-1, Information technology equipment - Safety - Part 1: General requirements, (IEC 60950-1:2005, modified); German Edition EN 60950-1:2006

[S3] EN 61340-5-1 and EN 61340-5-2 as well as IEC 61340-5-1 and IEC 61340-5-2

© Hilscher, 2008-2014

3 Descriptions and Requirements

3.1 Description

The PC cards cifX are communication interfaces of the cifX product family of Hilscher on the basis of the communication controller netX 100 for the Real-Time Ethernet or fieldbus communication. Depending of the loaded firmware, the protocol specific PC card cifX proceeds the communication of the corresponding Real-Time Ethernet or fieldbus system.

The used Real-Time Ethernet systems are:

- EtherCAT Master
- EtherCAT Slave
- EtherNet/IP Scanner (Master)
- EtherNet/IP Adapter (Slave)
- Open-Modbus/TCP
- POWERLINK-Controlled-Node/Slave
- PROFINET IO-Controller (Master)
- PROFINET IO-Device (Slave)
- sercos Master
- sercos Slave
- VARAN Client (Slave)

The used fieldbus systems are:

- PROFIBUS DP Master
- PROFIBUS DP Slave
- PROFIBUS MPI Device
- CANopen Master
- CANopen Slave
- DeviceNet Master
- DeviceNet Slave
- CC-Link Slave

The PC card cifX handles the complete data exchange between the connected Ethernet or fieldbus devices and the PC. The data exchange is proceeded via dual-port memory.

© Hilscher, 2008-2014

3.2 PC Cards cifX with integrated Interfaces

The PC cards PC/104 CIFX 104-XX and CIFX 104-XX-R provide integrated Ethernet, fieldbus or diagnostic interfaces.

3.2.1 PC Cards PC/104: CIFX 104-XX, CIFX 104-XX-R

PC Card cifX	Description
PC Cards PCI-104 with integrated Ethernet, fieldbus or diagnostic interface	
Real-Time Ethernet	
CIFX 104-RE	Real-Time Ethernet Master or Slave
CIFX 104-RE-R	Real-Time Ethernet Master or Slave (connectors at the left side)
PROFIBUS	
CIFX 104-DP	PROFIBUS DP Master or Slave and PROFIBUS MPI Device
CIFX 104-DP-R	PROFIBUS DP Master or Slave and PROFIBUS MPI Device (connectors at the left side)
CANopen	
CIFX 104-CO	CANopen Master or Slave
CIFX 104-CO-R	CANopen Master or Slave (connectors at the left side)
DeviceNet	
CIFX 104-DN	DeviceNet Master or Slave
CIFX 104-DN-R	DeviceNet Master or Slave (connectors at the left side)

Table 12: PC Cards PC/104: CIFX 104-XX and CIFX 104-XX-R

3.3 PC Cards cifX with AIFX Assembly Interfaces

3.3.1 The Label „\F“ in the Device Name

The PC cards cifX including the label “**\F**” in its device name are composed of a basic card and an assembly interface AIFX.

- The basic cards CIFX 104-RE\F and CIFX 104-RE-R\F are equipped with a **Cable Connector Ethernet**, to connect the Ethernet assembly interface (AIFX-RE).
- The basic cards CIFX 104-FB\F and CIFX 104-FB-R\F are equipped with a **Cable Connector Fieldbus**, to connect the PROFIBUS assembly interface (AIFX-DP), CANopen (AIFX-CO), DeviceNet (AIFX-DN) or CC-Link (AIFX-CC*), (*only for CIFX 104-FB\F; Note: ‘FB’ stands for ‚Fieldbus’.)
- The basic cards CIFX 104-RE\F, CIFX 104-RE-R\F, CIFX 104-FB\F and CIFX 104-FB-R\F are additionally equipped with a **Cable Connector DIAG**, to optionally connect the diagnostic assembly interface (AIFX-DIAG).

Important! Operating the PC cards cifX PC/104 with AIFX assembly interface (label “**\F**” in the device name) requires proper connection of the Ethernet (AIFX-RE), PROFIBUS (AIFX-DP), CANopen (AIFX-CO), DeviceNet (AIFX-DN) or CC-Link (AIFX-CC) assembly interface to the basic card!

© Hilscher, 2008-2014

3.3.2 PC Cards PC/104: CIFX 104-XX\F, CIFX 104-XX-R\F

PC Card cifX	Description
PC Cards PC/104 with AIFX Assembly Interfaces	
Real-Time Ethernet	
CIFX 104-RE\F	**Real-Time Ethernet Master or Slave** - Basic card CIFX 104-RE\F and - Ethernet assembly interface (AIFX-RE).
CIFX 104-RE-R\F	**Real-Time Ethernet Master or Slave** (connectors at the left side) - Basic card CIFX 104-RE-R\F and - Ethernet assembly interface (AIFX-RE).
PROFIBUS	
CIFX 104-DP\F	**PROFIBUS DP Master or Slave or PROFIBUS MPI Device** - Basic card CIFX 104-FB\F and - PROFIBUS assembly interface (AIFX-DP).
CIFX 104-DP-R\F	**PROFIBUS DP Master or Slave or PROFIBUS MPI Device** (connectors at the left side) - Basic card CIFX 104-FB-R\F and - PROFIBUS assembly interface (AIFX-DP).
CANopen	
CIFX 104-CO\F	**CANopen Master or Slave** - Basic card CIFX 104-FB\F and - CANopen assembly interface (AIFX-CO).
CIFX 104-CO-R\F	**CANopen Master or Slave** (connectors at the left side) - Basic card CIFX 104-FB-R\F and - CANopen assembly interface (AIFX-CO).
DeviceNet	
CIFX 104-DN\F	**DeviceNet Master or Slave** - Basic card CIFX 104-FB\F and - DeviceNet assembly interface (AIFX-DN).
CIFX 104-DN-R\F	**DeviceNet Master or Slave** (connectors at the left side) - Basic card CIFX 104-FB-R\F and - DeviceNet assembly interface (AIFX-DN).
CC-Link	
CIFX 104-CC\F	**CC-Link Slave** - Basic card CIFX 104-FB\F and - CC-Link assembly interface (AIFX-CC).

Table 13: PC Cards PC/104: CIFX 104-XX\F, CIFX 104-XX-R\F

3.3.3 AIFX Assembly Interfaces

AIFX	Description	For the PC Cards cifX
AIFX-RE	Ethernet Assembly Interface (with Ethernet interface)	CIFX 104-RE\F, CIFX 104-RE-R\F
AIFX-DP	PROFIBUS Assembly Interface (with PROFIBUS interface)	CIFX 104-DP\F, CIFX 104-DP-R\F
AIFX-CO	CANopen Assembly Interface (with CANopen interface)	CIFX 104-CO\F, CIFX 104-CO-R\F
AIFX-DN	DeviceNet Assembly Interface (with DeviceNet interface)	CIFX 104-DN\F, CIFX 104-DN-R\F
AIFX-CC	CC-Link Assembly Interface (with CC-Link interface)	CIFX 104-CC\F
AIFX-DIAG (optional)	Diagnostic Assembly Interface (with diagnostic interface)	CIFX 104-RE\F, CIFX 104-RE-R\F CIFX 104-DP\F, CIFX 104-DP-R\F, CIFX 104-CO\F, CIFX 104-CO-R\F, CIFX 104-DN\F, CIFX 104-DN-R\F, CIFX 104-CC\F

Table 14: AIFX Assembly Interfaces for PC Cards cifX with Cable Connector

© Hilscher, 2008-2014

3.4 System Requirements

3.4.1 Slot for the PC Cards cifX PC/104

PC with slot (5 V) for PC cards cifX *PC/104*:

PC Cards cifX		Bus [Pins]	Slot
CIFX 104-RE CIFX 104-RE-R CIFX 104-RE\F CIFX 104-RE-R\F CIFX 104-DP CIFX 104-DP-R CIFX 104-DP\F CIFX 104-DP-R\F	CIFX 104-CO CIFX 104-CO-R CIFX 104-CO\F CIFX 104-CO-R\F CIFX 104-DN CIFX 104-DN-R CIFX 104-DN\F CIFX 104-DN-R\F CIFX 104-CC\F	104	**PC/104 Slot** (5 V)

Table 15: Slot for the PC Cards cifX PC/104

3.4.2 Power Supply and Host Interface

For the power supply and the host interface used for the PC cards cifX *PC/104* you must observe the following requirements:

PC Cards cifX		Supply Voltage	Signaling Voltage Host Interface	Host Interface (PCI slot)
CIFX 104-RE CIFX 104-RE-R CIFX 104-RE\F CIFX 104-RE-R\F CIFX 104-DP CIFX 104-DP-R CIFX 104-DP\F CIFX 104-DP-R\F	CIFX 104-CO CIFX 104-CO-R CIFX 104-CO\F CIFX 104-CO-R\F CIFX 104-DN CIFX 104-DN-R CIFX 104-DN\F CIFX 104-DN-R\F CIFX 104-CC\F	+5 V dc ±5 %/ Typ. 500 mA	5 V Input compatible, 5 V TTL Output compatible (Uout ≥ 2,4 V @6 mA)	PC/104

Table 16: Requirements Power Supply and Host Interface for PC Cards cifX PC/104

The data in the *Table 16* above have the following meaning:

Supply Voltage
The required and permissible supply voltage at the PC cards cifX *PC/104*

Signaling Voltage Host Interface
The required or tolerated signaling voltage at the I/O signal pins at the PC/104 bus of the PC cards cifX *PC/104*

Host Interface (PCI slot) Type of the host interface

3.4.3 Panel Cutout for Installing AIFX

In order to connect the AIFX assembly interface to a PC card cifX **PC/104** with cable connector Ethernet or fieldbus (labeling „\F“), make sure that **the front plate of the PC cabinet** has an appropriate cutout and holes for fastening the AIFX.

PC Card cifX	Panel Cutout
PC/104	at the front plate of the PC cabinet

Table 17: Panel Cutout at the at the front plate of the PC cabinet

© Hilscher, 2008-2014

The panel cutout must be dimensioned sufficiently large for the interface, display or control elements placed on the AIFX. Partial standard cutouts can be used.

PC Cards cifX	AIFX	Panel Cutout and Holes	
CIFX 104-RE\F CIFX 104-RE-R\F	AIFX-RE	Required Cutout	for two RJ45 Sockets **Important!** The panel cutout layout must also cover the LEDs COM 0 and COM1 at the AIFX-RE.
		Standard cutout	D-Sub-15
		Holes	2, distance between the holes 37,3 mm
		Further Information	In the data sheet *MOD JACK – MJIM* [2], as well as in section *Ethernet - AIFX-RE* on page 49.
CIFX 104-DP\F CIFX 104-DP-R\F	AIFX-DP	Required Cutout	for Dsub female Connector, 9 pin
		Standard cutout	D-Sub-9
		Holes	2, distance between the holes 25 mm
		Further Information	in section *PROFIBUS - AIFX-DP* on page 50.
CIFX 104-CO\F CIFX 104-CO-R\F	AIFX-CO	Required Cutout	for D-Sub male Connector, 9 pin
		Standard cutout	D-Sub-9
		Holes	2, distance between the holes 25 mm
		Further Information	in section *CANopen - AIFX-CO* on page 51.
CIFX 104-DN\F CIFX 104-DN-R\F	AIFX-DN	Required Cutout	for CombiCon male Connector, 5 pin
		Standard cutout	D-Sub-9
		Holes	2x2, distance between the holes 24,94 mm
		Further Information	in section *DeviceNet - AIFX-DN* on page 52.
CIFX 104-CC\F	AIFX-CC	Required Cutout	for CombiCon male Connector, 5 pin
		Standard cutout	CombiCon male Connector
		Holes	2x2, distance between the holes 24,96 mm
		Further Information	in section *CC-Link - AIFX-CC* on page 53.
CIFX 104-RE\F CIFX 104-RE-R\F CIFX 104-DP\F CIFX 104-DP-R\F CIFX 104-CO\F CIFX 104-CO-R\F CIFX 104-DN\F CIFX 104-DN-R\F	AIFX-DIAG	Required Cutout	for the light channels, the rotary switch and the Mini B USB plug
		Standard cutout	-
		Holes	2, distance between the holes 47,1 mm
		Further Information	in section *Diagnostic - AIFX-DIAG* on page 54.

Table 18: Required Panel Cutout and Holes for AIFX

3.4.4 System Requirements cifX PC/104 (ISA)

Note: To operate a **PC Card cifX PC/104 (ISA)** in a PC, the PC has to provide a free ISA memory area of 16 Kbyte in the memory range C0000 to FBFFF. If the PC card cifX should be operated with interrupt, then the PC must provide additionally a free ISA interrupt.

© Hilscher, 2008-2014

3.5 Requirements for Operation of the PC Cards cifX

Operating the PC cards cifX properly, the following described requirements must be fulfilled.

Protocols	EtherCAT Slave, EtherCAT Master, EtherNet/IP Adapter (Slave), EtherNet/IP Scanner (Master), Open-Modbus/TCP, POWERLINK-Controlled-Node/Slave, PROFINET IO Device (Slave), PROFINET IO Controller (Master)	sercos Slave, sercos Master, VARAN Client (Slave)	PROFIBUS DP Slave, PROFIBUS DP Master, PROFIBUS MPI Device, CANopen Slave, CANopen Master, DeviceNet Slave, DeviceNet Master, CC-Link Slave
Software Installation	1. Driver for the Host Interface Host Interfaces: PC/104 • The device driver **cifX Device Driver** must be installed (from V1.0.x.x). If you install the device into a PC, in general Windows® will be available as operating system. In this case the cifX Device Driver must be installed to communicate to the device and to exchange data via the dual-port memory,. **Important!** Upgrade older versions of the **cifX Device Driver** necessarily on the current version indicated in section *Driver and Software* on page 9. OR • If Windows® is not available as operating system, an own driver must be developed using the cifX Driver Toolkit and this driver must be installed. • For the operating systems Linux, Windows® CE, VxWorks, QNX and IntervalZero RTX ™ you can buy Device Driver at the company Hilscher Gesellschaft für Systemautomation mbH http://www.hilscher.com/. 2. The configuration software **SYCON.net** or alternatively the simple Slave configuration tool **netX Configuration Tool** must be installed or another application program by which the PC card cifX (Slave) can be parameterized.		
How to use the Software	On how to use the software for the configuration, the firmware download and for the diagnosis, note the following notice: **Important!** The USB interface, the serial interface as well as the cifX Device Driver may only be used exclusively by **one** software, that is - the **SYCON.net** configuration software (with integrated ODMV3) or - the **netX Configuration Tool** or - the **cifX Test Application** or - the **cifX Driver Setup Utility** or - the application program. Never use the listed software simultaneously, otherwise this will result in communication problems with the device. If the SYCON.net configuration software was used on the PC, then stop the ODMV3 service before you use one of the other software listed above. Therefore, select **Service > Stop** from the context menu of the ODMV3 system tray icon.		
Firmware Download	3. Using the configuration software **SYCON.net** or for the Slave alternatively the Slave configuration tool **netX Configuration Tool**, the user must select and download the firmware to the PC card cifX.		
Parameter Setting	4. The PC card cifX must be parameterized using one of the following options: • Configuration Software **SYCON.net** • alternatively Slave configuration tool **netX Configuration Tool** (only Slave) • Application program (programming required)		
Communication	5. For the communication of a PC card cifX (Slave) a Master device for the respective communication system is required. For the communication of a PC card cifX (Master) a Slave device for the respective communication system is required.		
Hardware Installation	**Important!** Operating the PC cards cifX with **Cable Connector Ethernet** or with the **Cable Connector Fieldbus** (label "**\F**" in its device name) requires proper connection of the Ethernet (AIFX-RE), PROFIBUS (AIFX-DP), CANopen (AIFX-CO), DeviceNet (AIFX-DN) or CC-Link (AIFX-CC) assembly interface to the basic card!		
Environmental Conditions	Due to a plug element from ERNI the lower limit of the operating temperature for all PC cards cifX Real-Time Ethernet is 0 °C. This applies to all hardware revisions of the PC card cifX Real-Time Ethernet.		

Table 19: Requirements to operate PC Cards cifX properly

© Hilscher, 2008-2014

4 Getting Started

4.1 Installation and Configuration PC Card cifX PC/104

The following table describes the steps for the software and hardware installation and for the configuration of a PC card cifX PC/104 (Master and Slave) Real-Time Ethernet and fieldbus as it is typical for many cases. The Slave device can be configured using the corresponding Slave DTM in the configuration software **SYCON.net**. Alternatively, you can also use the simple Slave configuration tool **netX Configuration Tool**. The Master device can be configured using the corresponding Master DTM in the configuration software **SYCON.net**.

#	Step	Description	For detailed information see manual / section	Page
1	**Installing Driver and Software**			
1.1	Installing **cifX Device Driver**	Enter the Communication Solutions DVD in the PC and follow to the instructions of the installation wizard, to install the driver.	*Refer to User Manual Software Installation for the PC Cards cifX*	
1.2	**Installing USB Driver** Depending by device type / features	Only for PC Cards cifX PC/104: equipped with an USB interface or with the diagnostic assembly interface (AIFX-DIAG).		
1.3	Reserve **Memory Range / Interrupt** at the operating system.	Reserve for the PC card cifX the memory range and if necessary one interrupt at the operating system.		
1.4	Installing SYCON.net	For PC Cards cifX Master or Slave: Run the SYCON.net-Setup and follow to the instructions of the installation wizard.		
1.5	Installing **netX Configuration Tool**	For PC Cards cifX Slave: Start the **netX Configuration Tool setup** program to install the **netX Configuration Tool**.		
2	**Preparing Hardware Installation**			
2.1	Take precautions on Electrostatically sensitive Devices	**NOTICE** **Electrostatically sensitive Devices** Make sure, that the PC card cifX is grounded via the endplate and the PC and make sure, that you are discharged when you install/ uninstall the PC Card cifX.	*Electrostatically sensitive Devices*	*23*
2.2	Set **Starting Address** and **Interrupt**		*cifX PC/104: Set Starting Address and Interrupt*	57
2.3	Set **Data Bus Width**.	Depending by the target system (motherboard) if so, set a **Data Bus Width** of 8 bit or 16 bit. (Default jumper setting 16 Bit)	*Device Drawings*	*38*
3	**Hardware Installation**	Installing cifX. Take required safety precautions.	*Hardware Installation and Uninstalling*	55
3.1	Take safety precautions	**WARNING** **Lethal Electrical Shock caused by parts with more than 50V!** Disconnect the power plug of the PC or of the connecting device. Make sure, that the power supply is off at the PC or at the connecting device.	*Electrical Shock Hazard*	21

© Hilscher, 2008-2014

#	Step	Description	For detailed information see manual / section	Page
3.2	Open cabinet	Now open the cabinet of the PC or of the connecting device.	*Installing PC Cards cifX PC/104*	59
3.3	Installing cifX	Plug in and mount the PC card cifX.		
3.4	If so, plug module	(a) Install the first PC/104 module on the mainboard. (b) Install any other PC/104 module on the respective underlying PC/104 module.		
3.5	Connect AIFX (only for PC Cards cifX PC/104 with label "\F" in its device name and with Cable Connector Ethernet X4 or Fieldbus X3)	**Important!** Operating the PC cards cifX with AIFX assembly interface requires proper connection of the AIFX-RE, AIFX-DP, AIFX-CO, AIFX-DN or AIFX-CC assembly interface to the basic card! If so, connect an Ethernet (AIFX-RE), PROFIBUS (AIFX-DP), CANopen (AIFX-CO), DeviceNet (AIFX-DN) or CC-Link (AIFX-CC) assembly interface. If so, additionally connect an diagnostic assembly interface (AIFX-DIAG).	*The Label „\F" in the Device Name*	26
		To the basic card of each PC card cifX first connect the AIFX-RE, AIFX-DP, AIFX-CO, AIFX-DN, AIFX-CC or AIFX-DIAG assembly interface to the PC card cifX and check if the connector is plugged in correctly. Only then plug another PC/104 module.		
3.6	Close cabinet	Close the cabinet of the PC or connecting device.		
3.7	Plug the connecting cable to the Master or Slave	Note for all PC Cards cifX Real-Time Ethernet: **Note!** The RJ45 socket is only for use in LAN, not for telecommunication circuits.	*Ethernet Interface*	87
		Note for PC Cards cifX PROFINET IO Controller: **Important for Hardware Wiring!** Connect only ports with each other, which have different cross-over settings. Otherwise a connection between the devices can not be established. If the port settings of the PC card cifX PROFINET IO controller are not set to AUTO, then Port0 is switched uncrossed and Port1 crossed. Plug in the connecting cable from the PC card cifX to the PC card Master or Slave.	*See corresponding user manual*	
3.8	Connect the PC to the power / switch on.	Connect the PC or the connecting device to the power supply and switch it on.		
4	**Notice on how to use the Software**	Use only **one** Software.		
4.1	For the configuration, the firmware download and for the diagnosis, note:	**Important!** To avoid communication problems with the device, use the USB interface, the serial interface as well as the cifX Device Driver exclusively with **one** software, that is **SYCON.net** or **netX Configuration Tool**.	*Requirements for Operation of the PC Cards cifX*	*30*

© Hilscher, 2008-2014

#	Step	Description	For detailed information see manual / section	Page
5	**Configuring Slave using SYCON.net**	**Download Firmware and Configuration** Use the corresponding Slave DTM in the configuration software **SYCON.net**.		
5.1	Firmware Download	- Start configuration software **SYCON.net**, - Create new project /Open existing project, - Insert Slave into configuration, - Select driver and assign device. - Select and download the firmware.	*See corresponding user manual* *Device Names in SYCON.net*	36
	Firmware Slave:	EtherCAT Slave, EtherNet/IP Adapter, Open-Modbus/TCP, POWERLINK-Controlled-Node/Slave, PROFINET IO Device, sercos Slave, VARAN Client, PROFIBUS DP Slave, PROFIBUS MPI Device, CANopen Slave, DeviceNet Slave, CC-Link Slave		
5.2	Configuration cifX (Slave)	-Configure the PC card cifX (Slave).		
5.3	Download Configuration	- Download the configuration to the PC card cifX (Slave)		
6	OR **Configuring Slave using netX Configuration Tool**	**Download Firmware and Configuration**		
6.1	Downloading Firmware and Configuration (Slave)	If SYCON.net was already used on the PC, stop the ODMV3 service. Therefore, select **Service > Stop** from the context menu of the ODMV3 system tray icon. 	*Requirements for Operation of the PC Cards cifX*	*30*
		The ODMV3 system tray icon changes to **ODMV3 Service stopped**.  In the **netX Configuration Tool**: - select the Firmware protocol, - Set the PC card cifX (Slave) parameters. - Select **Apply**. The selected firmware and the configuration are downloaded to the replacement card cifX. The configuration is saved to the hard disk of the PC.	*See Operating Instruction Manual netX Configuration Tool for cifX, comX and netJACK*	
7	**Configuring Master using SYCON.net**	**Download Firmware and Configuration** Use the corresponding Master DTM in the configuration software **SYCON.net**.		
7.1	Firmware Download	- Start configuration software **SYCON.net**, - Create new project /Open existing project, - Insert Master into configuration, - Select driver and assign device. - Select and download the firmware.	*See corresponding user manual* *Device Names in SYCON.net*	36
	Firmware Master:	EtherCAT Master, EtherNet/IP Scanner, PROFINET IO Controller, PROFIBUS DP Master, CANopen Master, DeviceNet Master		
7.2	Configuration cifX (Master)	- Configure the PC card cifX (Master).	*Notes for the Configuration of the*	*35*

© Hilscher, 2008-2014

#	Step	Description	For detailed information see manual / section	Page
7.3	Download Configuration	- Download the configuration to the PC card cifX (Master).	*Master Device*	
8	**Diagnosis by SYCON.net** (Slave and Master)	**Diagnosis, I/O Data** Use the corresponding Slave or Master DTM in the configuration software **SYCON.net**.		
8.1	Diagnosis Steps (Master and Slave)	- In netDevice rightclick on device symbol. - Select context menu entry **Diagnosis**, - then select **Diagnosis > General** or **Firmware Diagnosis**, - or select **Diagnosis > Extended Diagnosis**.	*See corresponding user manual*	
8.2	I/O Monitor	- In netDevice rightclick on device symbol. - Select context menu entry **Diagnosis**, - then **Tools > IO Monitor**. -Check the input or output data.		
9	OR **Slave Diagnosis by netX Configuration Tool** (only Slave)	**Diagnosis**		
9.1	Diagnosis Steps (Slave)	If SYCON.net was already used on the PC, stop the ODMV3 service. Therefore, select **Service > Stop** from the context menu of the ODMV3 system tray icon. In the **netX Configuration Tool**: - In the navigation area click on **Diagnostic**, - click in the **Diagnostic** pane to **Start**, to start the communication to the Master device and to run the diagnosis. - click on **Extended**, to run the extended diagnosis.	*See Operating Instruction Manual netX Configuration Tool for cifX, comX and netJACK*	

Table 20: Steps for the Software and Hardware Installation, the Configuration and for the Diagnosis of a PC Card cifX PC/104 (Master and Slave)

© Hilscher, 2008-2014

4.2 Note on Exchange Service (Replacement Case)

For the exchange service (replacement case) of a PC card cifX (Master and Slave) obey to the following note.

Important! For PC cards cifX in terms of a device exchange service (replacement case) you must manually download the same firmware and configuration into the replacement card cifX, as into the preceding cifX.

4.3 Notes for the Configuration of the Master Device

To configure the Master, a device description file is required. Please note the following notes for the configuration of the Master Device:

System	Note
EtherCAT Slave	To configure the Master, an XML file (device description file) is required. The settings in the used Master must comply with the settings in the Slave to establish communication. Important parameters are: Vendor ID, Product Code, Serial Number, Revision Number, Output and Input Data Bytes.
	If the XML file *Hilscher cifX RE ECS V2.**2**.x.xml* is use/updated, the firmware with the version *2.**2**.x* must be use/updated.
	The loadable firmware supports for the number of cyclic input data and for cyclic output data in total up to 400 bytes. If more than 200 bytes for input data or for output data should be exchanged via EtharCAT, then a customer specific XML file is necessary. Additionally the following formular applies: (number of input bytes + 3)/4 + (number of output bytes + 3)/4 must be less or equal to 100.
EtherNet/IP Adapter	To configure the Scanner/Master, an EDS file (device description file) is required. The settings in the used Scanner/Master must comply with the settings in the Adapter/Slave to establish communication. Important parameters are: Input, Output Data Bytes, Vendor ID, Product Type, Product Code, Major Rev, Minor Rev, IP Address and Netmask.
POWERLINK-Controlled-Node/Slave	To configure the Managing Node/Master, an XDD file (device description file) is required. The settings in the used Managing Node/Master must comply with the settings in the Controlled Node/Slave, to establish communication. Important parameters are: Vendor ID, Product Code, Serial Number, Revision Number, Node ID, Output and Input length.
PROFINET IO Device	To configure the Controller, a GSDML file (device description file) is required. The settings in the used Controller must comply with the settings in the Device to establish communication. Important parameters are: Station Name, Vendor ID, Device ID, Input and Output Data Bytes. Under Name of Station, the name must be typed which was also used in the configuration file of the master of this device. If no name chosen freely is used in the configuration file, then the name from the GSDML file is used.
sercos Slave	The sercos Master uses the sercos address to communicate with the slave. Some Masters will verify Device ID, Vendor Code, Input Data Size and Output Data Size and will do further communication to the Slave only if all these values match. Therefor the Master reads these parameters from the Slave and compares them with the configuration stored in the Master. The parameters Device ID, Vendor Code, Input Data Size and Output Data Size are part of the SDDML device description file. If for the configuration of the sercos Master SDDML files are used and a default value of one of these parameters was changed, then a SDDML file must be created in the configuration software via Export SDDML and then used in the configuration of the sercos Master.
PROFIBUS DP Slave	To configure the Master, a GSD file (device description file) is required. The settings in the used Master must comply with the settings in the Slave to establish communication. Important parameters are: Station Address, Ident Number, Baudrate and Config Data (the configuration data for the output and input length).
CANopen Slave	To configure the Master, an EDS file (device description file) is required. The settings in the used Master must comply with the settings in the Slave to establish communication. Important parameters are: Node Address and Baudrate.
DeviceNet Slave	To configure the Master, an EDS file (device description file) is required. The settings in the used Master must comply with the settings in the Slave to establish communication. Important parameters are: MAC ID, Baudrate, Produced Size, Consumed Size, Vendor ID, Product Type, Product Code, Major Rev, Minor Rev.

© Hilscher, 2008-2014

System	Note
CC-Link Slave	To configure the Master, a CSP file (device description file) is required. The settings in the used Master must comply with the settings in the Slave to establish communication. Important parameters are: Slave Station Address, Baudrate, Station Type and Vendor Code.

Table 21: Notes for the Configuration of the Master Device

Further information to the device description files you find under section on *Device Description Files cifX* page 15.

4.4 Device Names in SYCON.net

The following table contains the device names displayed for the single communication protocols in the configuration software SYCON.net.

The table shows the PC card cifX and which protocol can be used. Furthermore, the table shows, for which protocol which device must be selected from the device catalog to configure the PC card cifX with SYCON.net.

PC Cards cifX	Protocol	DTM Specific Group	Device Name in SYCON.net
CIFX 104-RE, CIFX 104-RE-R CIFX 104-RE\F CIFX 104-RE-R\F	EtherCAT Master	Master	CIFX RE/ECM
	EtherCAT Slave	Gateway/Stand-Alone Slave	CIFX RE/ECS
	EtherNet/IP Scanner (Master)	Master	CIFX RE/EIM
	EtherNet/IP Adapter (Slave)	Gateway/Stand-Alone Slave	CIFX RE/EIS
	Open-Modbus/TCP	Gateway/Stand-Alone Slave	CIFX RE/OMB
	POWERLINK-Controlled-Node/Slave	Gateway/Stand-Alone Slave	CIFX RE/PLS
	PROFINET IO-Controller	Master	CIFX RE/PNM
	PROFINET IO-Device	Gateway/Stand-Alone Slave	CIFX RE/PNS
	sercos Master	Master	CIFX RE/S3M
	sercos Slave	Gateway/Stand-Alone Slave	CIFX RE/S3S
	VARAN Client (Slave)	Gateway/Stand-Alone Slave	CIFX RE/VRS
CIFX 104-DP CIFX 104-DP-R CIFX 104-DP\F CIFX 104-DP-R\F	PROFIBUS DP Master	Master	CIFX DP/DPM
	PROFIBUS DP Slave	Gateway/ Stand-Alone Slave	CIFX DP/DPS
	PROFIBUS MPI Device	Gateway/ Stand-Alone Slave	CIFX DP/MPI
CIFX 104-CO CIFX 104-CO-R CIFX 104-CO\F CIFX 104-CO-R\F	CANopen Master	Master	CIFX CO/COM
	CANopen Slave	Gateway/ Stand-Alone Slave	CIFX CO/COS
CIFX 104-DN CIFX 104-DN-R CIFX 104-DN\F CIFX 104-DN-R\F	DeviceNet Master	Master	CIFX DN/DNM
	DeviceNet Slave	Gateway/ Stand-Alone Slave	CIFX DN/DNS
CIFX 104-CC\F	CC-Link Slave	Gateway/ Stand-Alone Slave	CIFX CC/ CCS

Table 22: Device Names in SYCON.net by Communication Protocol

© Hilscher, 2008-2014

4.5 Update for Firmware, Driver and Software

Note: As a pre-requirement for the software update the project files, the configuration files and firmware files are to be saved.

At existing hardware installation the firmware, the driver and the configuration software must be updated according to the versions given in section *Notes on Hardware, Firmware, Software and Driver* on page 9. The following graphic gives an overview:


System Overview on „Which Software Elements must be actualized?“
PC
Step 4
If necessary, import new Device Description Files to SYCON.net.
Step 3
Actualize Configuration Software.
Configuration Software, to parameterize Slave(s) or to configure Master:
• SYCON.net (Master or Slave),
• netX Configuration Tool (only Slave) or
• another Application Program (Master or Slave).
Step 1
Actualize cifX Device Driver.
cifX Device Driver
Dual-Port Memory
CIFX
Step 2
Actualize Firmware.
Real-Time-Ethernet or Fieldbus Protocol (Master or Slave)
Slave(s) or Master

Figure 1: System Overview cifX to update Firmware, Driver and Software

Note the specific details for devices with **PC/104 bus** in section *Firmware* on page 10.

© Hilscher, 2008-2014

5 Device Drawings

5.1 PC-Karten cifX PC/104

5.1.1 CIFX 104-RE


System LED (gelb/grün) / (yellow/green)
Kommunikationsstatus-LED 0 und 1 (rot/grün) /
Communication Status LED 0 and 1 (red/green)
SYNC-Anschluss / SYNC Connector
(X51, 3-polig / 3 pin)
Steckbrücke Datenbusbreite 8 Bit und 16 Bit
(J9, im Bild Einstellung Steckbrücke für 16 Bit)
Data Bus Width Jumpers 8 Bit and 16 Bit
(J9, Jumper Settings for 16 Bit shown)
COM 1
COM 0
SYS
CIFX104-RE
Hilscher
made in Germany
Ethernet RJ45-Buchse / RJ45 Socket
(X6)
Pin 1: TX+
Pin 2: TX-
Pin 3: RX+
Pin 4: Term 1
Pin 5: Term 1
Pin 6: RX-
Pin 7: Term 2
Pin 8: Term 2
Kanal 0 /
Channel 0 (CH 0)
Kanal 1 /
Channel 1 (CH 1)
LED
grün / green
LED
gelb / yellow
Mini-B-USB-Buchse / Mini B USB Plug
(X5, 5-polig / 5 pin)
Drehschalter Geräteadresse /
Rotary Switch Device Address
(ohne Funktion / without function)
PC/104 Bus
(X1, 64-polig / 64 pin)
(X2, 40-polig / 40 pin)
Interrupt-Steckbrücke / Interrupt Jumper
(J8, 11-polig / 11 pin)
Adressteckbrücke / Address Jumpers
(J7, 7-polig / 7 pin)
Standardeinstellungen Steckbrücken / Default Jumper Settings

*Figure 2: CIFX 104-RE**

Note:

- *Device supports **Auto Crossover** Function.
- With loaded **EtherCAT Master** firmware only the RJ45 channel 0 can be used, channel 1 is deactivated. Beginning with the EtherCAT Master firmware version 3 channel 1 can be reactivated if redundancy is activated.
- For **Open Modbus/TCP** with V2.3.4.0 and higher both Rj45channels can be used.
- In **Interrupt Mode** (IRQ = Interrupt Request) exactly one jumper must be set. If no jumper is set, the PC card cifX works in **Polling Mode**. For further details refer to *Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory* on page 57.

- The meaning of the **LEDs** depends from the loaded firmware. See chapter *LED Descriptions* beginning from page 64.
- For the pin assignment of the **PCI/104** bus X1/X2 refer to section *Pin Assignment for PC/104 Bus* on page 96.
- For the pin assignment of the **SYNC** Connector refer to section *Pin Assignment SYNC Connector, X51* on page 94.
- For further information on the **Mini-B USB** Connector refer to section *Mini-B USB Connector (5 Pin)* on page 91.

© Hilscher, 2008-2014

5.1.2 CIFX 104-RE-R



*Figure 3: CIFX 104-RE-R**

Note:

- *Device supports **Auto Crossover** Function.
- With loaded **EtherCAT Master** firmware only the RJ45 channel 0 can be used, channel 1 is deactivated. Beginning with the EtherCAT Master firmware version 3 channel 1 can be reactivated if redundancy is activated.
- For **Open Modbus/TCP** with V2.3.4.0 and higher both Rj45channels can be used.
- In **Interrupt Mode** (IRQ = Interrupt Request) exactly one jumper must be set. If no jumper is set, the PC card cifX works in **Polling Mode**. For further details refer to *Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory* on page 57.

- The meaning of the **LEDs** depends from the loaded firmware. See chapter *LED Descriptions* beginning from page 64.
- For the pin assignment of the **PCI/104** bus X1/X2 refer to section *Pin Assignment for PC/104 Bus* on page 96.
- For the pin assignment of the **SYNC** Connector refer to section *Pin Assignment SYNC Connector, X51* on page 94.
- For further information on the **Mini-B USB** Connector refer to section *Mini-B USB Connector (5 Pin)* on page 91.

© Hilscher, 2008-2014

5.1.3 CIFX 104-RE\F


SYNC-Anschluss / SYNC Connector
(X51, 3-polig / 3 pin)
System-LED
(gelb/grün) /
(yellow/green)
CIFX104-RE
Hilscher
made in Germany
Steckbrücke Datenbusbreite 8 Bit und 16 Bit
(J9, im Bild Einstellung Steckbrücke für 16 Bit)
Data Bus Width Jumpers 8 Bit and 16 Bit
(J9, Jumper Settings for 16 Bit shown)
Kabelstecker Ethernet /
Cable Connector Ethernet
(X4, 20-polig / 20 pin)
Kabelstecker DIAG /
Cable Connector DIAG
(X3, 12-polig / 12 pin)
PC/104-Bus / PC/104 Bus
(X1, 64-polig / 64 pin)
(X2, 40-polig / 40 pin)
Interrupt-Steckbrücke / Interrupt Jumper
(J8, 11-polig / 11 pin)
Adressteckbrücke / Address Jumpers
(J7, 7-polig / 7 pin)
Standardeinstellungen Steckbrücken / Default Jumper Settings

Figure 4: Basic Card for CIFX 104-RE\F

Note:

- If the assembly inter face diagnostic **AIFX-DIAG** is connected to the basic card for the PC card CIFX 104-RE\F or CIFX 104-RE-R\F, the **Mini-B USB** connector on the AIFX-DIAG can be used beginning with the hardware revision 5 of the PC card cifX.
- In **Interrupt Mode** (IRQ = Interrupt Request) exactly one jumper must be set. If no jumper is set, the PC card cifX works in **Polling Mode**. For further details refer to *Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory* on page 57.

- For the pin assignment of the **PCI/104** bus X1/X2 refer to section *Pin Assignment for PC/104 Bus* on page 96.
- For the pin assignment of the **SYNC** Connector refer to section *Pin Assignment SYNC Connector, X51* on page 94.

© Hilscher, 2008-2014

5.1.4 CIFX 104-RE-R\F


Steckbrücke Datenbusbreite 8 Bit und 16 Bit
(J9, im Bild Einstellung Steckbrücke für 16 Bit)
Data Bus Width Jumpers 8 Bit and 16 Bit
(J9, Jumper Settings for 16 Bit shown)
SYNC-Anschluss / SYNC Connector
(X51, 3-polig / 3 pin)
CIFX104-RE
Hilscher
made in Germany
System LED
(gelb/grün) / (yellow/green)
Kabelstecker Ethernet /
Cable Connector Ethernet
(X304, 20-polig / 20 pin)
Kabelstecker DIAG /
Cable Connector DIAG
(X303, 12-polig / 12 pin)
PC/104 Bus
(X1, 64-polig / 64 pin)
(X2, 40-polig / 40 pin)
Interrupt-Steckbrücke / Interrupt Jumper
(J8, 11-polig / 11 pin)
Adresssteckbrücke / Address Jumpers
(J7, 7-polig / 7 pin)
Standardeinstellungen Steckbrücken / Default Jumper Settings

Figure 5: Basic Card for CIFX 104-RE-R\F

Note:

- If the assembly inter face diagnostic **AIFX-DIAG** is connected to the basic card for the PC card CIFX 104-RE\F or CIFX 104-RE-R\F, the **Mini-B USB** connector on the AIFX-DIAG can be used beginning with the hardware revision 5 of the PC card cifX.
- In **Interrupt Mode** (IRQ = Interrupt Request) exactly one jumper must be set. If no jumper is set, the PC card cifX works in **Polling Mode**. For further details refer to *Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory* on page 57.

- For the pin assignment of the **PCI/104** bus X1/X2 refer to section *Pin Assignment for PC/104 Bus* on page 96.
- For the pin assignment of the **SYNC** Connector refer to section *Pin Assignment SYNC Connector, X51* on page 94.

© Hilscher, 2008-2014

5.1.5 CIFX 104-DP



Figure 6: CIFX 104-DP

Note:

- In **Interrupt Mode** (IRQ = Interrupt Request) exactly one jumper must be set. If no jumper is set, the PC card cifX works in **Polling Mode**. For further details refer to *Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory* on page 57.

- For the pin assignment of the **PCI/104** bus X1/X2 refer to section *Pin Assignment for PC/104 Bus* on page 96.
- For further information on the **Mini-B USB** Connector refer to section *Mini-B USB Connector (5 Pin)* on page 91.

© Hilscher, 2008-2014

5.1.6 CIFX 104-DP-R


Steckbrücke Datenbusbreite 8 Bit und 16 Bit
(J9, im Bild Einstellung Steckbrücke für 16 Bit)
Data Bus Width Jumpers 8 Bit and 16 Bit
(J9, Jumper Settings for 16 Bit shown)
System LED (gelb/grün) / (yellow/green)
Kommunikations-LED (rot/grün) /
Communication LED (red/green)
PROFIBUS-Schnittstelle
DSub-Buchse (X400, 9-polig)
PROFIBUS Interface
DSub female Connector (X400, 9 pin)
Mini-B-USB-Buchse / Mini B USB Plug
(X305, 5-polig / 5 pin)
Drehschalter Geräteadresse /
Rotary Switch Device Address
(ohne Funktion / without function)
PC/104 Bus
(X1, 64-polig / 64 pin)
(X2, 40-polig / 40 pin)
Interrupt-Steckbrücke / Interrupt Jumper
(J8, 11-polig / 11 pin)
Adresssteckbrücke / Address Jumpers
(J7, 7-polig / 7 pin)
Standardeinstellungen Steckbrücken / Default Jumper Settings
CIFX104-C
CIFX104-DN
CIFX104-DP
Hilscher
SYS
COM
(x1)
(x16)
ADR 14 15 16 17 18 19
IRQ 3 4 5 6 7 9 10 11 12 14 15
L0913011

Figure 7: CIFX 104-DP-R

Note:

- In **Interrupt Mode** (IRQ = Interrupt Request) exactly one jumper must be set. If no jumper is set, the PC card cifX works in **Polling Mode**. For further details refer to *Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory* on page 57.

- For the pin assignment of the **PCI/104** bus X1/X2 refer to section *Pin Assignment for PC/104 Bus* on page 96.
- For further information on the **Mini-B USB** Connector refer to section *Mini-B USB Connector (5 Pin)* on page 91.

© Hilscher, 2008-2014

5.1.7 CIFX 104-CO



Figure 8: CIFX 104-CO

Note:

- In **Interrupt Mode** (IRQ = Interrupt Request) exactly one jumper must be set. If no jumper is set, the PC card cifX works in **Polling Mode**. For further details refer to *Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory* on page 57.

- For the pin assignment of the **PCI/104** bus X1/X2 refer to section *Pin Assignment for PC/104 Bus* on page 96.
- For further information on the **Mini-B USB** Connector refer to section *Mini-B USB Connector (5 Pin)* on page 91.

© Hilscher, 2008-2014

5.1.8 CIFX 104-CO-R



Figure 9: CIFX 104-CO-R

Note:

- In **Interrupt Mode** (IRQ = Interrupt Request) exactly one jumper must be set. If no jumper is set, the PC card cifX works in **Polling Mode**. For further details refer to *Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory* on page 57.

- For the pin assignment of the **PCI/104** bus X1/X2 refer to section *Pin Assignment for PC/104 Bus* on page 96.
- For further information on the **Mini-B USB** Connector refer to section *Mini-B USB Connector (5 Pin)* on page 91.

© Hilscher, 2008-2014

5.1.9 CIFX 104-DN



Figure 10: CIFX 104-DN

Note:

- In **Interrupt Mode** (IRQ = Interrupt Request) exactly one jumper must be set. If no jumper is set, the PC card cifX works in **Polling Mode**. For further details refer to *Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory* on page 57.

- For the pin assignment of the **PCI/104** bus X1/X2 refer to section *Pin Assignment for PC/104 Bus* on page 96.
- For further information on the **Mini-B USB** Connector refer to section *Mini-B USB Connector (5 Pin)* on page 91.

© Hilscher, 2008-2014

5.1.10 CIFX 104-DN-R


Steckbrücke Datenbusbreite 8 Bit und 16 Bit
(J9, im Bild Einstellung Steckbrücke für 16 Bit)
Data Bus Width Jumpers 8 Bit and 16 Bit
(J9, Jumper Settings for 16 Bit shown)
System LED (gelb/grün) / (yellow/green)
Modulnetzwerkstatus-LED (rot/grün) /
Module Network Status LED (red/green)
DeviceNet-Schnittstelle
COMBICON-Stecker (X360B, 5-polig)
DeviceNet Interface
COMBICON male Connector (X360B, 5 pin)
Mini-B-USB-Buchse / Mini B USB Plug
(X305, 5-polig / 5 pin)
Drehschalter Geräteadresse /
Rotary Switch Device Address
(ohne Funktion / without function)
PC/104 Bus
(X1, 64-polig / 64 pin)
(X2, 40-polig / 40 pin)
Interrupt-Steckbrücke / Interrupt Jumper
(J8, 11-polig / 11 pin)
Adressteckbrücke / Address Jumpers
(J7, 7-polig / 7 pin)
Standardeinstellungen Steckbrücken / Default Jumper Settings
CIFX104-CO
CIFX104-DN
CIFX104-DP
Hilscher
SYS
MNS
(x1)
(x16)
ADR 14 15 16 17 18 19
IRQ
3 4 5 6 7 9 10 11 12 14 15
L0913011

Figure 11: CIFX 104-DN-R

Note:

- In **Interrupt Mode** (IRQ = Interrupt Request) exactly one jumper must be set. If no jumper is set, the PC card cifX works in **Polling Mode**. For further details refer to *Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory* on page 57.

- For the pin assignment of the **PCI/104** bus X1/X2 refer to section *Pin Assignment for PC/104 Bus* on page 96.
- For further information on the **Mini-B USB** Connector refer to section *Mini-B USB Connector (5 Pin)* on page 91.

© Hilscher, 2008-2014

5.1.11 CIFX 104-DP\F, CIFX 104-CO\F, CIFX 104-DN\F, CIFX 104-CC\F


System LED
(gelb/grün) /
(yellow/green)
Steckbrücke Datenbusbreite 8 Bit und 16 Bit
(J9, im Bild Einstellung Steckbrücke für 16 Bit)
Data Bus Width Jumpers 8 Bit and 16 Bit
(J9, Jumper Settings for 16 Bit shown)
Kabelstecker Feldbus /
Cable Connector Fieldbus
(X4, 10-polig / 10 pin)
Kabelstecker DIAG /
Cable Connector DIAG
(X3, 12-polig / 12 pin)
PC/104 Bus
(X1, 64-polig / 64 pin)
(X2, 40-polig / 40 pin)
Interrupt-Steckbrücke / Interrupt Jumper
(J8, 11-polig / 11 pin)
Adresssteckbrücke / Address Jumpers
(J7, 7-polig / 7 pin)
Standardeinstellungen Steckbrücken / Default Jumper Settings
Hilscher
SYS
L0913011

Figure 12: Basic Card CIFX 104-FB\F for CIFX 104-DP\F, CIFX 104-CO\F, CIFX 104-DN\F, CIFX 104-CC\F

Note: In **Interrupt Mode** (IRQ = Interrupt Request) exactly one jumper must be set. If no jumper is set, the PC card cifX works in **Polling Mode**. For further details refer to *Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory* on page 57.

5.1.12 CIFX 104-DP-R\F, CIFX 104-CO-R\F, CIFX 104-DN-R\F


Steckbrücke Datenbusbreite 8 Bit und 16 Bit
(J9, im Bild Einstellung Steckbrücke für 16 Bit)
Data Bus Width Jumpers 8 Bit and 16 Bit
(J9, Jumper Settings for 16 Bit shown)
System-LED
(gelb/grün) / (yellow/green)
Kabelstecker Feldbus /
Cable Connector Fieldbus
(X304, 10-polig / 10 pin)
Kabelstecker DIAG /
Cable Connector DIAG
(X303, 12-polig / 12 pin)
PC/104 Bus
(X1, 64-polig / 64 pin)
(X2, 40-polig / 40 pin)
Interrupt-Steckbrücke / Interrupt Jumper
(J8, 11-polig / 11 pin)
Adresssteckbrücke / Address Jumpers
(J7, 7-polig / 7 pin)
Standardeinstellungen Steckbrücken / Default Jumper Settings
Hilscher
SYS
L0913011

Figure 13: Basic Card CIFX 104-FB-R\F for CIFX 104-DP-R\F, CIFX 104-CO-R\F, CIFX 104-DN-R\F

Note: In **Interrupt Mode** (IRQ = Interrupt Request) exactly one jumper must be set. If no jumper is set, the PC card cifX works in **Polling Mode**. For further details refer to *Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory* on page 57.

© Hilscher, 2008-2014

5.2 AIFX Assembly Interfaces

5.2.1 Ethernet - AIFX-RE

Only for CIFX 104-RE\F, CIFX 104-RE-R\F.



*Figure 14: Ethernet Assembly Interface (AIFX-RE)**

Note: *Assembled device supports Auto Crossover Function. Note also: With loaded EtherCAT Master firmware only the RJ45 channel 0 can be used, channel 1 is deactivated. Beginning with the EtherCAT Master firmware version 3 channel 1 can be reactivated if redundancy is activated. For Open Modbus/TCP with V2.3.4.0 and higher both RJ 45 channels can be used.



The meaning of the **LEDs COM0** and **COM1** at the reverse side of the AIFX-RE and the meaning of the green and yellow LEDs at RJ45Ch0 and RJ45Ch1 corresponds to the description in chapter *LED Descriptions* beginning from page 64.

Figure 15: Front Side Ethernet Assembly Interface (AIFX-RE)



Figure 16: Dimensioning and LED Display Ethernet Assembly Interface (AIFX-RE)

© Hilscher, 2008-2014

5.2.2 PROFIBUS - AIFX-DP

Only for CIFX 104-DP\F, CIFX 104-DP-R\F.



Figure 17: PROFIBUS Assembly Interface (AIFX-DP)

Figure 18: Front Side PROFIBUS Assembly Interface (AIFX-DP)



Figure 19: Dimensioning and LED Display PROFIBUS Assembly Interface (AIFX-DP)

The meaning of the **LEDs ERR** and **STA** at the reverse side of the AIFX-DP corresponds to the description in chapter *LED Descriptions* beginning from page 64.

© Hilscher, 2008-2014

5.2.3 CANopen - AIFX-CO

Only for CIFX 104-CO\F, CIFX 104-CO-R\F.



Figure 20: CANopen Assembly Interface (AIFX-CO)

Figure 21: Front Side Assembly Interface (AIFX-CO)



ERR: **LED Fehlerstatus** (rot) / ***LED Error status*** *(red)*

RUN: **LED Run** (grün) / ***LED Run*** *(green)*

Figure 22: Dimensioning and LED Display CANopen Assembly Interface (AIFX-CO)

The meaning of the **LEDs ERR** and **RUN** at the reverse side of the AIFX-CO corresponds to the description in chapter *LED Descriptions* beginning from page 64.

© Hilscher, 2008-2014

5.2.4 DeviceNet - AIFX-DN

Only for CIFX 104-DN\F, CIFX 104-DN-R\F.



Figure 23: DeviceNet Assembly Interface (AIFX-DN)



Figure 24: Front Side DeviceNet Assembly Interface (AIFX-DN)



Figure 25: Dimensioning and LED Display DeviceNet Assembly Interface (AIFX-DN)

The meaning of the **LED MNS** at the reverse side of the AIFX-DN corresponds to the description in chapter *LED Descriptions* beginning from page 64.

© Hilscher, 2008-2014

5.2.5 CC-Link - AIFX-CC

Only for CIFX 104-CC\F.



Figure 26: CC-Link Assembly Interface (AIFX-CC)



Figure 27: Front Side CC-Link Assembly Interface (AIFX-CC)



Figure 28: Dimensioning and LED Display CC-Link Assembly Interface (AIFX-CC)

The meaning of the **LEDs L-RUN** and **L-ERR** aat the reverse side of the AIFX-CC corresponds to the description in chapter *LED Descriptions* beginning from page 64.

© Hilscher, 2008-2014

5.2.6 Diagnostic - AIFX-DIAG

Only for CIFX 104-RE\F, CIFX 104-RE-R\F, CIFX 104-DP\F, CIFX 104-DP-R\F, CIFX 104-CO\F, CIFX 104-CO-R\, CIFX 104-DN\F, CIFX 104-DN-R\F, CIFX 104-CC\F.



Figure 29: Diagnostic Assembly Interface (AIFX-DIAG)

The meaning of the **LEDs** at the **AIFX-DAIG** corresponds to the descriptions in chapter *LED Descriptions* beginning from page 64. For further information on the **Mini-B USB** Connector refer to section *Mini-B USB Connector (5 Pin)* on page91.



Figure 30: Front Side Diagnostic Assembly Interface (AIFX-DIAG)



Figure 31: Dimensioning and LED Display Diagnostic Assembly Interface (AIFX-DIAG)

© Hilscher, 2008-2014

6 Hardware Installation and Uninstalling

To install / uninstall the PC cards cifX **PC/104**

- CIFX 104-RE
- CIFX 104-RE-R
- CIFX 104-RE\F
- CIFX 104-RE-R\F
- CIFX 104-DP
- CIFX 104-DP-R
- CIFX 104-DP\F
- CIFX 104-DP-R\F
- CIFX 104-CO
- CIFX 104-CO-R
- CIFX 104-CO\F
- CIFX 104-CO-R\F
- CIFX 104-DN
- CIFX 104-DN-R
- CIFX 104-DN\F
- CIFX 104-DN-R\F
- CIFX 104-CC\F

handle as described in the sections hereafter. The device drawing of your PC card cifX gives information on the manual control elements of your device.

For the installation, uninstalling and replacement of the PC card cifX check any notes in the overview in chapter *Getting Started* on page 31.

6.1 Safety Messages on Personal Injury

Obey to the following safety messages on personal injury, when installing, uninstalling or replacing the PC card cifX.

6.1.1 Electrical Shock Hazard

⚠ WARNING

Lethal Electrical Shock caused by parts with more than 50V!

- HAZARDOUS VOLTAGE inside of the PC or of the connecting device.
- Strictly obey to all safety rules provided by the device's manufacturer in the documentation!
- First disconnect the power plug of the PC or of the connecting device, before you open the cabinet.
- Make sure, that the power supply is off at the PC or at the connecting device.
- Open the PC cabinet and install or remove the PC card cifX only after disconnecting power.

© Hilscher, 2008-2014

6.2 Property Damage Messages

Obey to the following property damage messages, when installing, uninstalling or replacing the PC card cifX.

6.2.1 Device Destruction by exceeding allowed Supply Voltage

Adhere for all PC cards cifX described in this manual the instruction hereafter:

NOTICE

Device Destruction!

- Use only the permissible supply voltage to operate the PC card cifX.
- Operating the PC card cifX with a supply voltage above of the specified range leads to device destruction.

6.2.2 Device Destruction by exceeding allowed Signaling Voltage

Adhere for all PC cards cifX described in this manual the instruction hereafter:

NOTICE

Device Destruction!

- All I/O signal pins at the PC card cifX tolerate only the specified signaling voltage!
- Operation the PC card cifX with a signaling voltage other than the specified signaling voltage may lead to severe damage to the PC card cifX!

For detailed information on the supply and signaling voltage of the PC cards cifX described in this manual, refer to section *Power Supply and Host Interface* on page 28.

6.2.3 Electrostatically sensitive Devices

Adhere to the necessary safety precautions for components that are vulnerable with electrostatic discharge.

NOTICE

Electrostatically sensitive Devices

- To prevent damage to the PC and the PC card cifX, make sure, that the PC card cifX is grounded via the endplate and the PC and make sure, that you are discharged when you install/uninstall the PC card cifX.

© Hilscher, 2008-2014

6.3 cifX PC/104: Set Starting Address and Interrupt

To set the starting address and or an interrupt (or polling) for **PC Cards cifX PC/104**, proceed as follows:

1. Check the memory area of the PC.

Important! Make sure that the configured memory areas and interrupts of the PC are not used by another PC component.

In order to identify and prevent such errors:

- Start the **Device Manager**.
- Select **menu View > Resources by type**.
- The used **Memory** respectively the **interrupt (IRQ) resources** are shown.
- Search for a free memory area:

The possible memory areas of 16 KByte are:

- C0000 … C3FFF (hex),
- D0000 … D3FFF (hex),
- E0000 … E3FFF (hex) or
- F0000 … F3FFF (hex).

The PC card cifX PC/104 can be used in poll mode or in interrupt mode.

- If the PC card cifX shall be used in interrupt mode, then search for a free interrupt:

Possible interrupts are 3, 4, 5, 6, 7, 9, 10, 11, 12, 14, 15

2. Configure the start address of the PC card cifX PC/104 (*Hardware*).

Note: Please note that the PC card cifX PC/104 requires a free memory area of 16 KByte. Possible are the following areas:
- C0000 … C3FFF (hex),
- D0000 … D3FFF (hex),
- E0000 … E3FFF (hex) or
- F0000 … F3FFF (hex).

Address	A19	A18	A17	A16	A15	A14
C0000			X	X	X	X
D0000			X		X	X
E0000				X	X	X
F0000					X	X

Default Addresse D0000

Interrupt	3	…	12	14	15
15					X
14				X	
12			X		
…					
3	X				

(X = Jumper closed)

Polling	No jumper is set.

Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory

For more see next page.

© Hilscher, 2008-2014

3. If you are using the interrupt mode, set up a free interrupt on the PC card cifX PC/104 (*Hardware*).

For polling operation mode interrupt jumpers are not required.

Note: The default setting is address D0000 and no interrupt (**Basis Configuration 0**). To change the address select **Basis Configuration 1**. The interrupt and the address can be changed under **Basis Configuration 2**.

Note: On some PCs it is not possible to find a free ISA memory area between C0000–FBFFF or a free ISA interrupt in the Device Manager. This is Windows®(*) ACPI (Advanced Configuration and Power Management Interface) depending. Please check at first if your PC is ACPI compatible and you are using the latest BIOS version for your mainboard. Are there still problems to find available ISA resources, you can try to run Windows®(*) in "Standard PC" mode (ACPI disabled). Therefore the ACPI-HAL of Windows®(*) must be replaced with the STANDARD-PC-HAL or Windows®(*) must be installed new. Please contact Microsoft how to change the Windows®(*) XP-HAL, because this can make your installation unusable.

(*) Windows® XP

4. Reserve **Memory Range / Interrupt** at the *operating system*.

➢ Reserve for the PC cards cifX PC/104 the memory range and if necessary one interrupt at the operating system.

For further information refer to **User Manual Software Installation for the PC Cards cifX** on the Communication Solutions DVD.

© Hilscher, 2008-2014

6.4 Installing PC Cards cifX PC/104 (PC/104 Modules)

Note: For PC cards cifX PC/104 with AIFX assembly interface first install the basic card. Then connect the AIFX assembly interface to the basic card.

1. Adhere to the necessary safety precautions for components that are vulnerable with electrostatic discharge.

NOTICE

Electrostatically sensitive Devices

➢ To prevent damage to the PC and the PC card cifX, make sure, that the PC card cifX is grounded via the endplate and the PC and make sure, that you are discharged when you install/uninstall the PC card cifX.

2. Configure starting address, interrupt and data bus width of the PC card cifX PC/104

➢ Configure the start address of the PC card cifX PC/104.

➢ If you are using the interrupt mode, set up a free interrupt on the PC card cifX PC/104.

For polling operation mode interrupt jumpers are not required.

Note: Several PC/104 modules can be plugged one upon the other. For each PC card CIFX 104-RE\F you must define a free memory area of 16 KByte.

For further information on the starting address and or an interrupt (or polling) refer to section *cifX PC/104: Set Starting Address and Interrupt* on page 57.

➢ Depending by the target system (motherboard) if so, set at the PC card cifX PC/104 a **Data Bus Width** of 8 bit or 16 bit.

By default the jumper is set for a data bus width of 16 Bit (refer to chapter *Device Drawings* on page 38.

3. Take safety precautions.

⚠ WARNING

Lethal Electrical Shock caused by parts with more than 50V!

➢ Disconnect the power plug of the PC or of the connecting device.

➢ Make sure, that the power supply is off at the PC or at the connecting device.

4. Open cabinet.

➢ Open the cabinet of the PC or of the connecting device.

Note: If several PC/104 modules shall be put together in a stack:
(a) Install the first PC/104 module on the mainboard.
(b) Only for the basic cards CIFX 104-RE\F and CIFX 104-RE-R\F or the basic cards CIFX 104-FB\F and CIFX 104-FB-R\F: Connect the AIFX-RE, AIFX-DP, AIFX-CO, AIFX-DN, AIFX-CC assembly interface or AIFX-DIAG to the basic card for the first PC/104 module.
(c) Connect any other PC/104 module on the respective underlying PC/104 module.

5. Install PC card cifX **PC/104**.

➢ Plug the PC card cifX into a free PC/104 slot (or if so, to the underlying PC/104 module).

➢ Fix the PC card cifX using 4 spacing bolts and screws intended to the mainboard (or if so, to the underlying PC/104 module). The scope of delivery does not include spacing bolts and screws.

© Hilscher, 2008-2014

Connect AIFX Assembly Interface

Only for the basic cards CIFX 104-RE\F and CIFX 104-RE-R\F or the basic cards CIFX 104-FB\F and CIFX 104-FB-R\F:

Note: First connect the AIFX-RE, AIFX-DP, AIFX-CO, AIFX-DN or AIFX-CC assembly interface to each basic card PC/104, before plugging another PC/104 module. Just so you can check exactly whether the AIFX is properly connected to the basic card.

Important! Operating the PC cards CIFX 104-XX\F or CIFX 104-XX-R\F requires proper connection of the Ethernet (AIFX-RE), PROFIBUS (AIFX-DP), CANopen (AIFX-CO), DeviceNet (AIFX-DN) or CC-Link (AIFX-CC) assembly interface to the basic card!

6. Connect the Ethernet assembly interface (AIFX-RE) to the basic card.

- Connect the **cable connector Ethernet X1** on the AIFX-RE with the cable.
- Connect the **cable connector Ethernet X4** (or X304) on the basic card CIFX 104-RE\F or CIFX 104-RE-R\F with the cable.



Figure 32: Connecting the Ethernet Assembly Interface (AIFX-RE) to the Basic Card CIFX 104-RE\F (Example)

7. Or connect the PROFIBUS (AIFX-DP), CANopen (AIFX-CO), DeviceNet (AIFX-DN) or CC-Link (AIFX-CC) assembly interface to the basic card.

- Connect the **cable connector fieldbus X1** on the assembly interface with the cable.
- Connect the **cable connector fieldbus X4** (or X304) on the PC card CIFX 104-FB\F or CIFX 104-FB-R\F Feldbus with the cable.

AIFX-CO Assembly Interface with **Cable Connector Fieldbus X1**

Example basic card **CIFX 104C-CO-R**\F, **Cable Connector Fieldbus X4**



Important! The contacts on the connection cable must face up!

Figure 33: Connecting the CANopen Assembly Interface (AIFX-CO) to the Basic Card 104-FB-R\F (Example)

- Install the AIFX-RE, AIFX-DP, AIFX-CO, AIFX-DN or AIFX-CC assembly interface at the front plate of the PC cabinet.

© Hilscher, 2008-2014

Connect AIFX-DIAG

Only for the basic cards CIFX 104-RE\F and CIFX 104-RE-R\F or the basic cards CIFX 104-FB\F and CIFX 104-FB-R\F:

8. If so, connect the diagnostic assembly interface (AIFX-DIAG):

➢ Connect the **cable connector DIAG X1** on the diagnostic assembly interface (AIFX-DIAG) with the cable.

➢ Connect the **cable connector DIAG X3** (or X303) on the PC card cifX with the cable.

➢ Install the assembly interface AIFX-DIAG at the front plate of the PC cabinet).



Important! The contacts on the connection cable must face up!

Figure 34: Connecting the Diagnostic Assembly Interface (AIFX-DIAG) to the Basic Card CIFX 104-FB-R\F (Example)

After this:

9. Close cabinet.

➢ Close the cabinet of the PC or connecting device.

10. Plug the connecting cable to the Master or Slave.

➢ For the PC cards CIFX 104-RE\F or CIFX 104-RE-R\F note:

Note: The RJ45 socket is only for use in LAN, not for telecommuni-cation circuits. For further information refer to section *Ethernet Interface* on page 87.

➢ Plug the connecting cable from the PC card cifX to the PC card Master or Slave.

11. Connect the PC or the connecting device to the power supply and switch it on.

➢ Connect the PC or the connecting device to the power supply.

➢ Switch on the PC or the connecting device.

© Hilscher, 2008-2014

6.5 Uninstalling PC Cards cifX PC/104

1. Take safety precautions.

⚠ WARNING

Lethal Electrical Shock caused by parts with more than 50V!

➢ Disconnect the power plug of the PC or of the connecting device.

➢ Make sure, that the power supply is off at the PC or at the connecting device.

NOTICE

Electrostatically sensitive Devices

➢ To prevent damage to the PC and the PC card cifX, make sure, that the PC card cifX is grounded via the endplate and the PC and make sure, that you are discharged when you install/uninstall the PC card cifX.

2. Remove the connecting cable to the Master or Slave.

➢ Remove the connecting cable between the PC card cifX to be replaced and the PC card Master or Slave.

3. Open cabinet.

➢ Open the cabinet of the PC or of the connecting device.

Note: If a PC card CIFX 104-XX\F or CIFX 104-XX-R\F shall be uninstalled from a stack of PC/104 modules:
(a) Remove all PC/104 modules above from the PC card cifX and the PC card cifX. For each PC card cifX first remove the AIFX assembly interfaces from the basic cards.
(b) Reinstall the removed PC/104 modules.

Uninstall AIFX Assembly Interfaces

Only for PC cards PC/104 with AIFX Assembly Interface CIFX 104-XX\F and CIFX 104-XX-R\F:

4. Uninstall the Ethernet assembly interface (AIFX-RE), PROFIBUS (AIFX-DP), CANopen (AIFX-CO), DeviceNet (AIFX-DN) and diagnostic (AIFX-DIAG):

➢ Remove the AIFX assembly interfaces from the front plate of the PC cabinet.

➢ Disconnect the cables from the PC card cifX PC/104; cable connector Ethernet X4 (or X304) or cable connector fieldbus X4 (or X304) and cable connector DIAG X3 (or X303).

Remove PC Card cifX

5. Remove PC card cifX **PC/104**.

➢ Loosen the four fastening screws of the PC card cifX.

➢ Remove the PC card cifX.

After this:

6. Close cabinet.

➢ Close the cabinet of the PC or connecting device.

© Hilscher, 2008-2014

7 Troubleshooting

7.1 Instructions for Problem Solving

In case of any error, follow the instructions for problem solving given here:

General

➢ Check the PC card cifX operating requirements according to the requirements given in the section *Requirements for Operation* on page 30.

SYS and COM Status LEDs

Troubleshooting of the system is done by examining the LEDs behaviour. The PC cards cifX have depending by card type two or three bicolor status LEDs, which inform the user about the communication state of the device.

- The **SYS** LED shows the common system status of the device. It can be yellow or green ON or it can blink green/yellow.
- The **COM** LEDs display the status of the Real-Time Ethernet or fieldbus communication. Depending by protocol and state, the LEDs can be ON or flash cyclic or acyclic in green or red (or orange).

If the LED SYS is solid green and the LED COM or COM0 is static green, the PC card cifX is in operational state, the Master is in data exchange with the connected Slaves and the communication is running without fault. The meaning of the LEDs is described in chapter *LED Descriptions* beginning from page 64.

LINK-LED (for PC cards cifX Real-Time Ethernet)

➢ Check using the LINK LED's status whether a connection to the Ethernet is established. Therefore use the description on the LINK LED in the chapter *LED Descriptions* beginning from page 64.

Cable

➢ Check that the pin assignment of the cable is correct. This means, the cable by which you connect the PC card cifX to the PC card Master or Slave.

Configuration

➢ Check the configuration in the Master device and the Slave device. The configuration has to match.

Diagnosis

Via **Online > Diagnosis** (for SYCON.net) or **netX Configuration Tool > Diagnostics** (for netX Configuration Tool) the diagnostic information of the device is shown. The shown diagnostic information depends on the used protocol.

Further information about the device diagnosis and its functions you find in the operating instruction manual of the corresponding Real-Time Ethernet or fieldbus system.

© Hilscher, 2008-2014

8 LED Descriptions

8.1 Overview LEDs Real-Time Ethernet Systems

Note: The meaning of the communication status and the RJ45 LEDs at the PC card cifX is defined by the loaded cifX firmware of the predocol.

LED Naming in the Device Drawing		EtherCAT Master	EtherCAT Slave	EtherNet/IP	Open-Modbus/TCP	POWERLINK	PROFINET IO	sercos Master	sercos Slave	VARAN
SYS (System Status) (yellow/green)		**SYS**	**SYS**	**SYS**	**SYS**	**SYS**	**SYS**	**SYS**	**SYS**	**SYS**
COM 0 (Communication Status)		**RUN** (green)	**RUN** (green)	**MS** (red/ green)	**RUN** (green)	**BS** (green)	**SF** (red)	**STA** (green)	**S3** (red/ green/ orange)	**RUN** (green)
COM 1 (Communication Status)		**ERR** (red)	**ERR** (red)	**NS** (red/ green)	**ERR** (red)	**BE** (red)	**BF** (red)	**ERR** (red)	-	**ERR** (red)
RJ45 Ch0	(green)	**LINK**	**L/A IN**	**LINK**	**LINK**	**L/A**	**LINK**	**L/A**	**L/A**	**LINK**
	(yellow)	**ACT**	-	**ACT**	**ACT**	-	**RX/TX**	-	-	**ACT**
RJ45 Ch1	(green)	-	**L/A OUT**	**LINK**	**LINK**	**L/A**	**LINK**	**L/A**	**L/A**	**LINK**
	(yellow)	-	-	**ACT**	**ACT**	-	**RX/TX**	-	-	**ACT**

Table 24: Overview LEDs Real-Time Ethernet Systems

LED	Name	Meaning
System Status	SYS	System Status
Communication Status	COM	Communication Status
	RUN	Run
	ERR	Error
	STA	Status
	MS	Module Status
	NS	Network Status
	BS	Bus Status
	BE	Bus Error
	SF	System Failure
	BF	Bus Failure
	S3	Status / Error

LED	Name	Meaning
RJ45	LINK, L	Link
	ACT, A	Activity
	L/A	Link/Activity
	L/A IN	Link/Activity Input
	L/A OUT	Link/Activity Output
	RX/TX	Receive/Transmit

Table 25: LED Names

© Hilscher, 2008-2014

8.2 Overview LEDs Fieldbus Systems

LED	**PROFIBUS DP or PROFIBUS MPI** (1 Duo LED)	**PROFIBUS DP or PROFIBUS MPI** (2 LEDs, AIFX-DP is conneced)	**CANopen** (1 Duo LED)	**CANopen** (2 LEDs, AIFX-CO is conneced)	**DeviceNet** (1 Duo LED)	**CC-Link (Slave)** (2 LEDs)
System Status (gelb/green)	**SYS**	**SYS**	**SYS**	**SYS**	**SYS**	**SYS**
Communication Status	**COM** (red/green)	**ERR** (red) **STA** (green)	**CAN** (red/green)	**ERR** (red) **RUN** (green)	**MNS** (red/green)	**L RUN** (green) **L ERR** (red)

Table 26: Overview LEDs by Fieldbus System for 1- and 2-Channel Devices

LED	Name	Meaning
System Status	SYS	System Status
Communication Status	COM	Communication Status
	RUN	Run
	ERR	Error
	STA	Status
	CAN	CANopen Status
	MNS	Module Network Status
	L RUN / L ERR	Status Run / Status Error

Table 27: LED Names

8.3 System LED

The subsequent table describes the meaning of the system LED.

LED	Color	State	Meaning
SYS	**Duo LED yellow/green**		
	(green)	On	Operating System running
	(green/ yellow)	Blinking green/ yellow	Second stage bootloader is waiting for firmware
	(yellow)	Static	Bootloader netX (= romloader) is waiting for second stage bootloader
	(off)	Off	Power supply for the device is missing or hardware defect.

Table 28: System Status LED

8.4 Power On LED

The subsequent table describes the meaning of the Power On LED.

LED	Color	State	Meaning
PWR	**LED green**		
	(green)	On	Power supply for the device on.
	(off)	Off	Power supply for the device is missing.

Table 29: Power On LED

© Hilscher, 2008-2014

8.5 EtherCAT Master

The subsequent table describes the meaning of the LEDs for the PC card cifX Real-Time Ethernet Master when the firmware of the EtherCAT Master protocol is loaded to the device.

LED	Color	State	Meaning
RUN Name in the device drawing: **COM 0**	**Duo LED red/green**		
	(off)	Off	**INIT**: The device is in state INIT
	(green)	Blinking	**PRE-OPERATIONAL**: The device is in PRE-OPERATIONAL state
	(green)	Flickering	**BOOT**: Device is in Boot mode
	(green)	Single Flash	**SAFE-OPERATIONAL**: The device is in SAFE-OPERATIONAL state
	(green)	On	**OPERATIONAL**: The device is in OPERATIONAL state
ERR Name in the device drawing: **COM 1**	**Duo LED red/green**		
	(off)	Off	Master has no errors
	(red)	On	Master has detected a communication error. The error is indicated in the DPM
LINK/ RJ45 Ch0	**LED green**		
	(green)	On	A link is established
	(off)	Off	No link established
ACT/ RJ45 Ch0	**LED yellow**		
	(yellow)	Flickering	The device sends/receives Ethernet frames

Table 30: LEDs EtherCAT Master

LED State Definition for EtherCAT Master for the RUN and ERR LEDs

Indicator state	Definition
On	The indicator is constantly on.
Off	The indicator is constantly off.
Blinking	The indicator turns on and off with a frequency of 2,5 Hz: on for 200 ms, followed by off for 200 ms.
Flickering	The indicator turns on and off with a frequency of approximately 10 Hz: on for approximately 50 ms, followed by off for 50 ms.
Single Flash	The indicator shows one short flash (200 ms) followed by a long off phase (1,000 ms).

Table 31: LED State Definition for EtherCAT Master for the RUN and ERR LEDs

© Hilscher, 2008-2014

8.6 EtherCAT Slave

The subsequent table describes the meaning of the LEDs for the PC card cifX Real-Time Ethernet Slave when the firmware of the EtherCAT Slave protocol is loaded to the device.

LED	Color	State	Meaning
RUN Name in the device drawing: **COM 0**	**Duo LED red/green**		
	(off)	Off	**INIT**: The device is in state INIT
	(green)	Blinking	**PRE-OPERATIONAL**: The device is in state PRE-OPERATIONAL
	(green)	Single Flash	**SAFE-OPERATIONAL**: The device is in state SAFE-OPERATIONAL
	(green)	On	**OPERATIONAL**: The device is in state OPERATIONAL
ERR Name in the device drawing: **COM 1**	**Duo LED red/green**		
	(off)	Off	**No error**: The EtherCAT communication of the device is in working condition
	(red)	Blinking	**Invalid Configuration**: General Configuration Error Possible reason: State change commanded by master is impossible due to register or object settings.
	(red)	Single Flash	**Local Error**: Slave device application has changed the EtherCAT state autonomously. Possible reason 1: A host watchdog timeout has occurred. Possible reason 2: Synchronization Error, device enters Safe-Operational automatically.
	(red)	Double Flash	**Application Watchdog Timeout**: An application watchdog timeout has occurred. Possible reason: Sync Manager Watchdog timeout.
L/A IN/ RJ45 Ch0 **L/A OUT**/ RJ45 Ch1	**LED green**		
	(green)	On	A link is established
	(green)	Flickering	The device sends/receives Ethernet frames
	(off)	Off	No link established
RJ45 Ch0 RJ45 Ch1	**LED yellow**		
	(yellow)	-	-

Table 32: LEDs EtherCAT Slave

LED State Definition for EtherCAT Slave for the RUN and ERR LEDs

Indicator state	Definition
On	The indicator is constantly on.
Off	The indicator is constantly off.
Blinking	The indicator turns on and off with a frequency of 2,5 Hz: on for 200 ms, followed by off for 200 ms.
Flickering	The indicator turns on and off with a frequency of approximately 10 Hz: on for approximately 50 ms, followed by off for 50 ms.
Single Flash	The indicator shows one short flash (200 ms) followed by a long off phase (1,000 ms).
Double Flash	The indicator shows a sequence of two short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).

Table 33: LED State Definition for EtherCAT Slave for the RUN and ERR LEDs

© Hilscher, 2008-2014

8.7 EtherNet/IP Scanner (Master)

The subsequent table describes the meaning of the LEDs for the PC card cifX Real-Time Ethernet (Master) when the firmware of the EtherNet/IP Scanner (Master) protocol is loaded to the device.

LED	Color	State	Meaning
MS Name in the device drawing: **COM 0**	**Duo LED red/green**		
	(green)	On	**Device operational**: If the device is operating correctly, the module status indicator shall be steady green.
	(green)	Flashing	**Standby**: If the device has not been configured, the module status indicator shall be flashing green.
	(red)	On	**Major fault**: If the device has detected a non-recoverable major fault, the module status indicator shall be steady red.
	(red)	Flashing	**Minor fault**: If the device has detected a recoverable minor fault, the module status indicator shall be flashing red. NOTE: An incorrect or inconsistent configuration would be considered a minor fault.
	(red/green)	Flashing	**Self-test**: While the device is performing its power up testing, the module status indicator shall be flashing green/red.
	(off)	Off	**No power**: If no power is supplied to the device, the module status indicator shall be steady off.
NS Name in the device drawing: **COM 1**	**Duo LED red/green**		
	(green)	On	**Connected**: If the device has at least one established connection (even to the Message Router), the network status indicator shall be steady green.
	(green)	Flashing	**No connections**: If the device has no established connections, but has obtained an IP address, the network status indicator shall be flashing green.
	(red)	On	**Duplicate IP**: If the device has detected that its IP address is already in use, the network status indicator shall be steady red.
	(red)	Flashing	**Connection timeout**: If one or more of the connections in which this device is the target has timed out, the network status indicator shall be flashing red. This shall be left only if all timed out connections are reestablished or if the device is reset.
	(red/green)	Flashing	**Self-test**: While the device is performing its power up testing, the network status indicator shall be flashing green/red.
	(off)	Off	**Not powered, no IP address**: If the device does not have an IP address (or is powered off), the network status indicator shall be steady off.
LINK/RJ45 Ch0 & Ch1	**LED green**		
	(green)	On	A connection to the Ethernet exists
	(off)	Off	The device has no connection to the Ethernet
ACT/RJ45 Ch0 & Ch1	**LED yellow**		
	(yellow)	Flashing	The device sends/receives Ethernet frames

Table 34: LEDs EtherNet/IP Scanner (Master)

© Hilscher, 2008-2014

8.8 EtherNet/IP Adapter (Slave)

The subsequent table describes the meaning of the LEDs for the PC card cifX Real-Time Ethernet (Slave) when the firmware of the EtherNet/IP Adapter (Slave) protocol is loaded to the device.

LED	Color	State	Meaning
MS Name in the device drawing: **COM 0**	**Duo LED red/green**		
	(green)	On	**Device operational**: If the device is operating correctly, the module status indicator shall be steady green.
	(green)	Flashing	**Standby**: If the device has not been configured, the module status indicator shall be flashing green.
	(red)	On	**Major fault**: If the device has detected a non-recoverable major fault, the module status indicator shall be steady red.
	(red)	Flashing	**Minor fault**: If the device has detected a recoverable minor fault, the module status indicator shall be flashing red. NOTE: An incorrect or inconsistent configuration would be considered a minor fault.
	(red/green)	Flashing	**Self-test**: While the device is performing its power up testing, the module status indicator shall be flashing green/red.
	(off)	Off	**No power**: If no power is supplied to the device, the module status indicator shall be steady off.
NS Name in the device drawing: **COM 1**	**Duo LED red/green**		
	(green)	On	**Connected**: If the device has at least one established connection (even to the Message Router), the network status indicator shall be steady green.
	(green)	Flashing	**No connections**: If the device has no established connections, but has obtained an IP address, the network status indicator shall be flashing green.
	(red)	On	**Duplicate IP**: If the device has detected that its IP address is already in use, the network status indicator shall be steady red.
	(red)	Flashing	**Connection timeout**: If one or more of the connections in which this device is the target has timed out, the network status indicator shall be flashing red. This shall be left only if all timed out connections are reestablished or if the device is reset.
	(red/green)	Flashing	**Self-test**: While the device is performing its power up testing, the network status indicator shall be flashing green/red.
	(off)	Off	**Not powered, no IP address**: If the device does not have an IP address (or is powered off), the network status indicator shall be steady off.
LINK/RJ45 Ch0 & Ch1	**LED green**		
	(green)	On	A connection to the Ethernet exists
	(off)	Off	The device has no connection to the Ethernet
ACT/RJ45 Ch0 & Ch1	**LED yellow**		
	(yellow)	Flashing	The device sends/receives Ethernet frames

Table 35: LEDs EtherNet/IP Adapter (Slave)

© Hilscher, 2008-2014

8.9 Open Modbus/TCP

The subsequent table describes the meaning of the LEDs for the PC card cifX Real-Time Ethernet when the firmware of the Open Modbus/TCP protocol is loaded to the device.

LED	Color	State	Meaning
RUN Name in the device drawing: **COM 0**	**Duo LED red/green**		
	(off)	Off	**Not Ready** OMB task is not ready
	(green)	Flashing cyclic with 1Hz	**Ready, not configured yet** OMB task is ready and not configured yet
	(green)	Flashing cyclic with 5Hz	**Waiting for Communication:** OMB task is configured
	(green)	On	**Connected:** OMB task has communication – at least one TCP connection is established
ERR Name in the device drawing: **COM 1**	**Duo LED red/green**		
	(off)	Off	No communication error
	(red)	Flashing cyclic with 2Hz (On/Off Ratio = 25 %)	System error
	(red)	On	Communication error active
LINK/RJ 45 Ch0 & Ch1	**LED green**		
	(green)	On	A connection to the Ethernet exists
	(off)	Off	The device has no connection to the Ethernet
ACT/RJ 45 Ch0 & Ch1	**LED yellow**		
	(yellow)	Flashing	The device sends/receives Ethernet frames

Table 36: LEDs Open Modbus/TCP

© Hilscher, 2008-2014

8.10 POWERLINK Controlled Node/Slave

The subsequent table describes the meaning of the LEDs for the PC card cifX Real-Time Ethernet (Slave) when the firmware of the POWERLINK Controlled Node Controlled Node/Slave protocol is loaded to the device.

LED	Color	State	Meaning
BS Name in the device drawing: **COM 0**	**Duo LED red/green**		
	(off)	Off	Slave initializing
	(green)	Flickering	Slave is in 'Basic Ethernet' state
		Single Flash	Slave is in 'Pre-Operational 1' state
		Double Flash	Slave is in 'Pre-Operational 2' state
		Triple Flash	Slave is in 'ReadyToOperate' state
		On	Slave is in 'Operational' state
		Blinking	Slave is in 'Stopped' state
BE Name in the device drawing: **COM 1**	**Duo LED red/green**		
	(off)	Off	Slave has no error
	(red)	On	Slave has detected an error
L/A/ RJ45 Ch0 & Ch1	**LED green**		
	(green)	On	**Link**: A connection to the Ethernet exists
	(green)	Flickering	**Activity**: The device sends/receives Ethernet frames
	(off)	Off	The device has no connection to the Ethernet
RJ45 Ch0 & Ch1	**LED yellow**		
	-	-	This LED is not used.

Table 37: LEDs POWERLINK Controlled Node Controlled Node/Slave

LED State Definition for POWERLINK Controlled Node Controlled Node/Slave for the BS/BE LEDs

Indicator state	Definition
On	The indicator is constantly on.
Off	The indicator is constantly off.
Blinking	The indicator turns on and off with a frequency of approximately 2,5 Hz: on for approximately 200 ms, followed by off for 200 ms. Red and green LEDs shall be on alternately.
Flickering	The indicator turns on and off with a frequency of approximately 10 Hz: on for approximately 50 ms, followed by off for 50 ms. Red and green LEDs shall be on alternately.
Single Flash	The indicator shows one short flash (approximately 200 ms) followed by a long off phase (approximately 1,000 ms).
Double Flash	The indicator shows a sequence of two short flashes (each approximately 200 ms), separated by a short off phase (approximately 200 ms). The sequence is finished by a long off phase (approximately 1,000 ms).
Triple Flash	The indicator shows a sequence of three short flashes (each approximately 200 ms), separated by a short off phase (approximately 200 ms). The sequence is finished by a long off phase (approximately 1,000 ms).

Table 38: LED State Definition for POWERLINK Controlled Node Controlled Node/Slave for the BS/BE LEDs

© Hilscher, 2008-2014

8.11 PROFINET IO-Controller

The subsequent table describes the meaning of the LEDs for the PC card cifX Real-Time Ethernet (Master) when the firmware of the PROFINET IO-Controller protocol is loaded to the device.

LED	Color	State	Meaning
SF Name in the device drawing: **COM 0**	**Duo LED red/green**		
	(off)	Off	No error
	(red)	On	*(***together** *with BF „red ON“)* **No valid Master license**
	(red)	Flashing cyclic at 2 Hz	**System error**: Invalid configuration, Watchdog error or internal error
BF Name in the device drawing: **COM 1**	**Duo LED red/green**		
	(off)	Off	No error
	(red)	On	**No Connection:** No Link. *or (***together** *with SF „red ON“)* **No valid Master license**
	(red)	Flashing cyclic at 2 Hz	**Configuration fault:** not all configured IO-Devices are connected.
LINK/RJ45 Ch0 & Ch1	**LED green**		
	(green)	On	A connection to the Ethernet exists
	(off)	Off	The device has no connection to the Ethernet
RX/TX/RJ45 Ch0 & Ch1	**LED yellow**		
	(yellow)	Flashing	The device sends/receives Ethernet frames

Table 39: LEDs PROFINET IO-Controller

© Hilscher, 2008-2014

8.12 PROFINET IO-Device

The subsequent table describes the meaning of the LEDs for the PC card cifX Real-Time Ethernet (Slave) when the firmware of the PROFINET IO-Device protocol is loaded to the device

LED	Color	State	Meaning
SF Name in the device drawing: **COM 0**	**Duo LED red/green**		
	(off)	Off	No error
	(red)	On	Watchdog timeout; channel, generic or extended diagnosis present; system error
	(red)	Flashing cyclic at 2 Hz (for 3 sec.)	DCP signal service is initiated via the bus
BF Name in the device drawing: **COM 1**	**Duo LED red/green**		
	(off)	Off	No error
	(red)	On	No configuration; or low speed physical link; or no physical link
	(red)	Flashing cyclic at 2 Hz	No data exchange
LINK/RJ45 Ch0 & Ch1	**LED green**		
	(green)	On	A connection to the Ethernet exists
	(off)	Off	The device has no connection to the Ethernet
RX/TX/RJ45 Ch0 & Ch1	**LED yellow**		
	(yellow)	Flashing	The device sends/receives Ethernet frames

Table 40: LEDs PROFINET IO-Device

© Hilscher, 2008-2014

8.13 sercos Master

The subsequent table describes the meaning of the LEDs for the PC card cifX Real-Time Ethernet Master when the firmware of the sercos Master protocol is loaded to the device.

LED	Color	State	Meaning
STA Name in the device drawing: **COM 0**	**Duo LED red/green**		
	(green)	Blinking	**CP0:** Communication phase 0
	(green)	Flickering	Master isn't configured and is in NRT. After a status change this isn't indicated again
	(green)	Single Flash	**CP1:** Communication phase 1
	(green)	Double Flash	**CP2:** Communication phase 2
	(green)	Triple Flash	**CP3:** Communication phase 3
	(green)	On	**CP4:** Communication phase 4
	(off)	Off	**NRT:** Non Real-time Mode
ERR Name in the device drawing: **COM 1**	**Duo LED red/green**		
	(red)	Blinking	Error in the configuration database.
	(red)	Flickering	Boot-up was stopped due to an error.
	(red)	Double Flickering	Slave is missing.
	(red)	Single Flickering	Channel Init was executed at the Master.
	(red)	Quadruple Flash	No Master license present in the device
	(red)	Triple Flash	DPM Watchdog has expired.
	(red)	Double Flash	Internal Stop of the bus cycle
	(red)	Single Flash	Bus Sync Error Threshold
	(off)	Off	No error
L/A/RJ45 Ch0 & Ch1	**LED green**		
	(green)	On	Link: A connection to the Ethernet exists
	(green)	Flickering	Activity: The device sends/receives Ethernet frames
	(off)	Off	The device has no connection to the Ethernet
RJ45 Ch0 & Ch1	**LED yellow**		
	-	-	This LED is not used.

Table 41: LEDs sercos Master

LED State Definition for sercos Master for STA and ERR LEDs

Indicator state	Definition
Off	The indicator is constantly off.
Blinking	The indicator turns on and off with a frequency of 2,5 Hz: on for 200 ms, followed by off for 200 ms.
Single Flickering	The indicator turns on and off with a frequency of approximately 10 Hz: on for approximately 50 ms, followed by off for 50 ms.
Double Flickering	The indicator turns on / off / on each for approximately 50 ms, followed by off for 500 ms.
Flickering	The indicator turns on and off once: on for approximately 50 ms, followed by off for 50 ms.
Single Flash	The indicator shows one short flash (200 ms) followed by a long off phase (1,000 ms).
Double Flash	The indicator shows a sequence of two short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).
Triple Flash	The indicator shows a sequence of three short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).
Quadruple Flash	The indicator shows a sequence of four short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).

Table 42: LED State Definition for sercos Master for the STA and ERR LEDs

© Hilscher, 2008-2014

8.14 sercos Slave

The subsequent table describes the meaning of the LEDs for the PC card cifX Real-Time Ethernet Slave when the firmware of the sercos Slave protocol is loaded to the device.

LED	Color	State	Meaning
S3 Name in the device drawing: **COM 0**	**Duo LED red/green/orange** (orange = red/green simultaneously)		
	(off)	Off	**NRT-Mode**: No sercos Communication
	(green)	On	**CP4**: Communication phase 4, Normal operation, no error
	(green)	Flashing (2 Hz)	**Loopback**: The network state has changed from „fast-forward“ to „loopback“.
	(green/ orange)	Flashing (1 x green / 3 s)	**CP1**: Communication phase 1: Flashing green for 250 ms, then orange on for 2 second and 750 ms
		Flashing (2 x green / 3 s)	**CP2**: Communication phase 2: Flashing green / orange / green, each for 250 ms, then orange on for 2 seconds and 250 ms
		Flashing (3 x green / 3 s)	**CP3**: Communication phase 3: Flashing green / orange / green / orange / green, each for 250 ms, then orange on for 1 second and 750 ms
	(orange/ green)	Flashing (2 Hz)	**HP0**: Hot-plug mode (not yet implemented): Flashing orange /green permanently at 2 Hz.
		Flashing (1 x orange / 3 s)	**HP2**: Hot-plug mode (not yet implemented): Flashing orange for 250 ms, then green on for 2 second an 750 ms
		Flashing (2 x orange / 3 s)	**HP3**: Hot-plug mode (not yet implemented): Flashing orange / green / orange, each for 250 ms, then green on for 2 seconds and 250 ms
	(orange)	On	**CP0**: Communication phase 0
	(orange)	Flashing (2 Hz)	**Identification**: Corresponds to C-DEV.Bit 15 in the Slave’s Device Control indicating remote address allocation or configuration errors between Master and Slaves (for details refer to sercos Slave V3 Protocol API Manual).
	(green/ red)	Flashing (2 Hz), *The LED flashes at least for 2 seconds from green to red.*	**MST losses ≥ (S-0-1003/2)**: Depends on IDN S-0-1003 (for details refer to sercos Slave Protocol API manual). Corresponds to S-DEV.Bit 15 in the Device Status indicating a communication warning (Master SYNC telegrams have not been received)
	(red /orange)	Flashing (2 Hz)	**Application error (C1D)**: See GDP & FSP Status codes class error. See sercos Slave V3 Protocol API Manual.
	(red)	Flashing (2 Hz)	**Watchdog error**: Application is not running (not yet implemented)
	(red)	On	**Communication Error (C1D)**: Error detected according to sercos Class 1 Diagnosis, see SCP Status codes class error. See sercos Slave V3 Protocol API Manual.
Name in the device drawing: **COM 1**	**Duo LED red/green**		
	-	-	This LED is not used.
L/A/RJ45 Ch0 & Ch1	**LED green**		
	(green)	On	Link: A connection to the Ethernet exists
	(green)	Flickering	Activity: The device sends/receives Ethernet frames
	(off)	Off	The device has no connection to the Ethernet
RJ45 Ch0 & Ch1	**LED yellow**		
	-	-	This LED is not used.

Table 43: LEDs sercos Slave

© Hilscher, 2008-2014

LED State Definition for sercos Slave for the S3 LED

Indicator state	Definition
On	The indicator is constantly on.
Off	The indicator is constantly off.
Flashing (2 Hz)	The indicator turns on and off with a frequency of 2 Hz: first color for appr. 250 ms, followed by the second color for appr. 250 ms.
Flickering	The indicator turns on and off with a frequency of approximately 10 Hz: on for approximately 50 ms, followed by off for 50 ms.

Table 44: LED State Definition for sercos Slave for the S3 LED

8.15 VARAN Client (Slave)

The subsequent table describes the meaning of the LEDs for the PC card cifX Real-Time Ethernet Slave when the firmware of the VARAN Client (Slave) protocol is loaded to the device.

LED	Color	State	Meaning
RUN Name in the device drawing: **COM 0**	**Duo LED red/green**		
	(green)	Blinking	Configured and communication is inactive.
	(green)	On	Configured and communication is active.
	(off)	Off	Not configured.
ERR Name in the device drawing: **COM 1**	**Duo LED red/green**		
	(off)	Off	Configured.
	(red)	Blinking	Not configured.
	(red)	On	Communication error occurred.
LINK RJ45 Ch0 & Ch1	**LED green**		
	(green)	On	A connection to the Ethernet exists
	(off)	Off	The device has no connection to the Ethernet
ACT RJ45 Ch0 & Ch1	**LED yellow**		
	(yellow)	Flashing	The device sends/receives Ethernet frames

Table 45: LEDs VARAN Client

LED State Definition for VARAN Client for the RUN and ERR LEDs

Indicator state	Definition
On	The indicator is constantly on.
Off	The indicator is constantly off.
Blinking	The indicator turns on and off with a frequency of 5 Hz: on for 100 ms, followed by off for 100 ms.

Table 46: LED State Definition for VARAN Client for the RUN and ERR LEDs

© Hilscher, 2008-2014

8.16 PROFIBUS DP Master

8.16.1 1 Communication Status LED

The subsequent table describes the meaning of the LEDs for the PC card cifX PROFIBUS DP Master when the firmware of the PROFIBUS DP Master protocol is loaded to the device.

LED	Color	State	Meaning
cifX with 1 Communication Status LED (current Hardware Revision)			
COM	**Duo LED red/green**		
	(green)	Flashing acyclic	No configuration or stack error
	(green)	Flashing cyclic	Profibus is configured, but bus communication is not yet released from the application
	(green)	On	Communication to all Slaves is established
	(red)	Flashing cyclic	Communication to at least one Slave is disconnected
	(red)	On	Communication to one/all Slaves is disconnected or annother serious error has occured. Redundant Mode: The active Master was not found.

Table 47: LEDs PROFIBUS DP Master – 1 Communication Status LED (current Hardware Revision)

8.16.2 2 Communication Status LEDs

The subsequent table describes the meaning of the LEDs for the PC card cifX PROFIBUS DP Master when the firmware of the PROFIBUS DP Master protocol is loaded to the device.

LED	Color	State	Meaning
cifX with 2 Communication Status LEDs (AIFX-DP is connected or for prior Hardware Revisions)			
STA	**LED green**		
	(green)	Flashing acyclic	No configuration or stack error
	(green)	Flashing cyclic	Profibus is configured, but bus communication is not yet released from the application
	(green)	On	Communication to all Slaves is established
ERR	**LED red**		
	(red)	Flashing cyclic	Communication to at least one Slave is disconnected
	(red)	Static on	Communication to one/all Slaves is disconnected or annother serious error has occured. Redundant Mode: The active Master was not found.

Table 48: LEDs PROFIBUS DP Master – 2 Communication Status LEDs (AIFX-DP connected or prior Hardware Revision)

© Hilscher, 2008-2014

8.17 PROFIBUS DP Slave

8.17.1 1 Communication Status LED

The subsequent table describes the meaning of the LEDs for the PC card cifX PROFIBUS DP Slave when the firmware of the PROFIBUS DP Slave protocol is loaded to the device.

LED	Color	State	Meaning
cifX with 1 Communication Status LED (current Hardware Revision)			
COM	**Duo LED red/green**		
	(green)	On	RUN, cyclic communication
	(red)	On	Wrong configuration at PROFIBUS-DPside.
	(red)	Flashing cyclic	STOP, no communication, connection error
	(red)	Flashing acyclic	not configured

Table 49: LEDs PROFIBUS DP Slave – 1 Communication Status LED (current Hardware Revision)

8.17.2 2 Communication Status LEDs

The subsequent table describes the meaning of the LEDs for the PC card cifX PROFIBUS DP Slave when the firmware of the PROFIBUS DP Slave protocol is loaded to the device.

LED	Color	State	Meaning
cifX with 2 Communication Status LEDs (AIFX-DP is connected or for prior Hardware Revisions)			
STA	**LED red**		
	(green)	On	RUN, cyclic communication
ERR	**LED red**		
	(red)	On	Wrong configuration at PROFIBUS-DPside.
	(red)	Flashing cyclic	STOP, no communication, connection error
	(red)	Flashing acyclic	not configured

Table 50: LEDs PROFIBUS DP Slave – 2 Communication Status LEDs (AIFX-DP connected or prior Hardware Revision)

© Hilscher, 2008-2014

8.18 PROFIBUS MPI Device

8.18.1 1 Communication Status LED

The subsequent table describes the meaning of the LEDs for the PC Card cifX PROFIBUS MPI device when the firmware of the PROFIBUS MPI protocol is loaded to the device.

LED	Color	State	Meaning
cifX with 1 Communication Status LED			
COM	**LED green**		
	(green)	On	**Status** The device currently holds the PROFIBUS token and is able to transfer telegrams of data.
	(green)	Blinking (regularly) 5 Hz	**Status** The device is configured to be a part of the PROFIBUS ring, but it must share the PROFIBUS token with other PROFIBUS-Master devices present on the PROFIBUS ring.
	(green)	Blinking (regularly) 0.5 Hz	**Status** Automatic baudrate detection is running
	(off)	Off	**Status** The device has not been integrated into the PROFIBUS ring, i.e. it has not been configured correctly or has a wrong configuration or has not received the PROFIBUS token.

Table 51: LEDs PROFIBUS MPI – 1 Communication Status LED

8.18.2 2 Communication Status LEDs

The subsequent table describes the meaning of the LEDs for the PC Card cifX PROFIBUS MPI device when the firmware of the PROFIBUS MPI protocol is loaded to the device.

LED	Color	State	Meaning
cifX with 2 Communication Status LEDs (AIFX-DP is connected)			
STA	**LED green**		
	(green)	On	**Status** The device currently holds the PROFIBUS token and is able to transfer telegrams of data.
	(green)	Blinking (regularly) 5 Hz	**Status** The device is configured to be a part of the PROFIBUS ring, but it must share the PROFIBUS token with other PROFIBUS-Master devices present on the PROFIBUS ring.
	(green)	Blinking (regularly) 0.5 Hz	**Status** Automatic baudrate detection is running
	(off)	Off	**Status** The device has not been integrated into the PROFIBUS ring, i.e. it has not been configured correctly or has a wrong configuration or has not received the PROFIBUS token.
ERR	**LED red**		
	-	-	This LED is not used.

Table 52: LEDs PROFIBUS MPI – 2 Communication Status LEDs (AIFX-DP connected)

© Hilscher, 2008-2014

8.19 CANopen Master

8.19.1 1 Communication Status LED

The subsequent table describes the meaning of the LEDs for the PC card cifX CANopen Master when the firmware of the CANopen Master protocol is loaded to the device.

LED	Color	State	Meaning
cifX with 1 Communication Status LED (current Hardware Revision)			
CAN	**Duo LED red/green**		
	(off)	Off	**RESET:** The device is executing a reset
	(green)	Single flash	**STOPPED:** The device is in STOPPED state
	(green)	Blinking	**PREOPERATIONAL:** The device is in the PREOPERATIONAL state
	(green)	On	**OPERATIONAL:** The device is in the OPERATIONAL state
	(red)	Single flash	**Warning Limit reached:** At least one of the error counters of the CAN controller has reached or exceeded the warning level (too many error frames).
	(red)	Double flash	**Error Control Event:** A guard event (NMT Slave or NMT-master) or a heartbeat event (Heartbeat consumer) has occurred.
	(red)	On	**Bus Off:** The CAN controller is bus off

Table 53: LEDs CANopen Master – 1 Communication Status LED (current Hardware Revision)

LED State Definition for CANopen Master for the CAN LED

Indicator state	Definition
On	The indicator is constantly on.
Off	The indicator is constantly off.
Flickering	The indicator turns on and off with a frequency of 10 Hz: on for 50 ms, followed by off for 50 ms.
Blinking	The indicator turns on and off with a frequency of 2,5 Hz: on for 200 ms, followed by off for 200 ms.
Single Flash	The indicator shows one short flash (200 ms) followed by a long off phase (1,000 ms).
Double Flash	The indicator shows a sequence of two short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).

Table 54: LED State Definition for CANopen Master for the CAN LED

© Hilscher, 2008-2014

8.19.2 2 Communication Status LEDs

The subsequent table describes the meaning of the LEDs for the PC card cifX CANopen Master when the firmware of the CANopen Master protocol is loaded to the device.

LED	Color	State	Meaning
cifX with 2 Communication Status LEDs (AIFX-CO is connected or for prior Hardware Revisions)			
RUN	**LED green**		
	(off)	Off	**RESET:** The device is executing a reset
	(green)	Single flash	**STOPPED:** The device is in STOPPED state
	(green)	Blinking	**PREOPERATIONAL:** The device is in the PREOPERATIONAL state
	(green)	On	**OPERATIONAL:** The device is in the OPERATIONAL state
ERR	**LED red**		
	(red)	Single flash	**Warning Limit reached:** At least one of the error counters of the CAN controller has reached or exceeded the warning level (too many error frames).
	(red)	Double flash	**Error Control Event:** A guard event (NMT Slave or NMT-master) or a heartbeat event (Heartbeat consumer) has occurred.
	(red)	On	**Bus Off:** The CAN controller is bus off

Table 55: LEDs CANopen Master – 2 Communication Status LEDs (AIFX-CO connected or prior Hardware Revision)

LED State Definition for CANopen Master for the CAN or RUN/ERR LEDs

Indicator state	Definition
On	The indicator is constantly on.
Off	The indicator is constantly off.
Flickering	The indicator turns on and off with a frequency of 10 Hz: on for 50 ms, followed by off for 50 ms.
Blinking	The indicator turns on and off with a frequency of 2,5 Hz: on for 200 ms, followed by off for 200 ms.
Single Flash	The indicator shows one short flash (200 ms) followed by a long off phase (1,000 ms).
Double Flash	The indicator shows a sequence of two short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).

Table 56: LED State Definition for CANopen Master for the CAN or RUN/ERR LEDs

© Hilscher, 2008-2014

8.20 CANopen Slave

8.20.1 1 Communication Status LED

The subsequent table describes the meaning of the LEDs for the PC card cifX CANopen Slave when the firmware of the CANopen Slave protocol is loaded to the device.

LED	Color	State	Meaning
cifX with 1 Communication Status LED (current Hardware Revision)			
CAN	**Duo LED red/green**		
	(off)	Off	**RESET:** The device is executing a reset
	(green)	Single flash	**STOPPED:** The device is in STOPPED state
	(green)	Blinking	**PREOPERATIONAL:** The device is in the PREOPERATIONAL state
	(green)	On	**OPERATIONAL:** The device is in the OPERATIONAL state
	(red/green)	Flickering (alternatively red / green)	**Auto Baud Rate Detection active:** The Device is in the Auto Baud Rate Detection mode
	(red)	Single flash	**Warning Limit reached:** At least one of the error counters of the CAN controller has reached or exceeded the warning level (too many error frames).
	(red)	Double flash	**Error Control Event:** A guard event (NMT Slave or NMT-master) or a heartbeat event (Heartbeat consumer) has occurred.
	(red)	On	**Bus Off:** The CAN controller is bus off

Table 57: LEDs CANopen Slave – 1 Communication Status LED (current Hardware Revision)

LED State Definition for CANopen Slave for the CAN LED

Indicator state	Definition
On	The indicator is constantly on.
Off	The indicator is constantly off.
Flickering	The indicator turns on and off with a frequency of 10 Hz: on for 50 ms, followed by off for 50 ms.
Blinking	The indicator turns on and off with a frequency of 2,5 Hz: on for 200 ms, followed by off for 200 ms.
Single Flash	The indicator shows one short flash (200 ms) followed by a long off phase (1,000 ms).
Double Flash	The indicator shows a sequence of two short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).

Table 58: LED State Definition for CANopen Slave for the CAN LED

© Hilscher, 2008-2014

8.20.2 2 Communication Status LEDs

The subsequent table describes the meaning of the LEDs for the PC card cifX CANopen Slave when the firmware of the CANopen Slave protocol is loaded to the device.

LED	Color	State	Meaning
cifX with 2 Communication Status LEDs (AIFX-CO is connected or for prior Hardware Revisions)			
RUN	**LED green**		
	(off)	Off	**RESET:** The device is executing a reset
	(green)	Single flash	**STOPPED:** The device is in STOPPED state
	(green)	Blinking	**PREOPERATIONAL:** The device is in the PREOPERATIONAL state
	(green)	On	**OPERATIONAL:** The device is in the OPERATIONAL state
	(green)	Flickering (alternatively with ERR LED)	**Auto Baud Rate Detection active:** The Device is in the Auto Baud Rate Detection mode
ERR	**LED red**		
	(red)	Single flash	**Warning Limit reached:** At least one of the error counters of the CAN controller has reached or exceeded the warning level (too many error frames).
	(red)	Double flash	**Error Control Event:** A guard event (NMT Slave or NMT-master) or a heartbeat event (Heartbeat consumer) has occurred.
	(red)	On	**Bus Off:** The CAN controller is bus off
	(red)	Flickering (alternatively with RUN LED)	**Auto Baud Rate Detection active:** The Device is in the Auto Baud Rate Detection mode

Table 59: LEDs CANopen Slave – 2 Communication Status LEDs (AIFX-CO connected or prior Hardware Revision)

LED State Definition for CANopen Slave for the CAN or RUN/ERR LEDs

Indicator state	Definition
On	The indicator is constantly on.
Off	The indicator is constantly off.
Flickering	The indicator turns on and off with a frequency of 10 Hz: on for 50 ms, followed by off for 50 ms.
Blinking	The indicator turns on and off with a frequency of 2,5 Hz: on for 200 ms, followed by off for 200 ms.
Single Flash	The indicator shows one short flash (200 ms) followed by a long off phase (1,000 ms).
Double Flash	The indicator shows a sequence of two short flashes (each 200 ms), separated by a short off phase (200 ms). The sequence is finished by a long off phase (1,000 ms).

Table 60: LED State Definition for CANopen Slave for the CAN or RUN/ERR LEDs

© Hilscher, 2008-2014

8.21 DeviceNet Master

The subsequent table describes the meaning of the LEDs for the PC card cifX DeviceNet Master when the firmware of the DeviceNet Master protocol is loaded to the device.

LED	Color	State	Meaning
MNS	**Duo LED red/green**		
	(green)	On	**Device Operational AND On-line, Connected** Device is online and has established all connections with all Slaves.
	(green)	Flashing (1 Hz)	**Device Operational AND On-line** Device is online and has established no connection in the established state. - Configuration missing, incomplete or incorrect.
	(green/red/off)	Flashing Green/Red/Off	**Selftest after power on:** Green on for 250 ms, then red on for 250 ms, then off.
	(red)	Flashing (1 Hz)	**Minor Fault and/or Connection Time-Out** Device is online and has established one or more connections in the established state. It has data exchange with at least one of the configured Slaves. Minor or recoverable fault: No data exchange with one of the configured Slaves. One or more Slaves are not connected. Connection timeout
	(red)	On	**Critical Fault orCritical Link Failure** Critical connection failure; device has detected a network error: duplicate MAC-ID or severe error in CAN network (CAN-bus off).
	(off)	Off	**Device is not powered** - The device may not be powered. **Device is not on-line and/or No Network Power** - The device has not completed the Dup_MAC_ID test yet. - The device is powered, but the network power is missing.

Table 61: LEDs DeviceNet Master

LED State Definition for DeviceNet Master for the MNS LED

Indicator state	Definition
On	The indicator is constantly on.
Off	The indicator is constantly off.
Flashing (1 Hz) green	The indicator turns on and off with a frequency of appr. 1 Hz: on for appr. 500 ms, followed by off for appr. 500 ms.
Flashing (1 Hz) red	The indicator turns on and off with a frequency of appr. 1 Hz: on for appr. 500 ms, followed by off for appr. 500 ms.

Table 62: LED State Definition for DeviceNet Master for the MNS LED

© Hilscher, 2008-2014

8.22 DeviceNet Slave

The subsequent table describes the meaning of the LEDs for the PC card cifX DeviceNet Slave when the firmware of the DeviceNet Master protocol is loaded to the device.

LED	Color	State	Meaning
MNS	**Duo LED red/green**		
	(green)	On	**Device Operational AND On-line, Connected** Device is online and has established all connections with all Slaves.
	(green)	Flashing (1 Hz)	**Device Operational AND On-line** Device is online and has established no connection in the established state. - Configuration missing, incomplete or incorrect.
	(green/red/off)	Flashing Green/Red/Off	**Selftest after power on:** Green on for 250 ms, then red on for 250 ms, then off.
	(red)	Flashing (1 Hz)	**Minor Fault and/or Connection Time-Out** Device is online and has established one or more connections in the established state. It has data exchange with at least one of the configured Slaves. Minor or recoverable fault: No data exchange with one of the configured Slaves. One or more Slaves are not connected. Connection timeout
	(red)	On	**Critical Fault orCritical Link Failure** Critical connection failure; device has detected a network error: duplicate MAC-ID or severe error in CAN network (CAN-bus off).
	(off)	Off	**Device is not powered** - The device may not be powered. **Device is not on-line and/or No Network Power** - The device has not completed the Dup_MAC_ID test yet. - The device is powered, but the network power is missing.

Table 63: LEDs DeviceNet Slave

LED State Definition for DeviceNet Slave for the MNS LED

Indicator state	Definition
On	The indicator is constantly on.
Off	The indicator is constantly off.
Flashing (1 Hz) green	The indicator turns on and off with a frequency of appr. 1 Hz: on for appr. 500 ms, followed by off for appr. 500 ms.
Flashing (1 Hz) red	The indicator turns on and off with a frequency of appr. 1 Hz: on for appr. 500 ms, followed by off for appr. 500 ms.

Table 64: LED State Definition for DeviceNet Slave for the MNS LED

© Hilscher, 2008-2014

8.23 CC-Link Slave

The subsequent table describes the meaning of the LEDs for the PC card cifX CC-Link Slave when the firmware of the CC-Link Slave protocol is loaded to the device.

LED	Color	State	Meaning
L RUN	**LED green**		
	(off)	Off	1. Before participating in the network 2. Unable to detect carrier 3. Timeout 4. Resetting hardware
	(green)	On	Receive both refresh and polling signals or just the refresh signal normally, after participating in the network.
L ERR	**LED green**		
	(off)	Off	1. Normal communication 2. Resetting hardware
	(red)	Blinking	The switch setting has been changed from the setting at the reset cancellation (blinks for 0.4 sec.).
	(red)	On	1. CRC error 2. Address parameter error (0, 65 or greater is set including the number of occupied stations) 3. Baud rate switch setting error during cancellation of reset (5 or greater)

Table 65: LEDs CC-Link Slave

© Hilscher, 2008-2014

9 Device Connections and Switches

9.1 Ethernet Interface

For the Ethernet interface use RJ45 plugs and twisted pair cable of category 5 (CAT5) or higher, which consists of 4 twisted cores and has a maximum transmission rate of 100 MBit/s (CAT5).

9.1.1 Ethernet Pin Assignment at the RJ45 Socket

Note: The device supports the **Auto Crossover** function. Due to this fact RX and TX can be switched. The following figure shows the RJ45 standard pin assignment.



Figure 35: Ethernet Pin Assignment at the RJ45 Socket for cifX or AIFX

Pin	Signal	Meaning
1	TX+	Transmit Data +
2	TX–	Transmit Data –
3	RX+	Receive Data +
4	Term 1	Connected to each other and terminated to PE through RC circuit*
5	Term 1	
6	RX–	Receive Data –
7	Term 2	Connected to each other and terminated to PE through RC circuit*
8	Term 2	
		* Bob Smith Termination

Table 66: Ethernet Pin Assignment at the RJ45 Socket for cifX or AIFX

Further Notes:
(1) The RJ45 socket is only for use in LAN, not for telecommunication circuits.
(2) With loaded EtherCAT Master firmware only the RJ45 channel 0 can be used, channel 1 is deactivated. Beginning with the EtherCAT Master firmware version 3 channel 1 can be reactivated if redundancy is activated. For the Open Modbus/TCP firmware with V2.3.4.0 and higher both RJ45 RJ45channels can be used.

© Hilscher, 2008-2014

9.1.2 Ethernet Connection Data

Medium	2 x 2 Twisted-Pair cupric cable, CAT5 (100 MBit/s)
Length of cable	Typ. 100 m
Transmission rate	10 MBit/s/100 MBit/s

Table 67: Ethernet Connection Data

9.1.3 Use of Hubs and Switches

For the corresponding communication systems, the use of hubs and/or switches is either forbidden or allowed. The following table shows the acceptable use of hubs and switches by each communication system:

Communication System	Hub	Switch
EtherCAT	forbidden	only allowed between EtherCAT Master and first EtherCAT Slave (100 MBit/s, Full Duplex)
EtherNet/IP	allowed	allowed (10 MBit/s/100 MBit/s, Full or Half Duplex, Auto-Negotiation)
Open Modbus/TCP	allowed	allowed (10 MBit/s/100 MBit/s, Full or Half Duplex, Auto-Negotiation)
POWELINK	allowed	forbidden
PROFINET IO	forbidden	Only allowed if the switch supports ‚Priority Tagging' and LLDP (100 MBit/s, Full Duplex)
sercos	forbidden	forbidden
VARAN*	forbidden	forbidden

Table 68: Use of Hubs and Switches

*Instead of hubs and switches VARAN uses splitter. [3]

© Hilscher, 2008-2014

9.2 PROFIBUS Interface

Isolated RS-485 interface:



Figure 36: PROFIBUS Interface (DSub female connector, 9 pin), X400

Connection with DSub female connector	Signal	Meaning
3	RxD/TxD-P	Receive/Send Data-P respectively connection B plug
5	DGND	Reference potential
6	VP	Positive supply voltage
8	RxD/TxD-N	Receive/Send Data-N respectively connection A plug

Table 69: PROFIBUS Interface, X400

9.3 CANopen Interface

Isolated ISO 11898 interface:



Figure 37: CANopen Interface (DSub male connector, 9 pin), X400

Connection with DSub male connector	Signal	Description
2	CAN_L	CAN_Low Bus Line
3	CAN_GND	CAN Ground
7	CAN_H	CAN High Bus Line
1, 4, 5, 6, 8, 9		**Do not connect!**

Table 70: CANopen Interface, X400

© Hilscher, 2008-2014

9.4 DeviceNet Interface

Isolated ISO 11898 interface:



Figure 38: DeviceNet Interface (CombiCon male Connector, 5 pin), X360

Connection with CombiCon male connector	Signal	Color	Description
1	V-	Black	Reference potential DeviceNet supply voltage
2	CAN_L	Blue	CAN Low-Signal
3	Drain		Shield
4	CAN_H	White	CAN High-Signal
5	V+	Red	+24 V DeviceNet supply voltage

Table 71: DeviceNet Interface, X360

9.5 CC-Link Interface

Isolated RS-485 interface:



Figure 39: CC-Link Interface (CombiCon male Connector, 5 pin)

Connection with Screw terminal Connector	Signal	Meaning
1	DA	Data A
2	DB	Data B
3	DG	Data Ground
4	SLD	Shield
5	FG	Field Ground

Table 72: CC-Link Interface

© Hilscher, 2008-2014

9.6 Mini-B USB Connector (5 Pin)

The Mini-B USB connector is provided for the following PC cards cifX:
CIFX 104-RE, CIFX 104-DP, CIFX 104-CO, CIFX 104-DN,
CIFX 104-RE-R, CIFX 104-DP-R, CIFX 104-CO-R, CIFX 104-DN-R

In addition a Mini-B USB connector will be available for the following PC cards cifX if the AIFX-DIAG is connected to the PC card cifX:
CIFX 104-RE\F*, CIFX 104-DP\F, CIFX 104-CO\F, CIFX 104-DN\F,
CIFX 104-CC\F,
CIFX 104-RE-R\F*, CIFX 104-DP-R\F, CIFX 104-CO-R\F, CIFX 104-DN-R\F

Note! *From the hardware revision 5 of the PC cards CIFX 104-RE\F and CIFX 104-RE-R\F if the diagnostic **AIFX-DIAG** assembly interface is connected, the **Mini-B USB** connector on the AIFX-DIAG can be used.



Figure 40: Mini-B USB Connector (5 Pin)

Pin	Name	Description
1	USB_EXT	USB Bus Power (+5 V dc, supplied externally)
2	D-	Data -
3	D+	Data +
4	ID	Not connected
5	GND	Ground

Table 73: Pin Assignment Mini-B USB Connector

9.7 Rotary Switch Device Address

The **Rotary Switch Device Address** at the PC cards
CIFX 104-RE, CIFX 104-RE-R, CIFX 104-RE\F, CIFX 104-RE-R\F,
CIFX 104-DP, CIFX 104-DP-R, CIFX 104-DP\F, CIFX 104-DP-R\F,
CIFX 104-CO, CIFX 104-CO-R, CIFX 104-CO\F, CIFX 104-CO-R\F,
CIFX 104-DN, CIFX 104-DN-R, CIFX 104-DN\F, CIFX 104-DN-R\F,
CIFX 104-CC\F
currently is unassigned. The Slave address setting is done via the configuration software.

© Hilscher, 2008-2014

9.8 Cable Connector

9.8.1 Pin Assignment for Cable Connector Ethernet

Only for CIFX 104-RE\F (X304), CIFX 104-RE-R\F (X4).

Pin Assignment for Cable Connector Ethernet X4 or X304 – Cable 20 pin Ethernet and Status LEDs:

Pin	Signal
1	GND
2	+3V3 Analog
3	STA0_green (*RE LED COM 0*)
4	STA0_red (*RE LED COM 0*)
5	XM0_TX
6	STA1_green (*RE LED COM 1*)
7	CH0_LINKn
8	CH0_ACTIVITY
9	AIFINIT
10	STA1_red (*RE LED COM 1*)
11	CH0_TXP
12	CH0_TXN
13	CH0_RXP
14	CH0_RXN
15	CH1_TXP
16	CH1_TXN
17	CH1_RXP
18	CH1_RXN
19	CH1_LINKn
20	CH1_ACTIVITY

Table 74: Pin Assignment for Cable Connector Ethernet X4 or X304

Cable Connector Ethernet:



Figure 41: 1x20 Pins for CIFX 104-RE\F, CIFX 104-RE-R\F

© Hilscher, 2008-2014

9.8.2 Pin Assignment for Cable Connector Fieldbus X3, X304, X4

Only for
CIFX 104-DP\F, CIFX 104-CO\F, CIFX 104-DN\F, CIFX 104-CC\F: (X304);
CIFX 104-DP-R\F, CIFX 104-CO-R\F, CIFX 104-DN-R\F: (X4).

Pin Assignment for Cable connector Fieldbus X3, X304 or X4,
Cable 10 pin Fieldbus:

Pin	Signal
1	GND
2	+3V3 Analog
3	I2C_CLK/PIO 4
4	I2C_DATA/ PIO 5
5	XMAC2_TX
6	XMAC2_RX
7	XMAC2_IO0
8	XMAC2_IO1
9	/RSTOUT
10	(not used)

Table 75: Pin Assignment for Cable connector Fieldbus X3, X304 or X4

9.8.3 Pin Assignment for Cable Connector DIAG

Only for CIFX 104-RE\F (X303), CIFX 104-RE-R\F (X3),
CIFX 104-DP\F, CIFX 104-CO\F, CIFX 104-DN\F, CIFX 104-CC\F: (X303)

Pin Assignment for Cable connector DIAG X3 or X303 -
Cable 12 pin USB + Status LEDs

Pin	Signal (Feldbus)	Signal (Ethernet)
1	GND	GND
2	+3V3	+3V3
3	STA2 (*FB LED COM 0*)	STA2 (*not used*)
4	STA3 (*FB LED COM 1*)	STA3 (*not used*)
5	USB_POS	USB_POS
6	USB_NEG	USB_NEG
7	RDYn	RDYn
8	RUNn	RUNn
9	STA0_green (*not used*)	STA0_green (*RE LED COM 0*)
10	STA0_red (*not used*)	STA0_red (*RE LED COM 0*)
11	STA1_green (*not used*)	STA1_green (*RE LED COM 1*)
12	STA1_red (*not used*)	STA1_red (*RE LED COM 1*)

Table 76: Pin Assignment for Cable connector DIAG X3 or X303

© Hilscher, 2008-2014

9.9 SYNC Connector (Pin-Assignment, Hardware/Firmware)

9.9.1 Pin Assignment SYNC Connector, X51 (CIFX 80 90 104C)

Only for CIFX 104-RE, CIFX 104-RE-R, CIFX 104-RE\F, CIFX 104-RE-R\F.

Pin	Signal
1	GND
2	IO_SYNC0
3	IO_SYNC1

Table 77: Pin Assignment for SYNC Connector, X51

9.9.2 Items on Hardware

Item	Explanation
SYNC Signal	3.3 V (LVTTL), maximum load 6 mA
Connector	SYNC connector, X51 (for the PC cards cifX, as indicated under section *Pin Assignment SYNC Connector, X51* on page 94.) Female connector, 3 pin, pitch spacing 1.25 mm (for example, the type Molex series 51021) and female crimp contacts in design (e. g. type Molex series 50079/50058)
Max. Cable Length	Recommendation: Max. 50 mm **Note**: Take EMC into consideration for the cable laying

Table 78: SYNC Connector: SYNC Signal, Connector, Max. Cable Length

9.9.3 Items on Firmware

The firmware determines the input signal or output signal. The following table shows the meaning of the SYNC signals for each protocol.

Protocol	Signal IO_SYNC0 Input/Output	Signal IO_SYNC1 Input/Output	From Firmware Version	Remarks
EtherCAT Slave	SYNC 0 Output	SYNC 1 Output	-	Configurable
sercos Master	External trigger to start bus cycle Input Rising edge	-	2.0.8.0	-
sercos Slave	CON_CLK Output	DIV_CLK Output	3.0.10.0	Configurable

Table 79: Meaning of the SYNC Signals for each Protocol

© Hilscher, 2008-2014

9.10 Pin Assignment at the PC/104 Bus

9.10.1 Overview

For the PC cards cifX *PC/104* the table below gives an overview about the pin assignment at the PC/104 bus.

cifX	Hardware Revision	PC/104 Bus [Pins]	Pin Assignment at the PC/104 Bus		PC/104 Specification
			according to the standard	Compare Section, page	
CIFX 104-RE CIFX 104-RE-R CIFX 104-RE\F CIFX 104-RE-R\F CIFX 104-DP CIFX 104-DP-R CIFX 104-DP\F CIFX 104-DP-R\F CIFX 104-CO CIFX 104-CO-R CIFX 104-CO\F CIFX 104-CO-R\F CIFX 104-DN CIFX 104-DN-R CIFX 104-DN\F CIFX 104-DN-R\F CIFX 104-CC\F	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	104	*yes*	*Pin Assignment for PC/104 Bus*, 96	[bus spec 8]

Table 80: Pin Assignment at the PC/104 Bus

9.10.2 Reference PC/104 Specification

No.	Specification	Revision	Version	De	www
[bus spec 8]	PC/104 Specification		2.6	October 13, 2008	pcisig.com, pc104.org

Table 81: Reference PC/104 Specification

© Hilscher, 2008-2014

9.10.3 Pin Assignment for PC/104 Bus

Only for:
CIFX 104-RE, CIFX 104-RE-R ,
CIFX 104-RE\F, CIFX 104-RE-R\F

The used control signals of the PC/104 bus are given in the tables below.

Pin Assignment for PC/104-Bus, X1

Pin (X1)	A	B
1		GND
2	SD7	RESET
3	SD6	+5V
4	SD5	IRQ9
5	SD4	
6	SD3	
7	SD2	
8	SD1	
9	SD0	
10	IOCHRDY	GND [2]
11	AEN	SMEMW
12	SA19	SMEMR
13	SA18	
14	SA17	
15	SA16	
16	SA15	
17	SA14	
18	SA13	
19	SA12	
20	SA11	
21	SA10	IRQ7
22	SA9	IRQ6
23	SA8	IRQ5
24	SA7	IRQ4
25	SA6	IRQ3
26	SA5	
27	SA4	
28	SA3	
29	SA2	+5V
30	SA1	
31	SA0	GND
32	GND	GND

Table 82: Pin Assignment for PC/104-Bus, X1 (Control Signals used on the 8 Bit Connector)

[2] Differs from the standard [bus spec 9, page B-2].

© Hilscher, 2008-2014

Important: Avoid dual-port memory access errors

It is mandatory that the host CPU always uses the IOCHNRDY (pin A10) signal, otherwise these results in wrong data read from the dual-port memory or dual-port memory write accesses are being ignored.

- The maximum value for accesses can not be specified.

- For maximum performance, the IOCHNRDY signal must always be evaluated by the host CPU.

- If you use a host CPU that can not use the IOCHNRDY (A10) signal, then contact our technical support.

Pin Assignment for PC/104-Bus, X2

Pin (X2)	C	D
0	GND	GND
1	SBHE	MEMCS16
2		
3		IRQ10
4		IRQ11
5		IRQ12
6		IRQ15
7		IRQ14
8		
9		
10		
11	SD8	
12	SD9	
13	SD10	
14	SD11	
15	SD12	
16	SD13	+5V
17	SD14	
18	SD15	GND
19		GND

Table 83: Pin Assignment for PC/104-Bus, X2 (Used Control Signals on the Expansion Connector)

The pin assignment described in *Table 82* and *Table 83* originates from the standard [bus spec 8, page B-2] (refer to section *Reference PC/104 Specification* on page 95).

© Hilscher, 2008-2014

10 Technical Data

10.1 Technical Data PC Cards cifX

Note: All technical data are temporarily and can be altered without notice.

10.1.1 CIFX 104-RE, CIFX 104-RE-R

CIFX 104-RE, CIFX 104-RE-R	Parameter	Value	
Part	Name	CIFX 104-RE	CIFX 104-RE-R
	Part No.	1278.100	1279.100
	Description	PC Card cifX PC/104 for Real-Time Ethernet Master or Slave; (for CIFX 104-RE-R connectors at the right side)	
	Function	Communication Interface with PC/104 and Ethernet interface	
Communication Controller	Type	netX 100 processor	
Integrated Memory	RAM	8 MB SDRAM	
	FLASH	4 MB serial Flash EPROM	
	Size of the Dual-Port Memory	16 KByte	
System Interface	Bus Type	PC/104, according to [bus spec 8], refer to section *Overview*, page 95.	
	Transmission Rate	33 MHz	
	Data Access	DPM	
	Width for the data access to the Dual-Port Memory (DPM)	8 Bit or 16 Bit	
Ethernet Communication	Supported Real-Time Ethernet communication systems (determined by the loaded firmware)	EtherCAT Master, EtherCAT Slave	
		EtherNet/IP Scanner (Master), EtherNet/IP Adapter (Slave)	
		Open Modbus/TCP	
		POWERLINK Controlled Node/Slave	
		PROFINET IO-Controller (Master), PROFINET IO-Device (Slave)	
		sercos Master, sercos Slave	
		VARAN Client (Slave)	
	Ethernet Frame Types	Ethernet II	
Ethernet interface	Transmission Rate	100 MBit/s, 10 MBit/s (depending on loaded firmware)	
	Interface Type	100 BASE-TX, 10 BASE-T (depending on loaded firmware), refer to section *Ethernet Interface*, page 87.	
	Galvanic Isolation	isolated	
	Isolation Voltage	1000 VDC (tested for 1 minute)	
	Half duplex/Full duplex	depending on loaded firmware, supported (at 100 MBit/s)	
	Auto-Negotiation	depending on loaded firmware	
	Auto-Crossover	depending on loaded firmware	
	Connector	2* RJ45 Socket	
	Channel 0 and 1	With loaded EtherCAT Master firmware only the RJ45 channel 0 can be used, channel 1 is deactivated.	

© Hilscher, 2008-2014

CIFX 104-RE, CIFX 104-RE-R	Parameter	Value
		Beginning with the EtherCAT Master firmware version 3 channel 1 can be reactivated if redundancy is activated. For Open Modbus/TCP with V2.3.4.0 and higher both RJ45 channels can be used.
Diagnosis Interface	USB Interface	Mini B USB Plug (5 pin), refer to section *Mini-B USB Connector (5 Pin)*, page 91.
Display	LED Display	**SYS** System Status LED The meaning of the following LEDs depends on the loaded firmware: **COM 0** LED Communication Status 0 (duo LED) **COM 1** LED Communication Status 1 (duo LED) **LED yellow** / **LED green** at RJ45Ch0 and RJ45Ch1, for Ethernet Link status, Ethernet Activity status and additional status Refer to chapter *LED Descriptions*, page 64.
Power supply	Supply Voltage	+5 V dc ±5 %, refer to section *Power Supply and Host Interface*, page 28.
	Maximum Current at at 5 V (typically)	500 mA
	Connector	Via PC/104 Bus
Operation	Rotary Switch Device Address	Is currently unassigned. Refer to section *Rotary Switch Device Address* on page 91.
Environmental Conditions	Operating temperature range*	0 °C ... +70 °C
	*Air flow during measurment	0,5m/s
	Storage temperature range	0 °C ... +70 °C
	Humidity	10 … 95% relative humidity, no condensation permitted
Device	Dimensions (L x W x H)	97 x 91 x 24 mm
	Mounting/Installation	PC/104 Slot (5 V), refer to section *Slot for the PC Cards cifX PC/104*, page 28.
	RoHS	Yes
CE Sign	CE Sign	Yes
	Emission	EN 55011:2009 + A1:2010, CISPR 11:2009, Class A (Radio disturbance characteristics - Limits and methods of measurement)
	Immunity	EN 61000-4-2:2009 (Electrostatic discharge test) EN 61000-4-3:2006 + A1:2008 + A2:2010 (Radiated, radio-frequency, electromagnetic field test) EN 61000-4-4:2004 + A1:2010 (Burst Electrical fast transients/burst test) EN 61000-4-5:2006 (Surge test) EN 61000-4-6:2009 (to conducted disturbances, induced by radio- frequency fields) EN 61000-4-8:2010 (power frequency magnetic field test) EN 61000-6-2:2005 + B1:2011 (for industrial environments)
Configuration	Configuration Software Master and Slave	SYCON.net
	Configuration Software Slave	netX Configuration Tool

Table 84: Technical Data CIFX 104-RE, CIFX 104-RE-R

© Hilscher, 2008-2014

10.1.2 CIFX 104-RE\F, CIFX 104-RE-R\F

CIFX 104-RE\F, CIFX 104-RE-R\F	Parameter	Value	
Part	Name	CIFX 104-RE\F	CIFX 104-RE-R\F
	Part No.	1278.101	1279.101
	Description	PC Card cifX PC/104 for Real-Time Ethernet Master or Slave composed of: - Basic card CIFX 104-RE\F or CIFX 104-RE-R\F* with cable connector Ethernet X4 (X304) and cable connector DIAG X3 (X303) (*connectors at the right side) - Ethernet assembly interface (AIFX-RE) and - diagnostic assembly interface (AIFX-DIAG).	
	Function	Communication Interface with PC/104 and Ethernet interface	
Communication Controller	Type	netX 100 processor	
Integrated Memory	RAM	8 MB SDRAM	
	FLASH	4 MB serial Flash EPROM	
	Size of the Dual-Port Memory	16 KByte	
System Interface	Bus Type	PC/104, according to [bus spec 8], refer to section *Overview*, page 95.	
	Transmission Rate	33 MHz	
	Data Access	DPM	
	Width for the data access to the Dual-Port Memory (DPM)	8 Bit or 16 Bit	
Ethernet Communication	Supported Real-Time Ethernet communication systems (determined by the loaded firmware)	EtherCAT Master, EtherCAT Slave	
		EtherNet/IP Scanner (Master), EtherNet/IP Adapter (Slave)	
		Open Modbus/TCP	
		POWERLINK Controlled Node/Slave	
		PROFINET IO-Controller (Master), PROFINET IO-Device (Slave)	
		sercos Master, sercos Slave	
		VARAN Client (Slave)	
	Ethernet Frame Types	Ethernet II	
Ethernet interface	Transmission Rate	100 MBit/s, 10 MBit/s (depending on loaded firmware)	
	Interface Type	100 BASE-TX, 10 BASE-T (depending on loaded firmware), refer to section *Ethernet Interface*, page 87.	
	Half duplex/Full duplex	depending on loaded firmware, supported (at 100 MBit/s)	
	Auto-Negotiation	depending on loaded firmware	
	Auto-Crossover	depending on loaded firmware	
	Ethernet Assembly Interface	AIFX-RE, refer to section *AIFX-RE*, page 112. **Important!** Operating the PC cards CIFX 104-RE\F or CIFX 104-RE-R\F requires proper connection of the Ethernet assembly interface (AIFX-RE) to the basic card!	
	Connector AIFX-RE	Cable Connector Ethernet X4 (X304) (JST SM20B-SRSS-TB(LF)(SN), Pitch 1,0 mm)	
	Channel 0 and 1	With loaded EtherCAT Master firmware only the RJ45 channel 0 can be used, channel 1 is deactivated. Beginning with the EtherCAT Master firmware version 3 channel 1 can be reactivated if redundancy is activated.	

© Hilscher, 2008-2014

CIFX 104-RE\F, CIFX 104-RE-R\F	Parameter	Value
		For Open Modbus/TCP with V2.3.4.0 and higher both RJ45 channels can be used.
Diagnosis Interface	Diagnostic Assembly Interface	AIFX-DIAG, refer to section *AIFX-DIAG*, page 117. **Note:** If the diagnostic **AIFX-DIAG** assembly interface is connected to the PC card CIFX 104-RE\F or CIFX 104-RE-R\F, the **Mini-B USB** connector on the AIFX-DIAG can be used beginning with the hardware revision 5 of the PC card cifX.
	Connector AIFX-DIAG	Cable Connector DIAG X3 (X303) (JST 12FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
Display	LED Display	**SYS** System Status LED
		For LEDs at AIFX-RE, refer to section *AIFX-RE*, page 112.
Power supply	Supply Voltage	+5 V dc ±5 %, refer to section *Power Supply and Host Interface*, page 28.
	Maximum Current at at 5 V (typically)	500 mA
	Connector	Via PC/104 Bus
Environmental Conditions	Operating temperature range*	0 °C ... +70 °C
	*Air flow during measurment	0,5m/s
	Storage temperature range	0 °C ... +70 °C
	Humidity	10 … 95% relative humidity, no condensation permitted
Device	Dimensions (L x W x H)	97 x 91 x 24 mm
	Mounting/Installation	PC/104 Slot (5 V), refer to section *Slot for the PC Cards cifX PC/104*, page 28.
	RoHS	Yes
CE Sign	CE Sign	Yes
	Emission	EN 55011:2009 + A1:2010, CISPR 11:2009, Class A (Radio disturbance characteristics - Limits and methods of measurement)
	Immunity	EN 61000-4-2:2009 (Electrostatic discharge test) EN 61000-4-3:2006 + A1:2008 + A2:2010 (Radiated, radio-frequency, electromagnetic field test) EN 61000-4-4:2004 + A1:2010 (Burst Electrical fast transients/burst test) EN 61000-4-5:2006 (Surge test) EN 61000-4-6:2009 (to conducted disturbances, induced by radio- frequency fields) EN 61000-4-8:2010 (power frequency magnetic field test) EN 61000-6-2:2005 + B1:2011 (for industrial environments)
Configuration	Configuration Software Master and Slave	SYCON.net
	Configuration Software Slave	netX Configuration Tool

Table 85: Technical Data CIFX 104-RE\F, CIFX 104-RE-R\F

© Hilscher, 2008-2014

10.1.3 CIFX 104-DP, CIFX 104-DP-R

CIFX 104-DP, CIFX 104-DP-R	Parameter	Value	
Part	Name	CIFX 104-DP	CIFX 104-DP-R
	Part No.	1278.410	1279.410
	Description	PC Card cifX PC/104 PROFIBUS DP Master or Slave and PROFIBUS MPI Device; (for CIFX 104-DP-R connectors at the right side)	
	Function	Communication Interface with PC/104 and fieldbus interface PROFIBUS	
Communication Controller	Type	netX 100 processor	
Integrated Memory	RAM	8 MB SDRAM	
	FLASH	4 MB serial Flash EPROM	
	Size of the Dual-Port Memory	16 KByte	
System Interface	Bus Type	PC/104, according to [bus spec 8], refer to section *Overview*, page 95.	
	Transmission Rate	33 MHz	
	Data Access	DPM	
	Width for the data access to the Dual-Port Memory (DPM)	8 Bit or 16 Bit	
PROFIBUS Communication	Supported communication standard/ protocol (determined by the loaded firmware)	PROFIBUS DP Master, PROFIBUS DP Slave, PROFIBUS MPI Device	
PROFIBUS Interface	Transmission Rate	9,6 kBit/s, 19,2 kBit/s, 31,25 kBit/s, 45,45 kBit/s, 93,75 kBit/s, 187,5 kBit/s, 500 kBit/s, 1,5 MBit/s, 3 MBit/s, 6 MBit/s, 12 MBit/s	
	Interface Type	RS 485, refer to section *PROFIBUS Interface*, page 89.	
	Galvanic Isolation	isolated	
	Isolation Voltage	1000 VDC (tested for 1 minute)	
	Connector	DSub female Connector, 9 pin	
Diagnosis Interface	USB Interface	Mini B USB Plug (5 pin), refer to section *Mini-B USB Connector (5 Pin)*, page 91.	
Display	LED Display	**SYS** System Status LED **COM 0** LED Communication Status 0 (duo LED) The meaning of the COM LED depends on the loaded firmware. Refer to chapter *LED Descriptions*, page 64.	
Power supply	Supply Voltage	+5 V dc ±5 %, refer to section *Power Supply and Host Interface*, page 28.	
	Maximum Current at at 5 V (typically)	500 mA	
	Connector	Via PC/104 Bus	
Operation	Rotary Switch Device Address	Is currently unassigned. Refer to section *Rotary Switch Device Address* on page 91.	
Environmental Conditions	Operating temperature range*	-20 °C ... +70 °C	
	*Air flow during measurment	0,5m/s	
	Storage temperature range	-10 °C ... +70 °C	
	Humidity	10 … 95% relative humidity, no condensation permitted	
Device	Dimensions (L x W x H)	97 x 91 x 24 mm	
	Mounting/Installation	PC/104 Slot (5 V), refer to section *Slot for the PC Cards cifX PC/104*, page 28.	

© Hilscher, 2008-2014

CIFX 104-DP, CIFX 104-DP-R	Parameter	Value
	RoHS	Yes
CE Sign	CE Sign	Yes
	Emission	EN 55011:2009 + A1:2010, CISPR 11:2009, Class A (Radio disturbance characteristics - Limits and methods of measurement)
	Immunity	EN 61000-4-2:2009 (Electrostatic discharge test) EN 61000-4-3:2006 + A1:2008 + A2:2010 (Radiated, radio-frequency, electromagnetic field test) EN 61000-4-4:2004 + A1:2010 (Burst Electrical fast transients/burst test) EN 61000-4-5:2006 (Surge test) EN 61000-4-6:2009 (to conducted disturbances, induced by radio- frequency fields) EN 61000-4-8:2010 (power frequency magnetic field test) EN 61000-6-2:2005 + B1:2011 (for industrial environments)
Configuration	Configuration Software Master and Slave	SYCON.net
	Configuration Software Slave	netX Configuration Tool

Table 86: Technical Data CIFX 104-DP, CIFX 104-DP-R

10.1.4 CIFX 104-DP\F, CIFX 104-DP-R\F

CIFX 104-DP\F, CIFX 104-DP-R\F	Parameter	Wert	
Part	Name	CIFX 104-DP\F	CIFX 104-DP-R\F
	Part No.	1278.411	1279.411
	Description	PC Card cifX PC/104 PROFIBUS DP Master or Slave and PROFIBUS MPI Device composed of: - Basic card CIFX 104-FB\F or CIFX 104-FB-R\F* with cable connector Fieldbus X4 (X304) and cable connector DIAG X3 (X303) (*connectors at the right side) - PROFIBUS assembly interface (AIFX-DP) and - diagnostic assembly interface (AIFX-DIAG).	
	Function	Communication Interface with PC/104 and fieldbus interface PROFIBUS	
Communication Controller	Type	netX 100 processor	
Integrated Memory	RAM	8 MB SDRAM	
	FLASH	4 MB serial Flash EPROM	
	Size of the Dual-Port Memory	16 KByte	
System Interface	Bus Type	PC/104, according to [bus spec 8], refer to section *Overview*, page 95.	
	Transmission Rate	33 MHz	
	Data Access	DPM	
	Width for the data access to the Dual-Port Memory (DPM)	8 Bit or 16 Bit	
PROFIBUS Communication	Supported communication standard/ protocol (determined by the loaded firmware)	PROFIBUS DP Master, PROFIBUS DP Slave, PROFIBUS MPI Device	
PROFIBUS Interface	Transmission Rate	9,6 kBit/s, 19,2 kBit/s, 31,25 kBit/s, 45,45 kBit/s, 93,75 kBit/s, 187,5 kBit/s, 500 kBit/s, 1,5 MBit/s, 3 MBit/s, 6 MBit/s, 12 MBit/s	

© Hilscher, 2008-2014

CIFX 104-DP\F, CIFX 104-DP-R\F	Parameter	Wert
	Interface Type	RS 485, refer to section *PROFIBUS Interface* page 89.
	PROFIBUS Assembly Interface	AIFX-DP, refer to section *AIFX-DP* page 113. **Important!** Operating the PC cards CIFX 104-DP\F or CIFX 104-DP-R\F requires proper connection of the PROFIBUS assembly interface (AIFX-DP) to the basic card!
	Connector AIFX-DP	Cable Connector Fieldbus X4 (X304) (JST 10FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
Diagnosis Interface	Diagnostic Assembly Interface	AIFX-DIAG, refer to section *AIFX-DIAG*, page 117.
	Connector AIFX-DIAG	Cable Connector DIAG X3 (X303) (JST 12FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
Display	LED Display	**SYS** System Status LED
		For LEDs at AIFX-DP, refer to section *AIFX-DP* page 113.
Power supply	Supply Voltage	+5 V dc ±5 %, refer to section *Power Supply and Host Interface*, page 28.
	Maximum Current at at 5 V (typically)	500 mA
	Connector	Via PC/104 Bus
Environmental Conditions	Operating temperature range*	-20 °C ... +70 °C
	*Air flow during measurment	0,5m/s
	Storage temperature range	-10 °C ... +70 °C
	Humidity	10 … 95% relative humidity, no condensation permitted
Device	Dimensions (L x W x H)	97 x 91 x 24 mm
	Mounting/Installation	PC/104 Slot (5 V), refer to section *Slot for the PC Cards cifX PC/104*, page 28.
	RoHS	Yes
CE Sign	CE Sign	Yes
	Emission	EN 55011:2009 + A1:2010, CISPR 11:2009, Class A (Radio disturbance characteristics - Limits and methods of measurement)
	Immunity	EN 61000-4-2:2009 (Electrostatic discharge test) EN 61000-4-3:2006 + A1:2008 + A2:2010 (Radiated, radio-frequency, electromagnetic field test) EN 61000-4-4:2004 + A1:2010 (Burst Electrical fast transients/burst test) EN 61000-4-5:2006 (Surge test) EN 61000-4-6:2009 (to conducted disturbances, induced by radio- frequency fields) EN 61000-4-8:2010 (power frequency magnetic field test) EN 61000-6-2:2005 + B1:2011 (for industrial environments)
Configuration	Configuration Software Master and Slave	SYCON.net
	Configuration Software Slave	netX Configuration Tool

Table 87: Technical Data CIFX 104-DP\F, CIFX 104-DP-R\F

© Hilscher, 2008-2014

10.1.5 CIFX 104-CO, CIFX 104-CO-R

CIFX 104-CO, CIFX 104-CO-R	Parameter	Value	
Part	Name	CIFX 104-CO	CIFX 104-CO-R
	Part No.	1278.500	1279.500
	Description	PC Card cifX PC/104 CANopen Master or Slave; (for CIFX 104-CO-R connectors at the right side)	
	Function	Communication Interface with PC/104 and fieldbus interface CANopen	
Communication Controller	Type	netX 100 processor	
Integrated Memory	RAM	8 MB SDRAM	
	FLASH	4 MB serial Flash EPROM	
	Size of the Dual-Port Memory	16 KByte	
System Interface	Bus Type	PC/104, according to [bus spec 8], refer to section *Overview*, page 95.	
	Transmission Rate	33 MHz	
	Data Access	DPM	
	Width for the data access to the Dual-Port Memory (DPM)	8 Bit or 16 Bit	
CANopen Communication	Supported communication standard/ protocol (determined by the loaded firmware)	CANopen Master, CANopen Slave	
CANopen Interface	Transmission Rate	10 kBit/s, 20 kBit/s, 50 kBit/s, 100 kBit/s, 125 kBit/s, 250 kBit/s, 500 kBit/s, 800 kBit/s, 1 MBit/s	
	Interface Type	ISO-11898, refer to section *CANopen Interface*, page 89.	
	Galvanic Isolation	isolated (optically isolated)	
	Isolation Voltage	1000 VDC (tested for 1 minute)	
	Connector	DSub female Connector, 9 pin	
Diagnosis Interface	USB Interface	Mini B USB Plug (5 pin), refer to section *Mini-B USB Connector (5 Pin)*, page 91.	
Display	LED Display	**SYS** System Status LED **CAN** CANopen Status (duo LED) The meaning of the CAN LED is depending on loaded firmware. Refer to chapter *LED Descriptions*, page 64.	
Power supply	Supply Voltage	+5 V dc ±5 %, refer to section *Power Supply and Host Interface*, page 28.	
	Maximum Current at at 5 V (typically)	500 mA	
	Connector	Via PC/104 Bus	
Operation	Rotary Switch Device Address	Is currently unassigned. Refer to section *Rotary Switch Device Address* on page 91.	
Environmental Conditions	Operating temperature range*	-20 °C ... +70 °C	
	*Air flow during measurment	0,5m/s	
	Storage temperature range	-10 °C ... +70 °C	
	Humidity	10 … 95% relative humidity, no condensation permitted	
Device	Dimensions (L x W x H)	97 x 91 x 24 mm	
	Mounting/Installation	PC/104 Slot (5 V), refer to section *Slot for the PC Cards cifX PC/104*, page 28.	
	RoHS	Yes	

© Hilscher, 2008-2014

CIFX 104-CO, CIFX 104-CO-R	Parameter	Value
CE Sign	CE Sign	Yes
	Emission	EN 55011:2009 + A1:2010, CISPR 11:2009, Class A (Radio disturbance characteristics - Limits and methods of measurement)
	Immunity	EN 61000-4-2:2009 (Electrostatic discharge test) EN 61000-4-3:2006 + A1:2008 + A2:2010 (Radiated, radio-frequency, electromagnetic field test) EN 61000-4-4:2004 + A1:2010 (Burst Electrical fast transients/burst test) EN 61000-4-5:2006 (Surge test) EN 61000-4-6:2009 (to conducted disturbances, induced by radio- frequency fields) EN 61000-4-8:2010 (power frequency magnetic field test) EN 61000-6-2:2005 + B1:2011 (for industrial environments)
Configuration	Configuration Software Master and Slave	SYCON.net
	Configuration Software Slave	netX Configuration Tool

Table 88: Technical Data CIFX 104-CO, CIFX 104-CO-R

10.1.6 CIFX 104-CO\F, CIFX 104-CO-R\F

CIFX 104-CO\F, CIFX 104-CO-R\F	Parameter	Value	
Part	Name	CIFX 104-CO\F	CIFX 104-CO-R\F
	Part No.	1278.501	1279.501
	Description	PC Card cifX PC/104 CANopen Master or Slave composed of: - Basic card CIFX 104-FB\F or CIFX 104-FB-R\F* with cable connector Fieldbus X4 (X304) and cable connector DIAG X3 (X303) (*connectors at the right side) - CANopen assembly interface (AIFX-CO) and - diagnostic assembly interface (AIFX-DIAG).	
	Function	Communication Interface with PC/104 and fieldbus interface CANopen	
Communication Controller	Type	netX 100 processor	
Integrated Memory	RAM	8 MB SDRAM	
	FLASH	4 MB serial Flash EPROM	
	Size of the Dual-Port Memory	16 KByte	
System Interface	Bus Type	PC/104, according to [bus spec 8], refer to section *Overview*, page 95.	
	Transmission Rate	33 MHz	
	Data Access	DPM	
	Width for the data access to the Dual-Port Memory (DPM)	8 Bit or 16 Bit	
CANopen Communication	Supported communication standard/ protocol (determined by the loaded firmware)	CANopen Master, CANopen Slave	
CANopen Interface	Transmission Rate	10 kBit/s, 20 kBit/s, 50 kBit/s, 100 kBit/s, 125 kBit/s, 250 kBit/s, 500 kBit/s, 800 kBit/s, 1 MBit/s	
	Interface Type	ISO-11898, refer to section *CANopen Interface*, page 89.	
	CANopen Assembly Interface	AIFX-CO, refer to section *AIFX-CO*, page 114.	

© Hilscher, 2008-2014

CIFX 104-CO\F, CIFX 104-CO-R\F	Parameter	Value
		Important! Operating the PC cards CIFX 104-CO\F or CIFX 104-CO-R\F requires proper connection of the CANopen assembly interface (AIFX-CO) to the basic card!
	Connector AIFX-CO	Cable Connector Fieldbus X4 (X304) (JST 10FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
Diagnosis Interface	Diagnostic Assembly Interface	AIFX-DIAG, refer to section *AIFX-DIAG*, page 117.
	Connector AIFX-DIAG	Cable Connector DIAG X3 (X303) (JST 12FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
Display	LED Display	**SYS** System Status LED
		For LEDs at AIFX-CO, refer to section *AIFX-CO*, p. 114.
Power supply	Supply Voltage	+5 V dc ±5 %, refer to section *Power Supply and Host Interface*, page 28.
	Maximum Current at at 5 V (typically)	500 mA
	Connector	Via PC/104 Bus
Environmental Conditions	Operating temperature range*	-20 °C ... +70 °C
	*Air flow during measurment	0,5m/s
	Storage temperature range	-10 °C ... +70 °C
	Humidity	10 … 95% relative humidity, no condensation permitted
Device	Dimensions (L x W x H)	97 x 91 x 24 mm
	Mounting/Installation	PC/104 Slot (5 V), refer to section *Slot for the PC Cards cifX PC/104*, page 28.
	RoHS	Yes
CE Sign	CE Sign	Yes
	Emission	EN 55011:2009 + A1:2010, CISPR 11:2009, Class A (Radio disturbance characteristics - Limits and methods of measurement)
	Immunity	EN 61000-4-2:2009 (Electrostatic discharge test) EN 61000-4-3:2006 + A1:2008 + A2:2010 (Radiated, radio-frequency, electromagnetic field test) EN 61000-4-4:2004 + A1:2010 (Burst Electrical fast transients/burst test) EN 61000-4-5:2006 (Surge test) EN 61000-4-6:2009 (to conducted disturbances, induced by radio- frequency fields) EN 61000-4-8:2010 (power frequency magnetic field test) EN 61000-6-2:2005 + B1:2011 (for industrial environments)
Configuration	Configuration Software Master and Slave	SYCON.net
	Configuration Software Slave	netX Configuration Tool

Table 89: Technical Data CIFX 104-CO\F, CIFX 104-CO-R\F

© Hilscher, 2008-2014

10.1.7 CIFX 104-DN, CIFX 104-DN-R

CIFX 104-DN, CIFX 104-DN-R	Parameter	Value	
Part	Name	CIFX 104-DN	CIFX 104-DN-R
	Part No.	1278.510	1279.510
	Description	PC Card cifX PC/104 DeviceNet Master or Slave; (for CIFX 104-DN-R connectors at the right side)	
	Function	Communication Interface with PC/104 and fieldbus interface DeviceNet	
Communication Controller	Type	netX 100 processor	
Integrated Memory	RAM	8 MB SDRAM	
	FLASH	4 MB serial Flash EPROM	
	Size of the Dual-Port Memory	16 KByte	
System Interface	Bus Type	PC/104, according to [bus spec 8], refer to section *Overview*, page 95.	
	Transmission Rate	33 MHz	
	Data Access	DPM	
	Width for the data access to the Dual-Port Memory (DPM)	8 Bit or 16 Bit	
DeviceNet Communication	Supported communication standard/ protocol (determined by the loaded firmware)	DeviceNet Master, DeviceNet Slave	
DeviceNet Interface	Transmission Rate	125 kBit/s, 250 kBit/s, 500 kBit/s	
	Interface Type	ISO-11898 according to DeviceNet specification, refer to section *DeviceNet Interface*, page 90.	
	Galvanic Isolation	isolated (optically isolated)	
	Isolation Voltage	1000 VDC (tested for 1 minute)	
	Connector	CombiCon male Connector, 5-polig	
Diagnosis Interface	USB Interface	Mini B USB Plug (5 pin), refer to section *Mini-B USB Connector (5 Pin)*, page 91.	
Display	LED Display	**SYS** System Status LED **MNS** Module network status (duo LED) The meaning of the MNS LED is depending on loaded firmware. Refer to chapter *LED Descriptions*, page 64.	
Power supply	Supply Voltage	+5 V dc ±5 %, refer to section *Power Supply and Host Interface*, page 28.	
	Maximum Current at at 5 V (typically)	500 mA	
	Connector	Via PC/104 Bus	
Operation	Rotary Switch Device Address	Is currently unassigned. Refer to section *Rotary Switch Device Address* on page 91.	
Environmental Conditions	Operating temperature range*	-20 °C ... +70 °C	
	*Air flow during measurment	0,5m/s	
	Storage temperature range	-10 °C ... +70 °C	
	Humidity	10 … 95% relative humidity, no condensation permitted	
Device	Dimensions (L x W x H)	97 x 91 x 24 mm	
	Mounting/Installation	PC/104 Slot (5 V), refer to section *Slot for the PC Cards cifX PC/104*, page 28.	
	RoHS	Yes	
CE Sign	CE Sign	Yes	

© Hilscher, 2008-2014

CIFX 104-DN, CIFX 104-DN-R	Parameter	Value
	Emission	EN 55011:2009 + A1:2010, CISPR 11:2009, Class A (Radio disturbance characteristics - Limits and methods of measurement)
	Immunity	EN 61000-4-2:2009 (Electrostatic discharge test) EN 61000-4-3:2006 + A1:2008 + A2:2010 (Radiated, radio-frequency, electromagnetic field test) EN 61000-4-4:2004 + A1:2010 (Burst Electrical fast transients/burst test) EN 61000-4-5:2006 (Surge test) EN 61000-4-6:2009 (to conducted disturbances, induced by radio- frequency fields) EN 61000-4-8:2010 (power frequency magnetic field test) EN 61000-6-2:2005 + B1:2011 (for industrial environments)
Configuration	Configuration Software Master and Slave	SYCON.net
	Configuration Software Slave	netX Configuration Tool

Table 90: Technical Data CIFX 104-DN, CIFX 104-DN-R

10.1.8 CIFX 104-DN\F, CIFX 104-DN-R\F

CIFX 104-DN\F, CIFX 104-DN-R\F	Parameter	Value	
Part	Name	CIFX 104-DN\F	CIFX 104-DN-R\F
	Part No.	1278.511	1279.511
	Description	PC Card cifX PC/104 DeviceNet Master or Slave composed of: - Basic card CIFX 104-FB\F or CIFX 104-FB-R\F* with cable connector Fieldbus X4 (X304) and cable connector DIAG X3 (X303) (*connectors at the right side) - DeviceNet assembly interface (AIFX-DN)and - diagnostic assembly interface (AIFX-DIAG).	
	Function	Communication Interface with PC/104 and fieldbus interface DeviceNet	
Communication Controller	Type	netX 100 processor	
Integrated Memory	RAM	8 MB SDRAM	
	FLASH	4 MB serial Flash EPROM	
	Size of the Dual-Port Memory	16 KByte	
System Interface	Bus Type	PC/104, according to [bus spec 8], refer to section *Overview*, page 95.	
	Transmission Rate	33 MHz	
	Data Access	DPM	
	Width for the data access to the Dual-Port Memory (DPM)	8 Bit or 16 Bit	
DeviceNet Communication	Supported communication standard/ protocol (determined by the loaded firmware)	DeviceNet Master, DeviceNet Slave	
DeviceNet Interface	Transmission Rate	125 kBit/s, 250 kBit/s, 500 kBit/s	
	Interface Type	ISO-11898 according to DeviceNet specification, refer to section *DeviceNet Interface*, page 90.	
	DeviceNet Assembly Interface	AIFX-DN, refer to section *AIFX-DN,* page 115. **Important!** Operating the PC cards CIFX 104-DN\F or CIFX 104-	

© Hilscher, 2008-2014

CIFX 104-DN\F, CIFX 104-DN-R\F	Parameter	Value
		DN-R\F requires proper connection of the DeviceNet assembly interface (AIFX-DN) to the basic card!
	Connector AIFX-DN	Cable Connector Fieldbus X4 (X304) (JST 10FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
Diagnosis Interface	Diagnostic Assembly Interface	AIFX-DIAG, refer to section *AIFX-DIAG*, page 117.
	Connector AIFX-DIAG	Cable Connector DIAG X3 (X303) (JST 12FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
Display	LED Display	**SYS** System Status LED
		For LED at AIFX-DN, refer to section *AIFX-DN,* p. 115.
Power supply	Supply Voltage	+5 V dc ±5 %, refer to section *Power Supply and Host Interface*, page 28.
	Maximum Current at at 5 V (typically)	500 mA
	Connector	Via PC/104 Bus
Environmental Conditions	Operating temperature range*	-20 °C ... +70 °C
	*Air flow during measurment	0,5m/s
	Storage temperature range	-10 °C ... +70 °C
	Humidity	10 … 95% relative humidity, no condensation permitted
Device	Dimensions (L x W x H)	97 x 91 x 24 mm
	Mounting/Installation	PC/104 Slot (5 V), refer to section *Slot for the PC Cards cifX PC/104*, page 28.
	RoHS	Yes
CE Sign	CE Sign	Yes
	Emission	EN 55011:2009 + A1:2010, CISPR 11:2009, Class A (Radio disturbance characteristics - Limits and methods of measurement)
	Immunity	EN 61000-4-2:2009 (Electrostatic discharge test) EN 61000-4-3:2006 + A1:2008 + A2:2010 (Radiated, radio-frequency, electromagnetic field test) EN 61000-4-4:2004 + A1:2010 (Burst Electrical fast transients/burst test) EN 61000-4-5:2006 (Surge test) EN 61000-4-6:2009 (to conducted disturbances, induced by radio- frequency fields) EN 61000-4-8:2010 (power frequency magnetic field test) EN 61000-6-2:2005 + B1:2011 (for industrial environments)
Configuration	Configuration Software Master and Slave	SYCON.net
	Configuration Software Slave	netX Configuration Tool

Table 91: Technical Data CIFX104C-DN\F, CIFX 104-DN-R\F

10.1.9 CIFX 104-CC\F

CIFX 104-CC\F	Parameter	Value
Part	Name	CIFX 104-CC\F
	Part No.	1278.741
	Description	PC Card cifX PC/104 CC-Link Slave composed of: - Basic card CIFX 104-FB\F with cable connector Fieldbus X4 and cable connector DIAG X3, - CC-Link assembly interface (AIFX-CC) and

© Hilscher, 2008-2014

CIFX 104-CC\F	Parameter	Value
		- diagnostic assembly interface (AIFX-DIAG).
	Function	Communication Interface with PC/104 and fieldbus interface CC-Link
Communication Controller	Type	netX 100 processor
Integrated Memory	RAM	8 MB SDRAM
	FLASH	4 MB serial Flash EPROM
	Size of the Dual-Port Memory	16 KByte
System Interface	Bus Type	PC/104, according to [bus spec 8], refer to section *Overview*, page 95.
	Transmission Rate	33 MHz
	Data Access	DPM
	Width for the data access to the Dual-Port Memory (DPM)	8 Bit or 16 Bit
CC-Link Communication	Supported communication standard/ protocol (determined by the loaded firmware)	CC-Link Slave
CC-Link Interface	Transmission Rate	156 kBit/s, 625 kBit/s, 2500 kBit/s, 5 MBit/s, 10 MBit/s
	Interface Type	RS-485, refer to section *CC-Link Interface*, page 90.
	CC-Link Assembly Interface	AIFX-CC, refer to section *AIFX-CC* page 116. **Important!** Operating the PC cards CIFX 104-CC\F requires proper connection of the CC-Link assembly interface (AIFX-CC) to the basic card!
	Connector AIFX-CC	Cable Connector Fieldbus X4 (JST 10FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
Diagnosis Interface	Diagnostic Assembly Interface	AIFX-DIAG, refer to section *AIFX-DIAG*, page 117.
	Connector AIFX-DIAG	Cable Connector DIAG X3 (JST 12FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
Display	LED Display	**SYS** System Status LED
		For LEDs at AIFX-CC, refer to section *AIFX-CC* page 116.
Power supply	Supply Voltage	+5 V dc ±5 %, refer to section *Power Supply and Host Interface*, page 28.
	Maximum Current at at 5 V (typically)	500 mA
	Connector	Via PC/104 Bus
Environmental Conditions	Operating temperature range*	0 °C ... +60 °C
	*Air flow during measurment	0,5m/s
	Storage temperature range	-10 °C ... +70 °C
	Humidity	10 … 95% relative humidity, no condensation permitted
Device	Dimensions (L x W x H)	97 x 91 x 24 mm
	Mounting/Installation	PC/104 Slot (5 V), refer to section *Slot for the PC Cards cifX PC/104*, page 28.
	RoHS	Yes
CE Sign	CE Sign	Yes
	Emission	EN 55011:2009 + A1:2010, CISPR 11:2009, Class A (Radio disturbance characteristics - Limits and methods of measurement)
	Immunity	EN 61000-4-2:2009 (Electrostatic discharge test) EN 61000-4-3:2006 + A1:2008 + A2:2010 (Radiated, radio-frequency, electromagnetic field test) EN 61000-4-4:2004 + A1:2010 (Burst Electrical fast

© Hilscher, 2008-2014

CIFX 104-CC\F	Parameter	Value
		transients/burst test) EN 61000-4-5:2006 (Surge test) EN 61000-4-6:2009 (to conducted disturbances, induced by radio- frequency fields) EN 61000-4-8:2010 (power frequency magnetic field test) EN 61000-6-2:2005 + B1:2011 (for industrial environments)
Configuration	Configuration Software	SYCON.net or netX Configuration Tool

Table 92: Technical Data CIFX104C-CC\F

10.1.10 AIFX-RE

AIFX-RE	Parameter	Value
Part	Name	AIFX-RE
	Part No.	2800.100
	Description	Ethernet assembly interface (with Ethernet interface) for the PC cards CIFX 104-RE\F, CIFX 104-RE-R\F
Interface PC Card cifX	Connector	Cable Connector Ethernet X1 (JST SM20B-SRSS-TB(LF)(SN), Pitch 1.0 mm)
Ethernet Interface	Galvanic Isolation	isolated
	Isolation Voltage	1000 VDC (tested for 1 minute)
	Connector	2* RJ45 Socket
Display	LED Display (on the reverse side of the device)	The meaning of the following LEDs depends on the loaded firmware:: **COM 0** LED Communication Status 0 (duo LED) **COM 1** LED Communication Status 1 (duo LED) **LED yellow** / **LED green** at RJ45Ch0 and RJ45Ch1, for Ethernet Link status, Ethernet Activity status and additional status Refer to chapter *LED Descriptions*, page 64.
Power supply	Connector	Cable Connector Ethernet X1
Environmental Conditions	Operating temperature range*	0 °C ... +70 °C
	*Air flow during measurment	0,5m/s
	Storage temperature range	0 °C ... +70 °C
	Humidity	10 … 95% relative humidity, no condensation permitted
	Environment	For UL compliant usage: The device must be used in a pollution degree 2 environment.
Device	Dimensions (L x W x H)	30,7 x 42,3 x 18,5 mm (H = width of the front panel)
	Mounting/Installation	At the basic cards CIFX 104-RE\F, CIFX 104-RE-R\F: Cable Connector Ethernet X4 (X304)
	RoHS	Yes
CE Sign	CE Sign	Yes
	Emission, Immunity	Tested together with the corresponding basic card cifX.
UL Certification	The device is certified according to UL 508	UL-File-Nr. E221530

Table 93: Technical Data AIFX-RE

© Hilscher, 2008-2014

10.1.11 AIFX-DP

AIFX-DP	Parameter	Value
Part	Name	AIFX-DP
	Part No.	2800.400
	Description	PROFIBUS assembly interface (with PROFIBUS interface) for the PC cards CIFX 104-DP\F, CIFX 104-DP-R\F
Interface PC Card cifX	Connector	Cable Connector Fieldbus X1 (JST 10FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
PROFIBUS Interface	Galvanic Isolation	isolated
	Isolation Voltage	1000 VDC (tested for 1 minute)
	Connector	DSub female Connector, 9 pin
Display	LED Display (on the reverse side of the device)	The meaning of the following LEDs depends on the loaded firmware: **ERR** LED Error status (red) **STA** LED Status (green) For PROFIBUS MPI the STA LED is not used. Refer to chapter *LED Descriptions*, page 64.
Power supply	Connector	Cable Connector Fieldbus X1
Environmental Conditions	Operating temperature range*	-20 °C ... +70 °C
	*Air flow during measurment	0,5m/s
	Storage temperature range	-10 °C ... +70 °C
	Humidity	10 … 95% relative humidity, no condensation permitted
	Environment	For UL compliant usage: The device must be used in a pollution degree 2 environment.
Device	Dimensions (L x W x H)	17 x 31 x 18,5 mm (H = width of the front panel)
	Mounting/Installation	At the basic cards CIFX 104-FB\F, CIFX 104-FB-R\F: Cable Connector Fieldbus X4 (X304)
	RoHS	Yes
CE Sign	CE Sign	Yes
	Emission, Immunity	Tested together with the corresponding basic card cifX.
UL Certification	The device is certified according to UL 508	UL-File-Nr. E221530

Table 94: Technical Data AIFX-DP

© Hilscher, 2008-2014

10.1.12 AIFX-CO

AIFX-CO	Parameter	Value
Part	Name	AIFX-CO
	Part No.	2800.500
	Description	CANopen assembly interface (with CANopen interface) for the PC cards CIFX 104-CO\F, CIFX 104-CO-R\F
Interface PC Card cifX	Connector	Cable Connector Fieldbus X1 (JST 10FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
CANopen Interface	Galvanic Isolation	isolated (optically isolated)
	Isolation Voltage	1000 VDC (tested for 1 minute)
	Connector	DSub female Connector, 9 pin
Display	LED Display (on the reverse side of the device)	The meaning of the following LEDs depends on the loaded firmware:: **ERR** LED Error status (red) **RUN** LED Run (green) Refer to chapter *LED Descriptions*, page 64.
Power supply	Connector	Cable Connector Fieldbus X1
Environmental Conditions	Operating temperature range*	-20 °C ... +70 °C
	*Air flow during measurment	0,5m/s
	Storage temperature range	-10 °C ... +70 °C
	Humidity	10 … 95% relative humidity, no condensation permitted
	Environment	For UL compliant usage: The device must be used in a pollution degree 2 environment.
Device	Dimensions (L x W x H)	17 x 31 x 18,5 mm (H = width of the front panel)
	Mounting/Installation	At the basic cards CIFX 104-FB\F, CIFX 104-FB-R\F: Cable Connector Fieldbus X4 (X304)
	RoHS	Yes
CE Sign	CE Sign	Yes
	Emission, Immunity	Tested together with the corresponding basic card cifX..
UL Certification	The device is certified according to UL 508	UL-File-Nr. E221530

Table 95: Technical Data AIFX-CO

© Hilscher, 2008-2014

10.1.13 AIFX-DN

AIFX-DN	Parameter	Value
Part	Name	AIFX-DN
	Part No.	2800.510
	Description	DeviceNet assembly interface (with DeviceNet interface) for the PC cards CIFX 104-DN\F, CIFX 104-DN-R\F
Interface PC Card cifX	Connector	Cable Connector Fieldbus X1 (JST 10FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
DeviceNet Interface	Galvanic Isolation	isolated (optically isolated)
	Isolation Voltage	1000 VDC (tested for 1 minute)
	Connector	CombiCon male Connector, 5-polig
Display	LED Display (on the reverse side of the device)	**MNS** Module network status (duo LED) The meaning of the MNS LED is depending on loaded firmware. Refer to chapter *LED Descriptions*, page 64.
Power supply	Connector	Cable Connector Fieldbus X1
Environmental Conditions	Operating temperature range*	-20 °C ... +70 °C
	*Air flow during measurment	0,5m/s
	Storage temperature range	-10 °C ... +70 °C
	Humidity	10 … 95% relative humidity, no condensation permitted
	Environment	For UL compliant usage: The device must be used in a pollution degree 2 environment.
Device	Dimensions (L x W x H)	23,7 x 31 x 18,5 mm (L = 23,7, without CombiCon male Connector; H = width of the front panel)
	Mounting/Installation	At the basic cards CIFX 104-FB\F, CIFX 104-FB-R\F: Cable Connector Fieldbus X4 (X304)
	RoHS	Yes
CE Sign	CE Sign	Yes
	Emission, Immunity	Tested together with the corresponding basic card cifX..
UL Certification	The device is certified according to UL 508	UL-File-Nr. E221530

Table 96: Technical Data AIFX-DN

© Hilscher, 2008-2014

10.1.14 AIFX-CC

AIFX-CC	Parameter	Value
Part	Name	AIFX-CC
	Part No.	2800.730
	Description	CC-Link assembly interface (with CC-Link interface) for the PC card CIFX 104-CC\F
Interface PC Card cifX	Connector	Cable Connector Fieldbus X1 (JST 10FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
CC-Link Interface	Galvanic Isolation	isolated (optically isolated)
	Isolation Voltage	1000 VDC (tested for 1 minute)
	Connector	CombiCon male Connector, 5-polig
Display	LED Display (on the reverse side of the device)	**L RUN** LED L Run (Duo-LED) **L ERR** LED L Error (Duo-LED) Refer to chapter *LED Descriptions*, page 64.
Power supply	Connector	Cable Connector Fieldbus X1
Environmental Conditions	Operating temperature range*	0 °C ... +60 °C
	*Air flow during measurment	0,5m/s
	Storage temperature range	-10 °C ... +70 °C
	Humidity	10 … 95% relative humidity, no condensation permitted
Device	Dimensions (L x W x H)	43,2 x 31 x 18,5 mm (L = 43,2, without CombiCon male Connector; H = width of the front panel)
	Mounting/Installation	At the basic card CIFX 104C-FB\F: Cable Connector Fieldbus X4 (X304)
	RoHS	Yes
CE Sign	CE Sign	Yes
	Emission, Immunity	Tested together with the corresponding basic card cifX.

Table 97: Technical Data AIFX-CC

© Hilscher, 2008-2014

10.1.15 AIFX-DIAG

AIFX-DIAG	Parameter	Value
Part	Name	AIFX-DIAG
	Part No.	2800.000
	Description	Diagnostic assembly interface (with diagnostic interface) for the PC cards CIFX 104-RE\F, CIFX 104-RE-R\F CIFX 104-DP\F, CIFX 104-DP-R\F, CIFX 104-CO\F, CIFX 104-CO-R\F, CIFX 104-DN\F, CIFX 104-DN-R\F, CIFX 104-CC\F
Schnittstelle PC-Karte cifX	Connector	Cable Connector DIAG X1 (JST 12FMN-SMT-A-TF(LF)(SN), Pitch 1,0 mm)
Diagnosis Interface	USB Interface	Mini B USB Plug (5 pin), refer to section *Mini-B USB Connector (5 Pin)*, page 91.
Display	LED Display	**PWR** Supply Voltage ON LED **SYS** System Status LED The meaning of the following LEDs depends on the loaded firmware:: **COM 0** LED Communication Status 0 (duo LED) **COM 1** LED Communication Status 1 (duo LED) Refer to chapter *LED Descriptions*, page 64.
Power supply	Connector	Kabelstecker DIAG X1
Operation	Rotary Switch Device Address	Is currently unassigned. Refer to section *Rotary Switch Device Address* on page 91.
Environmental Conditions	Operating temperature range*	-20 °C ... +70 °C
	*Air flow during measurment	0,5m/s
	Storage temperature range	-10 °C ... +70 °C
	Humidity	10 … 95% relative humidity, no condensation permitted
	Environment	For UL compliant usage: The device must be used in a pollution degree 2 environment.
Device	Dimensions (L x W x H)	20,5 x 52,7 x 18,5 mm (H = width of the front panel)
	Mounting/Installation	For the basic cards: CIFX 104-RE\F, CIFX 104-RE-R\F, CIFX 104-FB\F, CIFX 104-FB-R\F Cable Connector DIAG X3 (X303)
	RoHS	Yes
CE Sign	CE Sign	Yes
	Emission, Immunity	Tested together with the corresponding basic card cifX..
UL Certification	The device is certified according to UL 508	UL-File-Nr. E221530

Table 98: Technical Data AIFX-DIAG

© Hilscher, 2008-2014

10.2 Technical Data of the Communication Protocols

10.2.1 EtherCAT Master

Parameter	Description
Maximum number of EtherCAT slaves	Maximum 200 Slaves. The number of usable slaves depends on the available memory for the configuration file. See ‘configuration file’ below.
Maximum number of cyclic input data	5760 bytes
Maximum number of cyclic output data	5760 bytes
Minimum bus cycle time	205 µs, depending on the used number of slaves and the used number of cyclic input data and output data. Recommended is a cycle time of 1 ms and higher.
Acyclic communication	CoE (CANopen over EtherCAT) CoE-Upload, CoE-Download Maximum 1500 bytes
Functions	Get OD List Get object description Get entry description Emergency Slave diagnostics
Bus Scan	Supported
Redundancy	Supported, but not at the same time with Distributed Clocks
Distributed Clocks	Supported, but not at the same time with Redundancy
Topology	Line or ring
Baud rate	100 MBit/s
Data transport layer	Ethernet II, IEEE 802.3
Configuration File (ethercat.xml or config.nxd)	PC cards PCI, PCI Express, PCI Express Low Profile, Mini PCI, Compact PCI, Mini PCI Express, PCI-104 Real-Time Ethernet: Maximum 1 MByte PC cards PC/104 Real-Time Ethernet: Maximum 2 MByte
Limitations	The size of the bus configuration file is limited by the size of the RAM Disk (1 Mbyte) or FLASH disk (2 Mbyte). All CoE Uploads, Downloads and information services must fit in one TLR-Packet. Fragmentation is not supported Distubuted Clock and Redundancy can not be used at the same time.
Reference to firmware/stack version	V3.0.x.x

Table 99: Technical Data EtherCAT Master Protocol

© Hilscher, 2008-2014

10.2.2 EtherCAT Slave

Parameter	Description
Maximum number of cyclic input data	256* bytes
Maximum number of cyclic output data	256* bytes
Acyclic communication	SDO SDO Master-Slave SDO Slave-Slave (depending on Master capability)
Type	Complex Slave
Functions	Emergency
FMMUs	3
SYNC Manager	4
Distributed Clocks (DC)	Supported, 32 Bit
Baud rate	100 MBit/s
Data transport layer	Ethernet II, IEEE 802.3
Limitation	LRW is not supported
Reference to firmware/stack version	V2.5.x.x and V4.2.x.x

Table 100: Technical Data EtherCAT Slave Protocol

Note: * The loadable firmware supports for the number of cyclic input data and for cyclic output data in total up to 512 bytes. If more than 256 bytes for input data or for output data shall be exchanged via EtherCAT, then a customer specific XML file is necessary. Additionally the following formula applies: The sum of the input data length and the ouput data length may not exceed 512 bytes, where each length has to be rounded up to the next multiple of 4 for this calculation.

© Hilscher, 2008-2014

10.2.3 EtherNet/IP Scanner (Master)

Parameter	Description
Maximum number of EtherNet/IP connections	64 connections for implicit and explicit
Maximum number of total cyclic input data	5712 bytes
Maximum number of total cyclic output data	5760 bytes
Maximum number of cyclic input data	504 bytes per slave per telegram
Maximum number of cyclic output data	504 bytes per slave per telegram
IO Connection type	Cyclic, minimum 1 ms (depending on used number of connections and used number of input and output data)
Maximum number of unscheduled data	1400 bytes per telegram
UCMM, Class 3	Supported
Explicit Messages, Client and Server Services	Get_Attribute_Single/All Set_Attribute_Single/All
Quick connect	Supported
Predefined standard objects	Identity Object Message Route Object Assembly Object Connection Manager Ethernet Link Object TCP/IP Object DLR Object QoS Object
Maximal number of user specific objects	20
Topology	Tree, Line, Ring
DLR (Device Level Ring)	Beacon based ’Ring Node’
ACD (Address Conflict Detection)	Supported
DHCP	Supported
BOOTP	Supported
Baud rates	10 and 100 MBit/s
Data transport layer	Ethernet II, IEEE 802.3
Switch function	Integrated
Limitations	CIP Sync Services are not implemented TAGs are not supported
Reference to firmware/stack version	V2.6.x.x

Table 101: Technical Data EtherNet/IP Scanner (Master) Protocol

© Hilscher, 2008-2014

10.2.4 EtherNet/IP Adapter (Slave)

Parameter	Description
Maximum number of input data	504 bytes
Maximum number of output data	504 bytes
IO connection types (implicit)	1 exclusive owner, 1 listen only, 1 input only
IO Connection trigger types	Cyclic, minimum 1 ms* Application Triggered, minimum 1 ms* Change Of State, minimum 1 ms* * depending on number of connections and number of input and output data
Explicit Messages	Connected and unconnected
Maximum number of connections	8, explicit and implicit connections
Unconnected Message Manager (UCMM)	Supported
Quick connect	Supported
Predefined standard objects	Identity Object Message Route Object Assembly Object Connection Manager DLR Object QoS Object TCP/IP Object Ethernet Link Object
Reset services	Identity Object Reset Service of Type 0 and 1
Maximum number of user specific objects	20
DLR V2 (ring topology)	Supported
ACD (Address Conflict Detection)	Supported
DHCP	Supported
BOOTP	Supported
Baud rates	10 and 100 MBit/s
Duplex modes	Half duplex, Full duplex, Auto negotiation
MDI modes	MDI, MDI-X, Auto-MDIX
Data transport layer	Ethernet II, IEEE 802.3
Switch function	Integrated
Limitations	CIP Sync Services are not implemented TAGs are not supported
Reference to firmware/stack version	V2.7.x.x

Table 102: Technical Data EtherNet/IP Adapter (Slave) Protocol

© Hilscher, 2008-2014

10.2.5 Open Modbus/TCP

Parameter	Description
Maximum number of input data	2880 Registers
Maximum number of output data	2880 Registers
Acyclic communication	Read/Write Register: - Maximum 125 Registers per Read Telegram (FC 3, 4, 23), - Maximum 121 Registers per Write Telegram (FC 23), - Maximum 123 Registers per Write Telegram (FC 16) Read/Write Coil: - Maximum 2000 Coils per Read Telegram (FC 1, 2), - Maximum 1968 Coils per Write Telegram (FC 15)
Modbus Function Codes	1, 2, 3, 4, 5, 6, 7, 15, 16, 23* * Function Code 23 can be used via the packet API, but not with the Command Table.
Protocol Mode	Message Mode (Client Mode): - Client (using the Command Table: The data is stored in the I/O process data image) - Client (using the packet API: The I/O process data image is not used) - Server (using the packet API: The I/O process data image is not used) I/O Mode (Server Mode): - Server (only) (The data is stored in the I/O process data image)
Baud rates	10 and 100 MBit/s
Data transport layer	Ethernet II, IEEE 802.3
Reference to firmware/stack version	V2.5.x.x

Table 103: Technical Data Open Modbus/TCP Protocol

10.2.6 POWERLINK Controlled Node/Slave

Parameter	Description
Maximum number of cyclic input data	1490 bytes
Maximum number of cyclic output data	1490 bytes
Acyclic data transfer	SDO Upload/Download
Functions	SDO over ASND and UDP
Baud rate	100 MBit/s, half-duplex
Data transport layer	Ethernet II, IEEE 802.3
Ethernet POWERLINK version	V 2
Limitation	No slave to slave communication
Reference to firmware/stack version	V2.1.x.x

Table 104: Technical Data POWERLINK Controlled Node (Slave) Protocol

© Hilscher, 2008-2014

10.2.7 PROFINET IO-Controller

Parameter	Description
Maximum number of PROFINET IO Devices	128
Maximum number of total cyclic input data	5712 bytes (including IOxS status bytes)
Maximum number of total cyclic output data	5760 bytes (including IOxS status bytes)
Maximum number of cyclic input data	1440 bytes per device (= IOCR data length including IOxS status bytes)
Maximum number of cyclic output data	1440 bytes per device (= IOCR data length including IOxS status bytes)
Acyclic communication	Read/Write Record Limited to 1392 bytes per telegram Limited to 4096 bytes per request
Alarm processing	yes, but requires handling in host application program
Diagnostic data	One 200 byte buffer per IO device
DCP functions via API	Name Assignment IO-Devices (DCP SET NameOfStation) Set IO-Devices IP (DCP SET IP) Signal IO-Device (DCP SET SIGNAL) Reset IO-Device to factory settings (DCP Reset FactorySettings) Bus scan (DCP IDENTIFY ALL)
Supported Protocols	RTC – Real Time Cyclic Protocol, Class 1 RTA – Real Time Acyclic Protocol DCP – Discovery and configuration Protocol CL-RPC – Connectionless Remote Procedure Call
Context management by CL-RPC	Supported
Minimum cycle time	1 ms Different IO-Devices can be configured with different cycle times
Functions	Fast Startup of PROFINET IO Devices supported
Baud rate	100 MBit/s Full-Duplex mode
Data transport layer	Ethernet II, IEEE 802.3
Configuration file	Maximum 1 MByte
Limitations	RT over UDP not supported Multicast communication not supported DHCP is not supported (neither for PROFINET IO-Controller nor for the IO-Devices) Only one IOCR per IO Device NameOfStation of IO Controller CANNOT be set using the DCP SET NameOfStation service but only at start-up while configuring the IO Controller The buffer for IO-Device diagnosis data will be overwritten in case of multiple diagnostic events. Only one (the last) event is stored at the same time. If a single event produces more than 200 bytes of diagnosis data, only the first 200 bytes will be taken care of. The usable (minimum) cycle time depends on the number of used IO Devices, the number of used input and output data. The cycle-time, the number of configured IO Devices and the amount of IO data depend on each other. For example it is not possible due to performance reasons to have 128 IO Devices communication with cycle-time 1ms. The size of the bus configuration file is limited by the size of the RAM Disk (1 MByte) WriteMultiple-Record service is not supported

© Hilscher, 2008-2014

Parameter	Description
Reference to firmware/stack version	V2.6.x.x

Table 105: Technical Data PROFINET IO RT Controller

10.2.8 PROFINET IO-Device (V3.4)

Parameter	Description
Maximum number of cyclic input data	1024 bytes
Maximum number of cyclic output data	1024 bytes
Acyclic communication	Read/Write Record, max. 1024 bytes per telegram
Alarm Types	Process Alarm, Diagnostic Alarm, Return of SubModule Alarm Plug Alarm (implicit), Pull Alarm (implicit)
Supported protocols	RTC – Real Time Cyclic Protocol, Class 1 and 2 (unsynchronized), Class 3 (synchronized) RTA – Real Time Acyclic Protocol DCP – Discovery and configuration Protocol CL-RPC – Connectionless Remote Procedure Call LLDP – Link Layer Discovery Protocol SNMP – Simple Network Management Protocol MRP – MRP Client
Used Protocols (subset)	UDP, IP, ARP, ICMP (Ping)
Topology recognition	LLDP, SNMP V1, MIB2, physical device
VLAN- and priority tagging	yes
Context Management by CL-RPC	Supported
Identification & Maintenance	Read and write of I&M1-4
Minimum cycle time	1 ms for RTC1 and RTC2 250 µs for RTC3
Baud rate	100 MBit/s
Data transport layer	Ethernet II, IEEE 802.3
Limitations	RT over UDP not supported Multicast communication not supported Only one device instance is supported DHCP is not supported IRT “flex” (synchronized RT Class 2) is not supported FastStartUp is not supported. Media Redundancy (except MRP client) is not supported Access to the submodule granular status bytes (IOCS) is not supported. The amount of configured IO-data influences the minimum cycle time that can be reached. Supervisor-AR is not supported, Supervisor-DA-AR is supported Only 1 Input-CR and 1 Output-CR are supported Multiple WriteRequests are not supported Using little endian (LSB-MSB) byte order for cyclic process data instead of default big endian (MSB-LSB) byte order may have an negative impact on minimum reachable cycle time
Reference to firmware/stack version	V3.4.x.x

Table 106: Technical Data PROFINET IO RT IRT Device Protocol

© Hilscher, 2008-2014

10.2.9 PROFINET IO-Device (V3.5)

Parameter	Description
Maximum number of cyclic input data	1440 bytes
Maximum number of cyclic output data	1440 bytes
Maximum number of submodules	255 submodules per Application Relation at the same time, 1000 submodules can be configured
Multiple Application Relations (AR)	The Stack can handle up to 2 IO-ARs, one Supervisor AR and one Supervisor-DA AR at the same time
Acyclic communication	Read/Write Record, max. 1024 bytes per telegram
Alarm Types	Process Alarm, Diagnostic Alarm, Return of SubModule Alarm, Plug Alarm (implicit), Pull Alarm (implicit)
Supported protocols	RTC – Real Time Cyclic Protocol, class 1 (unsynchronized), class 3 (synchronized) RTA – Real Time Acyclic Protocol DCP – Discovery and configuration Protocol CL-RPC – Connectionless Remote Procedure Call LLDP – Link Layer Discovery Protocol SNMP – Simple Network Management Protocol MRP – MRP Client
Topology recognition	LLDP, SNMP V1, MIB2, physical device
Identification & Maintenance	Read and write of I&M1-4
Minimum cycle time	1 ms for RT_CLASS_1 250 µs for RT_CLASS_3
IRT Support	RT_CLASS_3
Media Redundancy	MRP client is supported
Additional features	DCP, VLAN- and priority tagging, Shared Device
Baud rate	100 MBit/s
Data transport layer	Ethernet II, IEEE 802.3
PROFINET IO specification	V2.2 (legacy startup) and V2.3 (but advanced startup only for RT) are supported
Limitations	RT over UDP not supported Multicast communication not supported Only one device instance is supported DHCP is not supported FastStartUp is not supported The amount of configured IO-data influences the minimum cycle time that can be reached. Only 1 Input-CR and 1 Output-CR are supported Using little endian (LSB-MSB) byte order for cyclic process data instead of default big endian (MSB-LSB) byte order may have an negative impact on minimum reachable cycle time System Redundancy (SR-AR) and Configuration-in-Run (CiR) are not supported Max. 255 submodules can be used simultaneously within one specific Application Relation Advanced Startup according Profinet specification V2.3 is NOT yet supported for IRT As there is no official certification available for Profinet IO specification V2.3 at the time of release of the stack there is no guarantee that this implementation will pass such a certification once it is available
Reference to firmware/stack version	V3.5.26.x

Table 107: Technical Data PROFINET IO RT IRT Device Protocol

© Hilscher, 2008-2014

10.2.10 sercos Master

Parameter	Description
Maximum number of cyclic input data	5760 bytes (including Connection Control per Connection)
Maximum number of cyclic output data	5760 bytes (including Connection Control per Connection)
Maximum number of configured slave devices	511
Minimum cycle time	250 µs
Acyclic communication	Service channel: Read/Write/Commands
Functions	Bus Scan
Communication phases	NRT, CP0, CP1, CP2, CP3, CP4
Topology	Line and double ring
Redundancy	supported
NRT channel	supported
Hot-Plug	supported
Cross Communication	supported, but only if the master is configured by the host application program by packets.
Baud rate	100 MBit/s, full duplex
Data transport layer	Ethernet II, IEEE 802.3
Auto crossover	supported
Supported sercos version	Communication Specification Version 1.3
TCP/IP stack	integrated
Reference to firmware/stack version	V2.1.x.x

Table 108: Technical Data sercos Master Protocol

© Hilscher, 2008-2014

10.2.11 sercos Slave

Parameter	Description
Maximum number of cyclic input data (Tx) of all slaves	128 bytes (including Connection Control and IO Status)
Maximum number of cyclic output data (Rx) of all slaves	128 bytes (including Connection Control and IO Status)
Maximum number of slave devices	8
Maximum number of applicable sercos addresses	1 … 511
Minimum cycle time	250 µs
Topology	Line and ring
Communication phases	NRT, CP0, CP1, CP2, CP3, CP4
Acyclic Communication (Service Channel)	Read/Write/Standard Commands
Baud rate	100 MBit/s
Data transport layer	Ethernet II, IEEE 802.3
Supported sercos version	sercos in the third generation Communication Specification Version 1.1.2
Supported sercos Communication Profiles	SCP_FixCFG Version 1.1.1 SCP_VarCFG Version 1.1.1 SCP_VarCFG Version 1.1.3
Supported User SCP Profiles	SCP_WD Version 1.1.1 SCP_Diag Version 1.1.1 SCP_RTB Version 1.1.1 SCP_Mux Version 1.1.1 SCP_Sig Version 1.1.1 SCP_ExtMuX Version 1.1.2 SCP_RTBListProd Version 1.3 SCP_RTBListCons Version 1.3 SCP_RTBWordProd Version 1.3 SCP_RTBWordCons Version 1.3 SCP_OvSBasic Version 1.3 SCP_WDCon Version 1.3
Supported FSP profiles	FSP_IO FSP_Drive
SCP Sync	Supported
S/IP	Supported
Identification LED	Supported
Storage location of object dictionary	Mixed mode
Limitations	Max. 2 connections: 1 for consumer and 1 for producer Modifications of the Service-Channel Object Dictionary will be volatile after reset (if it resides on device) Hot plug is not supported yet Cross communication not supported yet NRT Channel only forwarding
Reference to firmware/stack version	V3.1.x.x

Table 109: Technical Data sercos Slave Protocol

© Hilscher, 2008-2014

10.2.12 VARAN Client (Slave)

Parameter	Description
Maximum number of cyclic input data	128 bytes
Maximum number of cyclic output data	128 bytes
Memory Area	Read Memory Area 1, Write Memory Area 1
Functions	Memory Read Memory Write
Integrated 2 port splitter for daisy chain topology	Supported
Baud rate	100 MBit/s
Data transport layer	Ethernet II, IEEE 802.3
VARAN protocol version	1.1.1.0
Limitations	Integrated EMAC for IP data exchange with client application not supported SPI single commands (optional feature) not supported Memory area 2 is not supported.
Reference to firmware/stack version	V1.0.x.x

Table 110: Technical Data VARAN Client Protocol

© Hilscher, 2008-2014

10.2.13 PROFIBUS DP Master

Parameter	Description
Maximum number of PROFIBUS DP slaves	125 (DPV0/DPV1)
Maximum number of total cyclic input data	5712 bytes
Maximum number of total cyclic output data	5760 bytes
Maximum number of cyclic input data	244 bytes per slave
Maximum number of cyclic output data	244 bytes per slave
Configuration data	Max. 244 bytes per slave
Parameterization data per slave	7 bytes standard parameter per slave Max. 237 bytes application specific parameters per slave
Acyclic communication	DPV1 class 1 read, write DPV1 class 1 alarm DPV1 class 2 initiate, read, write, data transport, abort
Maximum number of acyclic read/write	240 bytes per slave and telegram
Functions	Configuration in Run (CiR), requires host application program support Timestamp (Master functionality)
Redundancy	Supported, requires host application program support
Baud rate	9,6 kBits/s, 19,2 kBits/s, 31,25 kBits/s, 45,45 kBits/s 93,75 kBits/s, 187,5 kBits/s, 500 kBits/s, 1, 5 MBits/s, 3 MBits/s, 6 MBits/s, 12 MBit/s Auto baud rate detection is not supported
Data transport layer	PROFIBUS FDL
Limitations	DPV2 isochronous mode and slave slave communication are not supported. The redundancy function can not be used, if the master is configured by the host application program by packets.
Reference to firmware/stack version	V2.6.x.x

Table 111: Technical Data PROFIBUS DP Master Protocol

© Hilscher, 2008-2014

10.2.14 PROFIBUS DP Slave

Parameter	Description
Maximum number of cyclic input data	244 bytes
Maximum number of cyclic output data	244 bytes
Maximum number of acyclic data (read/write)	240 bytes/telegram
Maximum number of modules	24
Configuration data	Max. 244 bytes
Parameter data	237 bytes application specific parameters
Acyclic communication	DP V1 Class 1 Read/Write DP V1 Class 1 Alarm DP V1 Class 2 Read/Write/Data Transport
Baud rate	9,6 kBits/s, 19,2 kBits/s, 31,25 kBits/s, 45,45 kBits/s 93,75 kBits/s, 187,5 kBits/s, 500 kBits/s, 1, 5 MBits/s, 3 MBits/s, 6 MBits/s, 12 MBit/s Auto baudrate detection is supported
Data transport layer	PROFIBUS FDL
Limitations	SSCY1S – Slave to slave communication state machine not implemented Data exchange broadcast not implemented I&M LR services other than Call-REQ/RES are not supported yet
Reference to firmware/stack version	V2.7.x.x

Table 112: Technical Data PROFIBUS DP Slave Protocol

© Hilscher, 2008-2014

10.2.15 PROFIBUS MPI

Parameter	Description
Maximum number of MPI connections	126
Maximum number of write data	216 bytes
Maximum number of read data	222 bytes
Functions	MPI Read/Write DB (data block), M (marker), Q (output), C (Counter), T (Timer) MPI Read I (Input) Data type bit to access to DB (data block), M (marker), Q (output) and I (Input, read only) MPI Connect (automatically when first read/write function is used) MPI Disconnect, MPI Disconnect All MPI Get OP Status MPI transparent (expert use only)
Baud rate	Fixed values ranging from 9,6 kBits/s to 12 MBit/s Auto-detection mode is supported
Data transport layer	PROFIBUS FDL
Reference to firmware/stack version	2.4.x.x

Table 113: Technical Data PROFIBUS-MPI Protocol

© Hilscher, 2008-2014

10.2.16 CANopen Master

Parameter	Description
Maximum number of CANopen nodes	126
Maximum number of cyclic input data	3584 bytes
Maximum number of cyclic output data	3584 bytes
Maximum number of receive PDOs	512
Maximum number of transmit PDOs	512
Exchange of process data	Via PDO transfer: - synchronized, - remotely requested and - event driven (change of date)
Acyclic communication	SDO Upload/Download, max. 512 bytes per request
Functions	Emergency message (consumer and producer) Node guarding / life guarding, heartbeat PDO mapping NMT Master SYNC protocol (producer) Simple boot-up process, reading object 1000H for identification
Baud rates	10 kBits/s, 20 kBits/s, 50 kBits/s, 100 kBits/s, 125 kBits/s, 250 kBits/s, 500 kBits/s, 800 kBits/s, 1 MBits/s
CAN layer 2 access	Send/receive via API supported (11 bit/29 bit)
Data transport layer	CAN Frames
CAN Frame type for CANopen	11 Bit
Reference to version	V2.11.x.x

Table 114: Technical Data CANopen Master Protocol

© Hilscher, 2008-2014

10.2.17 CANopen Slave

Parameter	Description
Maximum number of cyclic input data	512 bytes
Maximum number of cyclic output data	512 bytes
Maximum number of receive PDOs	64
Maximum number of transmit PDOs	64
Exchange of process data	Via PDO transfer - synchronized, - remotely requested and - event driven (change of date, event timer) On request of the host application program by packet
Acyclic communication	SDO upload/download (server only) Emergency message (producer) Timestamp (producer/consumer)
Functions	Node guarding / life guarding Heartbeat: 1 producer, max. 64 consumer PDO mapping NMT Slave SYNC protocol (consumer) Error behaviour (configurable): - in state operational: change to state pre-operational - in any state: no state change - in state operational or pre-operational: change to state stopped
Baud rates	10 kBits/s, 20 kBits/s, 50 kBits/s, 100 kBits/s, 125 kBits/s, 250 kBits/s, 500 kBits/s, 800 kBits/s, 1 MBits/s Auto baudrate detection is supported
CAN layer 2 access	Send/receive via API supported (11 bit/29 bit)
Data transport layer	CAN Frames
CAN Frame type for CANopen	11 Bit
Reference to firmware/stack version	V3.6.x.x

Table 115: Technical Data CANopen Slave Protocol

© Hilscher, 2008-2014

10.2.18 DeviceNet Master

Parameter	Description
Maximum number of DeviceNet slaves	63
Maximum number of total cyclic input data	3584 bytes
Maximum number of total cyclic output data	3584 bytes
Maximum number of cyclic input data	255 bytes/connection
Maximum number of cyclic output data	255 bytes/connection
Maximum Configuration data	1000 bytes/slave
Acyclic communication	Explicit connection All service codes are supported
Connections	Bit Strobe Change of State Cyclic Poll Explicit Peer-to-Peer Messaging
Function	Quick Connect
Fragmentation	Explicit and I/O
UCMM	Supported
Objects	Identity Object (Class Code 0x01) Message Router Object (Class Code 0x02) DeviceNet Object (Class Code 0x03) Connection Object (Class Code 0x05) Acknowledge Handler Object (Class Code 0x06)
Baud rates	125 kBits/s, 250 kBit/s, 500 kBit/s Auto baudrate detection is not supported
Data transport layer	CAN frames
Reference to firmware/stack version	V2.3.x.x

Table 116: Technical Data DeviceNet Master Protocol

© Hilscher, 2008-2014

10.2.19 DeviceNet Slave

Parameter	Description
Maximum number of cyclic input data	255 bytes
Maximum number of cyclic output data	255 bytes
Acyclic communication	Get_Attribute_Single/All Max. 240 bytes per request Set_Attribute_Single/All Max. 240 bytes per request
Connections	Poll Change-of-state Cyclic Bit-strobe
Explicit messaging	Supported
Fragmentation	Explicit and I/O
UCMM	Not supported
Baud rates	125 kBits/s, 250 kBit/s, 500 kBit/s Auto baudrate detection is not supported
Data transport layer	CAN frames
Reference to firmware/stack version	V2.3.x.x

Table 117: Technical Data DeviceNet Slave Protocol

© Hilscher, 2008-2014

10.2.20 CC Link Slave

Parameter	Description
Firmware works according to CC-Link Version 2.0:	
Station Types	Remote Device Station (up to 4 occupied stations)
Maximum input data	368 bytes
Maximum output data	368 bytes
Input data remote device station	112 bytes (RY) and 256 bytes (RWw)
Output data remote device station	112 bytes (RX) and 256 bytes (RWr)
Extension cycles	1, 2, 4, 8
Baud rates	156 kBit/s, 625 kBit/s, 2500 kBit/s, 5 MBit/s, 10 MBit/s
Limitation	Intelligent Device Station not supported
Firmware works according to CC-Link Version 1.11:	
Station Types	Remote I/O station, Remote device station' (up to 4 occupied stations)
Maximum input data	48 bytes
Maximum output data	48 bytes
Input data remote I/O station	4 bytes (RY)
Output data remote I/O station	4 bytes (RX)
Input data remote device station	4 bytes (RY) and 8 bytes (RWw) per occupied station
Output data remote device station	4 bytes (RX) and 8 bytes (RWr) per occupied station
Baud rates	156 kBit/s, 625 kBit/s, 2500 kBit/s, 5 MBit/s, 10 MBit/s
Firmware	
Reference to firmware/stack version	V2.9.x.x

Table 118: Technical Data CC-Link-Slave Protocol

© Hilscher, 2008-2014

11 Annex

11.1 Matrix Label

A matrix label is on the device. It contains 3 items:

1. Part number
2. Hardware Revision
3. Serial number

The figure shows part number 1250.100, hardware revision 3 and serial number 23456.



Figure 42: Matrix Label

11.2 EtherCAT Summary over Vendor ID, Conformance test, Membership and Network Logo

11.2.1 Vendor ID

The communication interface product is shipped with Hilscher's secondary vendor ID, which has to be replaced by the Vendor ID of the company shipping end products with the integrated communication interface. End Users or Integrators may use the communication interface product without further modification if they re-distribute the interface product (e.g. PCI Interface card products) only as part of a machine or machine line or as spare part for such a machine. In case of questions, contact Hilscher and/or your nearest ETG representative. The ETG Vendor-ID policies apply.

© Hilscher, 2008-2014

11.2.2 Conformance

EtherCAT Devices have to conform to the EtherCAT specifications. The EtherCAT Conformance Test Policies apply, which can be obtained from the EtherCAT Technology Group (ETG, www.ethercat.org).

Hilscher range of embedded network interface products are conformance tested for network compliance. This simplifies conformance testing of the end product and can be used as a reference for the end product as a statement of network conformance (when used with standard operational settings). It must however be clearly stated in the product documentation that this applies to the network interface and not to the complete product.

Conformance Certificates can be obtained by passing the conformance test in an official EtherCAT Conformance Test lab. Conformance Certificates are not mandatory, but may be required by the end user.

11.2.3 Certified Product vs. Certified Network Interface

The EtherCAT implementation may in certain cases allow one to modify the behavior of the EtherCAT network interface device in ways which are not in line with EtherCAT conformance requirements. For example, certain communication parameters are set by a software stack, in which case the actual software implementation in the device application determines whether or not the network interface can pass the EtherCAT conformance test. In such cases, conformance test of the end product must be passed to ensure that the implementation does not affect network compliance.

Generally, implementations of this kind require in-depth knowledge in the operating fundamentals of EtherCAT. To find out whether or not a certain type of implementation can pass conformance testing and requires such testing, contact EtherCAT Technology Group (“ETG”, www.ethercat.org) and/or your nearest EtherCAT conformance test centre. EtherCAT may allow the combination of an untested end product with a conformant network interface. Although this may in some cases make it possible to sell the end product without having to perform network conformance tests, this approach is generally not endorsed by Hilscher. In case of questions, contact Hilscher and/or your nearest ETG representative.

11.2.4 Membership and Network Logo

Generally, membership in the network organization and a valid Vendor-ID are prerequisites in order to be able to test the end product for conformance. This also applies to the use of the EtherCAT name and logo, which is covered by the ETG marking rules.

Vendor ID Policy accepted by ETG Board of Directors, November 5, 2008

© Hilscher, 2008-2014

11.3 Notes on earlier Hardeware Revisions

11.3.1 Failure in 10 MBit/s Half Duplex Mode and Workaround

The note is only valid for the PC cards cifX up to serial numbers indicated:

PC Cars cifX	Part No	up to Serial Number
CIFX 104-RE\F	1278.101	20003

NOTICE

Failure of the Network Communication

- Do not operate hardware with the communication controllers netX 50, netX100 or netX 500 with the protocols Ethernet TCP/UDP/IP, EtherNet/IP or Modbus TCP at 10 MBit/s in half-duplex mode, otherwise failure of the network communication can occur.
- Use only switches or 10/100 MBit/s dual-speed hubs and ensure that the network operates at 100 MBit/s and in full-duplex mode.

Affected Hardware

Hardware with the communication controller netX 50, netX 100 or netX 500; netX/Internal PHYs.

When can this Failure occur?

When using standard Ethernet communication with 10 MBit/s half duplex mode, the PHY gets stuck in case of network collisions. Then no further network communication is possible. Only device power cycling allows Ethernet communication again.

This problem can only occur with Ethernet TCP/UDP IP, EtherNet/IP or Modbus TCP protocols when using hubs at 10 MBit/s. The issue described above is not applicable for protocols which use 100 MBit/s or full duplex mode.

Solution / Workaround:

Do not use 10 MBit/s-only hubs. Use either switches or 10/100 MBit/s Dual Speed hubs, to make sure the netX Ethernet ports are connected with 100 MBit/s or in full duplex mode.

This erratum is fixed with all components of the ‘Y’ charge (9 digit charge number shows ‘Y’ at position 5 (nnnnYnnnn).

Reference

“Summary of 10BT problem on EthernetPHY”,
RenesasElectronics Europe, April 27, 2010

© Hilscher, 2008-2014

11.4 Disposal of Waste Electronic Equipment

According to the European Directive 2002/96/EG “Waste Electrical and Electronic Equipment (WEEE)”, waste electronic equipment may not be disposed of as household waste. As a consumer, you are legally obliged to dispose of all waste electronic equipment according to national and local regulations.

Waste Electronic Equipment

- This product must not be treated as household waste.
- This product must be disposed of at a designated waste electronic equipment collecting point.

11.5 References

[1] THE CIP NETWORKS LIBRARY, Volume 6, CompoNet Adaptation of CIP, Edition 1.4 November 2008

[2] Data sheet MOD JACK – MJIM:
https://www.erni-x-press.com/de/downloads/zeichnungen/203313.pdf

[3] Design - Specification for VARAN Rev. 0.76, section 5.1.4 VARAN Splitter

References Protocol API Manuals
• CANopen Master Protocol API Manual, Revision 14, Hilscher GmbH 2013
• CANopen Slave Protocol API Manual (V3), Revision 5, Hilscher GmbH 2013
• DeviceNet Master Protocol API Manual, Revision 10, Hilscher GmbH 2013
• DeviceNet Slave Protocol API Manual, Revision 13, Hilscher GmbH 2013
• EtherCAT Master Protocol API Manual (V3), Revision 5, Hilscher GmbH 2013
• EtherCAT Slave Protocol API Manual, Revision 3 (V4), Hilscher GmbH 2013
• EtherCAT Slave Protocol API Manual, Revision 21 (V2), Hilscher GmbH 2013
• EtherNetIP Scanner Protocol API Manual, Revision 13, Hilscher GmbH 2013
• EtherNetIP Adapter Protocol API Manual, Revision 12, Hilscher GmbH 2013
• Open Modbus/TCP Protocol API Manual, Revision 8, Hilscher GmbH 2013
• POWERLINK Controlled Node/Slave Protocol API Manual, Revision 12, Hilscher GmbH 2013
• PROFIBUS DP Master Protocol API Manual, Revision 18, Hilscher GmbH 2013
• PROFIBUS DP Slave Protocol API Manual, Revision 15, Hilscher GmbH 2013
• PROFIBUS MPI Protocol API Manual, Revision 4, Hilscher GmbH 2011
• PROFINET IO-Controller Protocol API Manual, Revision 18, Hilscher GmbH 2013
• PROFINET IO-Device Protocol API Manual (V3.4), Revision 13, Hilscher GmbH 2013
• PROFINET IO-Device Protocol API Manual (V3.5), Revision 6, Hilscher GmbH 2013
• sercos Master Protocol API Manual, Revision 11, Hilscher GmbH 2013
• sercos Slave Protocol API Manual (V3), Revision 12, Hilscher GmbH 2013
• VARAN Client Protocol API Manual, Revision 3, Hilscher GmbH 2013

Table 119: References Protocol API Manuals

References referring to the safety issues are listed separately in section *References Safety* on page 24.

References referring to the Standard Bus Specifications for PC/104 are listed separately *Reference PC/104 Specification* on page 95.

© Hilscher, 2008-2014

11.6 List of Figures

Figure 1: System Overview cifX to update Firmware, Driver and Software 37
Figure 2: CIFX 104-RE* 38
Figure 3: CIFX 104-RE-R* 39
Figure 4: Basic Card for CIFX 104-RE\F 40
Figure 5: Basic Card for CIFX 104-RE-R\F 41
Figure 6: CIFX 104-DP 42
Figure 7: CIFX 104-DP-R 43
Figure 8: CIFX 104-CO 44
Figure 9: CIFX 104-CO-R 45
Figure 10: CIFX 104-DN 46
Figure 11: CIFX 104-DN-R 47
Figure 12: Basic Card CIFX 104-FB\F for CIFX 104-DP\F, CIFX 104-CO\F, CIFX 104-DN\F, CIFX 104-CC\F 48
Figure 13: Basic Card CIFX 104-FB-R\F for CIFX 104-DP-R\F, CIFX 104-CO-R\F, CIFX 104-DN-R\F 48
Figure 14: Ethernet Assembly Interface (AIFX-RE)* 49
Figure 15: Front Side Ethernet Assembly Interface (AIFX-RE) 49
Figure 16: Dimensioning and LED Display Ethernet Assembly Interface (AIFX-RE) 49
Figure 17: PROFIBUS Assembly Interface (AIFX-DP) 50
Figure 18: Front Side PROFIBUS Assembly Interface (AIFX-DP) 50
Figure 19: Dimensioning and LED Display PROFIBUS Assembly Interface (AIFX-DP) 50
Figure 20: CANopen Assembly Interface (AIFX-CO) 51
Figure 21: Front Side Assembly Interface (AIFX-CO) 51
Figure 22: Dimensioning and LED Display CANopen Assembly Interface (AIFX-CO) 51
Figure 23: DeviceNet Assembly Interface (AIFX-DN) 52
Figure 24: Front Side DeviceNet Assembly Interface (AIFX-DN) 52
Figure 25: Dimensioning and LED Display DeviceNet Assembly Interface (AIFX-DN) 52
Figure 26: CC-Link Assembly Interface (AIFX-CC) 53
Figure 27: Front Side CC-Link Assembly Interface (AIFX-CC) 53
Figure 28: Dimensioning and LED Display CC-Link Assembly Interface (AIFX-CC) 53
Figure 29: Diagnostic Assembly Interface (AIFX-DIAG) 54
Figure 30: Front Side Diagnostic Assembly Interface (AIFX-DIAG) 54
Figure 31: Dimensioning and LED Display Diagnostic Assembly Interface (AIFX-DIAG) 54
Figure 32: Connecting the Ethernet Assembly Interface (AIFX-RE) to the Basic Card CIFX 104-RE\F (Example) 60
Figure 33: Connecting the CANopen Assembly Interface (AIFX-CO) to the Basic Card 104-FB-R\F (Example) 60
Figure 34: Connecting the Diagnostic Assembly Interface (AIFX-DIAG) to the Basic Card CIFX 104-FB-R\F (Example) 61
Figure 35: Ethernet Pin Assignment at the RJ45 Socket for cifX or AIFX 87
Figure 36: PROFIBUS Interface (DSub female connector, 9 pin), X400 89
Figure 37: CANopen Interface (DSub male connector, 9 pin), X400 89
Figure 38: DeviceNet Interface (CombiCon male Connector, 5 pin), X360 90
Figure 39: CC-Link Interface (CombiCon male Connector, 5 pin) 90
Figure 40: Mini-B USB Connector (5 Pin) 91
Figure 41: 1x20 Pins for CIFX 104-RE\F, CIFX 104-RE-R\F 92
Figure 42: Matrix Label 137

11.7 List of Tables

Table 1: List of Revisions 8

© Hilscher, 2008-2014

Table 2: Reference on Hardware PC Cards cifX, AIFX Assembly Interfaces 9
Table 3: Reference on Driver and Software 9
Table 4: Reference on Firmware 10
Table 5: PROFINET IO-Device Firmware Version 3.4 and 3.5, Header, GSDML and Protocol API Manual 13
Table 6: EtherCAT-Slave Firmware Version 2.5 and 4.2, Header, XML and Protocol API Manual 14
Table 7: Device Description Files for PC Cards cifX 15
Table 8: PC Cards cifX and the Real-Time Ethernet or Fieldbus Systems realized thereby 20
Table 9: PC Cards cifX with AIFX Assembly Interface 20
Table 10: Signal Words and Safety Signal in Safety Messages on Personal Injury 24
Table 11: Signal Words and Safety Signal in Safety Messages on Property Damage 24
Table 12: PC Cards PC/104: CIFX 104-XX and CIFX 104-XX-R 26
Table 13: PC Cards PC/104: CIFX 104-XX\F, CIFX 104-XX-R\F 27
Table 14: AIFX Assembly Interfaces for PC Cards cifX with Cable Connector 27
Table 15: Slot for the PC Cards cifX PC/104 28
Table 16: Requirements Power Supply and Host Interface for PC Cards cifX PC/104 28
Table 17: Panel Cutout at the at the front plate of the PC cabinet 28
Table 18: Required Panel Cutout and Holes for AIFX 29
Table 19: Requirements to operate PC Cards cifX properly 30
Table 20: Steps for the Software and Hardware Installation, the Configuration and for the Diagnosis of a PC Card cifX PC/104 (Master and Slave) 34
Table 21: Notes for the Configuration of the Master Device 36
Table 22: Device Names in SYCON.net by Communication Protocol 36
Table 23: Starting Address and Interrupt for 16 KByte Dual-Port Memory 57
Table 24: Overview LEDs Real-Time Ethernet Systems 64
Table 25: LED Names 64
Table 26: Overview LEDs by Fieldbus System for 1- and 2-Channel Devices 65
Table 27: LED Names 65
Table 28: System Status LED 65
Table 29: Power On LED 65
Table 30: LEDs EtherCAT Master 66
Table 31: LED State Definition for EtherCAT Master for the RUN and ERR LEDs 66
Table 32: LEDs EtherCAT Slave 67
Table 33: LED State Definition for EtherCAT Slave for the RUN and ERR LEDs 67
Table 34: LEDs EtherNet/IP Scanner (Master) 68
Table 35: LEDs EtherNet/IP Adapter (Slave) 69
Table 36: LEDs Open Modbus/TCP 70
Table 37: LEDs POWERLINK Controlled Node Controlled Node/Slave 71
Table 38: LED State Definition for POWERLINK Controlled Node Controlled Node/Slave for the BS/BE LEDs 71
Table 39: LEDs PROFINET IO-Controller 72
Table 40: LEDs PROFINET IO-Device 73
Table 41: LEDs sercos Master 74
Table 42: LED State Definition for sercos Master for the STA and ERR LEDs 74
Table 43: LEDs sercos Slave 75
Table 44: LED State Definition for sercos Slave for the S3 LED 76
Table 45: LEDs VARAN Client 76
Table 46: LED State Definition for VARAN Client for the RUN and ERR LEDs 76
Table 47: LEDs PROFIBUS DP Master – 1 Communication Status LED (current Hardware Revision) 77
Table 48: LEDs PROFIBUS DP Master – 2 Communication Status LEDs (AIFX-DP connected or prior Hardware Revision) 77
Table 49: LEDs PROFIBUS DP Slave – 1 Communication Status LED (current Hardware Revision) 78
Table 50: LEDs PROFIBUS DP Slave – 2 Communication Status LEDs (AIFX-DP connected or prior Hardware Revision) 78
Table 51: LEDs PROFIBUS MPI – 1 Communication Status LED 79

© Hilscher, 2008-2014

Table 52: LEDs PROFIBUS MPI – 2 Communication Status LEDs (AIFX-DP connected) 79
Table 53: LEDs CANopen Master – 1 Communication Status LED (current Hardware Revision) 80
Table 54: LED State Definition for CANopen Master for the CAN LED 80
Table 55: LEDs CANopen Master – 2 Communication Status LEDs (AIFX-CO connected or prior Hardware Revision) 81
Table 56: LED State Definition for CANopen Master for the CAN or RUN/ERR LEDs 81
Table 57: LEDs CANopen Slave – 1 Communication Status LED (current Hardware Revision) 82
Table 58: LED State Definition for CANopen Slave for the CAN LED 82
Table 59: LEDs CANopen Slave – 2 Communication Status LEDs (AIFX-CO connected or prior Hardware Revision) 83
Table 60: LED State Definition for CANopen Slave for the CAN or RUN/ERR LEDs 83
Table 61: LEDs DeviceNet Master 84
Table 62: LED State Definition for DeviceNet Master for the MNS LED 84
Table 63: LEDs DeviceNet Slave 85
Table 64: LED State Definition for DeviceNet Slave for the MNS LED 85
Table 65: LEDs CC-Link Slave 86
Table 66: Ethernet Pin Assignment at the RJ45 Socket for cifX or AIFX 87
Table 67: Ethernet Connection Data 88
Table 68: Use of Hubs and Switches 88
Table 69: PROFIBUS Interface, X400 89
Table 70: CANopen Interface, X400 89
Table 71: DeviceNet Interface, X360 90
Table 72: CC-Link Interface 90
Table 73: Pin Assignment Mini-B USB Connector 91
Table 74: Pin Assignment for Cable Connector Ethernet X4 or X304 92
Table 75: Pin Assignment for Cable connector Fieldbus X3, X304 or X4 93
Table 76: Pin Assignment for Cable connector DIAG X3 or X303 93
Table 77: Pin Assignment for SYNC Connector, X51 94
Table 78: SYNC Connector: SYNC Signal, Connector, Max. Cable Length 94
Table 79: Meaning of the SYNC Signals for each Protocol 94
Table 80: Pin Assignment at the PC/104 Bus 95
Table 81: Reference PC/104 Specification 95
Table 82: Pin Assignment for PC/104-Bus, X1 (Control Signals used on the 8 Bit Connector) 96
Table 83: Pin Assignment for PC/104-Bus, X2 (Used Control Signals on the Expansion Connector) 97
Table 84: Technical Data CIFX 104-RE, CIFX 104-RE-R 99
Table 85: Technical Data CIFX 104-RE\F, CIFX 104-RE-R\F 101
Table 86: Technical Data CIFX 104-DP, CIFX 104-DP-R 103
Table 87: Technical Data CIFX 104-DP\F, CIFX 104-DP-R\F 104
Table 88: Technical Data CIFX 104-CO, CIFX 104-CO-R 106
Table 89: Technical Data CIFX 104-CO\F, CIFX 104-CO-R\F 107
Table 90: Technical Data CIFX 104-DN, CIFX 104-DN-R 109
Table 91: Technical Data CIFX104C-DN\F, CIFX 104-DN-R\F 110
Table 92: Technical Data CIFX104C-CC\F 112
Table 93: Technical Data AIFX-RE 112
Table 94: Technical Data AIFX-DP 113
Table 95: Technical Data AIFX-CO 114
Table 96: Technical Data AIFX-DN 115
Table 97: Technical Data AIFX-CC 116
Table 98: Technical Data AIFX-DIAG 117
Table 99: Technical Data EtherCAT Master Protocol 118
Table 100: Technical Data EtherCAT Slave Protocol 119
Table 101: Technical Data EtherNet/IP Scanner (Master) Protocol 120
Table 102: Technical Data EtherNet/IP Adapter (Slave) Protocol 121

© Hilscher, 2008-2014

Table 103: Technical Data Open Modbus/TCP Protocol 122
Table 104: Technical Data POWERLINK Controlled Node (Slave) Protocol 122
Table 105: Technical Data PROFINET IO RT Controller 124
Table 106: Technical Data PROFINET IO RT IRT Device Protocol 124
Table 107: Technical Data PROFINET IO RT IRT Device Protocol 125
Table 108: Technical Data sercos Master Protocol 126
Table 109: Technical Data sercos Slave Protocol 127
Table 110: Technical Data VARAN Client Protocol 128
Table 111: Technical Data PROFIBUS DP Master Protocol 129
Table 112: Technical Data PROFIBUS DP Slave Protocol 130
Table 113: Technical Data PROFIBUS-MPI Protocol 131
Table 114: Technical Data CANopen Master Protocol 132
Table 115: Technical Data CANopen Slave Protocol 133
Table 116: Technical Data DeviceNet Master Protocol 134
Table 117: Technical Data DeviceNet Slave Protocol 135
Table 118: Technical Data CC-Link-Slave Protocol 136
Table 119: References Protocol API Manuals 140

© Hilscher, 2008-2014

11.8 Glossary

10-Base T

Standard for communication on Ethernet over twisted pair lines with RJ45 connectors and a Baud rate of 10 MBit/s (according to the IEEE 802.3 specification).

100-Base TX

Standard for communication on Ethernet over unshielded twisted pair lines with RJ45 connectors and a baud rate of 100 MBit/s according to the IEEE 802. specification

AIFX

Assembly **I**nter**F**ace based on net**X**

Auto-Crossover

Auto-Crossover is a feature of an interface: An interface with Auto-Crossover capability will automatically detect and correct if the data lines have been exchanged vice versa.

Auto-Negotiation

Auto-Negotiation is a feature of an interface: An interface with Auto-Negotiation will automatically determine a set of correct communication parameters.

Baud rate

Data transmission speed of a communication channel or interface.

Boot loader

Program loading the firmware into the memory of a device in order to be executed.

Ch0, Ch1 …

Within the configuration software SYCON.net the communication channels are named ‚Ch0', Ch1' ….

For the Real-Time-Ethernet devices cifX, comX and netJACK and the Real-Time Ethernet protocols used with it, the following shall apply:

'Ch0' in SYCON.net: Both ports of the Ethernet RJ45 connector CH0 and CH1 are assigned always to channel 0 in SYCON.net.

'Ch1' in SYCON.net: Depending on the firmware channel 1 in SYCON.net can be used as an additional communication channel.

CH0, CH1 (Ch0, Ch1)

Names for the ports of an Ethernet RJ45 socket with two Ethernet channels.

CH0 stands for Ethernet channel 0.

CH1 stands for Ethernet channel 1.

© Hilscher, 2008-2014

cifX

Communication **I**nter**F**ace based on net**X**

cifX TCP/IP Server

cifX TCP Server.exe

Program for the remote diagnostics via Ethernet.

Name: **cifX TCP/IP Server for SYCON.net**

User Interface: **TCP/IP Server for cifX**

Coil

A coil is a single bit in the memory that can be accessed using Modbus: read or write access with FC 1, 5, 15. Depending on the used Modbus function code a single coil or several coils lying in succession can be accessed.

CSP

electronic device data sheet, required for each CC-Link device

Device Description File

A file containing configuration information about a device being a part of a network that can be read out by masters for system configuration. Device Description Files use various formats which depend on the communication system.

DHCP

Dynamic Host Configuration Protocol

This is a protocol simplifying the configuration of IP networks by automatically assigning IP addresses.

Discrete Input

A “Discrete Input” (as defined in the Modbus terminology) is a single bit in the memory which can be accessed using Modbus (read with FC 2).

DP

Decentral Periphery

DPM

Dual-Port Memory

EDS

Electronic Data Sheet

EDS file

A special kind of Device Description File used for example by EtherNet/IP.

EtherCAT

A communication system for industrial Ethernet designed and developed by Beckhoff Automation GmbH.

© Hilscher, 2008-2014

Ethernet

A networking technology used both for office and industrial communication via electrical or optical connections. It has been developed and specified by the Intel, DEC and XEROX. It provides data transmission with collision control and allows various protocols. As Ethernet is not necessarily capable for real-time application, various real-time extensions have been developed.

EtherNet/IP

A communication system for industrial Ethernet designed and developed by Rockwell. It partly uses the CIP (Common Industrial Protocol).

Ethernet POWERLINK

A communication system for industrial Ethernet designed and developed by B&R. It partly uses CANopen technologies.

FDL

Fieldbus Data Link defines the PROFIBUS communication on layer 2, identical for DP and FMS

Firmware

Software running inside a device providing the basic functionality of this device. The firmware is stored remanently in the flash memory circuit of the device. It can be updated by a firmware download.

Full duplex

Full duplex denominates a telecommunication system between two communication partners which allows simultaneous communication in both directions is called a full-duplex telecommunication system. At such a system, it will be possible to transmit data even if currently data are received. Full-duplex is the opposite of Half_duplex.

Function code

A function code (FC) is a standardized method to access, i. e. read or write on coils (Bits) or registers via Modbus.

Modbus function codes are elements of Modbus request/reply telegrams.

GSD

Generic Station Description, Device description file

GSD file

A special kind of Device Description File used by PROFIBUS (GSD = Generic Station Description).

GSDML

Generic Station Description Markup Language

XML based device description file.

GSDML file

A special kind of XML-based Device Description File used by PROFINET.

© Hilscher, 2008-2014

Half duplex

Half duplex denominates a telecommunication system between two communication partners which does not allow simultaneous, but alternating, communication in both directions is called a half-duplex telecommunication system. At such a system, receiving data inhibits the transmission of data. Half-duplex is the opposite of _Full_duplex.

Hub

A network component connecting multiple communication partners with each other. A hub does not provide own intelligence, thus it does not analyze the data traffic and sends received data to all connected communication partners. A hub can be used for setting up a star topology.

Industrial Ethernet

See Real-Time Ethernet

© Hilscher, 2008-2014

IP

Internet Protocol.

IP belongs to the TCP/IP family of protocols and is defined in RFC791. It is based on layer 3 of the ISO/OSI 7 layer model of networking.

It is a connectionless protocol, i.e. you do not need to open a connection to a computer before sending an IP data packet to it. Therefore IP is not able to guarantee that the IP data packets really arrive at the recipient. On IP level neither the correctness of data nor the consistence and completeness are checked.

IP defines special addressing mechanisms, see IP Address.

IP Address

Address within IP (the Internet Protocol, part of TCP/IP).

An IP address is an address identifying a device or a computer within a network using the IP protocol. IP addresses are defined as a 32 bit number. Usually, for ease of notation the IP address is divided into four 8 bit numbers which are represented in decimal notation and separated by points:

a.b.c.d

where a.b.c.d are each integer values between 0 and 255.

Example: 192.168.30.15

However, not all combinations are allowed, some are reserved for special purposes.

The IP address 0.0.0.0 is defined as invalid.

MAC-ID

MAC = Media Access Control

Definition for Ethernet:

A MAC-ID is on delivery a unique (physical) Ethernet address of the device.

MAC-IDs are defined as a 48 bit number. Usually, for ease of notation the IP address is divided into six 8 bit numbers which are represented in hexadecimal notation and separated by “minus”-signs (-):

A-B-C-D-E-F

where A-B-C-D-E-F are each integer values between 0 and 255.

Example: 00-02-A2-20-91-18

Definition for DeviceNet:

The network address of a device serves to distinguish itself on a DeviceNet fieldbus system from any other device or Slave on this network. This should be a unique number for each device. A valid MAC-ID address is within a range of 0 to 63 and can be re-entered and changed in the MAC-ID box in the Device Configuration Dialog.

© Hilscher, 2008-2014

Modbus Data Model

The data model distinguishes four basic types of data areas:

• Discrete Inputs (inputs) = FC 2 (Read)

• coils (outputs) = FC 1, 5, 15 (Write and Read back)

• Input register (input data) = FC 4 (Read)

• Holding register (output data) = FC 3, 6, 16, 23 (Write and Read back).

It should be noted, however, that depending on the device manufacturer and device type:

• the data area in the device may be present or not,

• and two data areas can be combined into one data region. For example, discrete inputs and input registers can be a common data area, which can be accessed with read-FC 2 and FC 4.

• Further FC 1 and FC 3 are used instead of reading back the inputs to read the outputs.

MPI

Multi Point Interface

The MPI is a proprietary interface of the SIMATIC® S7® series of PLCs. It is compatible to PROFIBUS and based on RS-485. It usually works with a transmission rate of 187.5 kBaud.

netX

networX on chip, Hilscher network communication controllers

netX Configuration Tool

The netX Configuration Tool allows users to operate cifX or netX based devices in different networks. Its graphical user interface serves as a configuration tool for the installation, configuration and diagnosis of the devices.

Object Dictionary

An object dictionary is a storage area for device parameter data structures. It is accessed in standardized manner.

Open Modbus/TCP

A communication system for Industrial Ethernet designed and developed by Schneider Automation and maintained by the Modbus-IDA organization based on the Modbus protocols for serial communication.

PCB

Printed Circuit Board, (printed = machine-made) circuit board

© Hilscher, 2008-2014

PC Card cifX

Communication Interfaces of the cifX product family of Hilscher on the basis of the communication controller netX 100:

for the Real-Time Ethernet systems

- EtherCAT
- EtherNet/IP
- Open-Modbus/TCP
- POWERLINK
- PROFINET IO
- sercos
- VARAN

and for the fieldbus systems

- PROFIBUS DP
- PROFIBUS MPI
- CANopen
- DeviceNet
- CC-Link

as Communication Interface netX with PCI Bus

- PCI (CIFX50),
- PCI Express (CIFX 50E),
- Low Profile PCI Express (CIFX 70E, CIFX 100EH-RE\CUBE*),
- Compact PCI (CIFX80),
- Mini PCI (CIFX90),
- Mini PCI Express (CIFX 90E),
- PC/104 (CIFX 104)

and as Communication Interface netX with PC/104 (ISA Bus)

- PC/104 (CIFX 104).

*only Real-Time Ethernet

PROFINET

A communication system for Industrial Ethernet designed and developed by PROFIBUS & PROFINET International (PI). It uses some mechanisms similar to those of the PROFIBUS field bus.

PROFINET IO Controller

A PROFINET control unit responsible for the defined run-up of an I/O subsystem and the cyclic or acyclic data exchange.

PROFINET IO Device

A PROFINET field device that cyclically receives output data from its IO-Controller and responds with its input data.

RE

RE stands for Real-Time Ethernet

© Hilscher, 2008-2014

Real-Time Ethernet

Real-Time Ethernet (Industrial Ethernet) is an extension of the Ethernet networking technology for industrial purposes with very good real-time features and performance. There is a variety of different Real-Time Ethernet systems on the market which are incompatible with each other. The most important systems of these are

- EtherCAT
- EtherNet/IP
- Ethernet POWERLINK
- Open Modbus/TCP
- PROFINET
- sercos
- VARAN

Register

A register is a 16-bit wide storage area for data which can be accessed and addressed as a unit by some of the Modbus Function Codes.

Depending on the used Modbus function code a single register or multiple registers sequentially located can be accessed.

Modbus differs Input Registers (FC 4) and Holding Registers (FC 3, 6, 16, 23).

Remanent

Remanent memory holds its data even after power-off, for instance flash memory is remanent. It is also called non-volatile memory.

RJ45

A connector type often used for Ethernet connection. It has been standardized by the Federal Communications Commission of the USA (FCC).

sercos

A communication system for industrial Ethernet designed and developed by Bosch-Rexroth and supported by sercos International.

Switch

A network component connecting multiple communication partners (or even entire branches of a network) with each other. A switch is an intelligent network component which analyzes network traffic in order to decide on its own. For the connected communication partners a switch behaves transparently.

SYCON.net

FDT/DTM based configuration and diagnosis software by Hilscher

SYNC

Synchronization cycle of the master

© Hilscher, 2008-2014

TCP/IP

Transport Control Protocol/Internet Protocol connection-orientated, secure transfer protocol as basis for the Internet-protocols

UCMM

Unconnected Message Manager

VARAN

Versatile **A**utomation **R**andom **A**ccess **N**etwork

A communication system for industrial Ethernet based on the DIAS-BUS developed by Sigmatek. The system is supported by the VARAN-BUS-NUTZERORGANISATION (VNO).

Watchdog Timer

A watchdog timer provides an internal supervision mechanism of a communication system. It supervises that an important event happens within a given timeframe (the watchdog time which can be adjusted accordingly, for instance by a parameter in the _Warmstart message) and causes an alarm otherwise (usually this is accomplished by changing the operational state of the communication system to a more safe state).

XDD file

A special kind of Device Description file used by Ethernet POWERLINK.

XML

XML means Extended Markup Language. It is a symbolic language for structuring data systematically. XML is standard maintained by the W3C (World-wide web consortium). Device Description Files often use XML-based formats for storing the device-related data appropriately.

© Hilscher, 2008-2014

11.9 Contacts

Headquarters

Germany
Hilscher Gesellschaft für
Systemautomation mbH
Rheinstrasse 15
65795 Hattersheim
Phone: +49 (0) 6190 9907-0
Fax: +49 (0) 6190 9907-50
E-Mail: info@hilscher.com

Support
Phone: +49 (0) 6190 9907-99
E-Mail: de.support@hilscher.com

Subsidiaries

China
Hilscher Systemautomation (Shanghai) Co. Ltd.
200010 Shanghai
Phone: +86 (0) 21-6355-5161
E-Mail: info@hilscher.cn

Support
Phone: +86 (0) 21-6355-5161
E-Mail: cn.support@hilscher.com

France
Hilscher France S.a.r.l.
69500 Bron
Phone: +33 (0) 4 72 37 98 40
E-Mail: info@hilscher.fr

Support
Phone: +33 (0) 4 72 37 98 40
E-Mail: fr.support@hilscher.com

India
Hilscher India Pvt. Ltd.
New Delhi - 110 065
Phone: +91 11 26915430
E-Mail: info@hilscher.in

Italy
Hilscher Italia S.r.l.
20090 Vimodrone (MI)
Phone: +39 02 25007068
E-Mail: info@hilscher.it

Support
Phone: +39 02 25007068
E-Mail: it.support@hilscher.com

Japan
Hilscher Japan KK
Tokyo, 160-0022
Phone: +81 (0) 3-5362-0521
E-Mail: info@hilscher.jp

Support
Phone: +81 (0) 3-5362-0521
E-Mail: jp.support@hilscher.com

Korea
Hilscher Korea Inc.
Seongnam, Gyeonggi, 463-400
Phone: +82 (0) 31-789-3715
E-Mail: info@hilscher.kr

Switzerland
Hilscher Swiss GmbH
4500 Solothurn
Phone: +41 (0) 32 623 6633
E-Mail: info@hilscher.ch

Support
Phone: +49 (0) 6190 9907-99
E-Mail: ch.support@hilscher.com

USA
Hilscher North America, Inc.
Lisle, IL 60532
Phone: +1 630-505-5301
E-Mail: info@hilscher.us

Support
Phone: +1 630-505-5301
E-Mail: us.support@hilscher.com

© Hilscher, 2008-2014